

# Huawei Access Switch Alarm Resolution SOP

**Node:** Huawei-Access-Delhi-NCR-16 | **Vendor:** Huawei | **Severity:** Major | **Alarm Code:** ALARM\_4096

## Description

This SOP outlines the steps for resolving a major alarm on Huawei Access Switch Node ID: Huawei-Access-Delhi-NCR-16, with Alarm Code: ALARM\_4096

## Potential Root Causes

| Cause               | Probability |
|---------------------|-------------|
| Hardware Failure    | High        |
| Software Glitch     | Medium      |
| Configuration Issue | Low         |

## Diagnostic Commands

```
display version
display diagnose
diagconf version
display fault
display alarm
```

## Resolution Steps

- Step 1: {Step 1: 'Check the event log to determine the exact cause of the alarm'}
- Step 2: {Step 2: 'Run the command "display fault" to identify the faulty component'}
- Step 3: {Step 3: 'Replace the faulty component and verify the fix by running the command "display fault"'}
- Step 4: {Step 4: 'Verify the software version and update it if necessary using the command "software install "'}
- Step 5: {Step 5: 'Verify the configuration and make any necessary changes using the command "system-view"'}

## Post-Check Verification

```
display fault
display alarm
```

```
display version  
display diagnose  
ping
```