

Huawei Access Switch Node - Alarm 8094 SOP

Node: Huawei-Access-Kolkata-WB-116 | **Vendor:** Huawei | **Severity:** Minor | **Alarm Code:** ALARM_8094

Description

Alarm 8094 on Huawei Access Switch Node (Node ID: Huawei-Access-Kolkata-WB-116) indicates a minor issue. This SOP outlines the troubleshooting process to resolve the issue.

Potential Root Causes

Cause	Probability
Incorrect configuration settings	Medium
Hardware failure	Low
Software bug	Low

Diagnostic Commands

```
display current-configuration | include snmp-agent
display version
display system dcd
display device internal-info
```

Resolution Steps

Step 1: {'Step': '1. Check the configuration settings.', 'Action': "Run the 'display current-configuration | include snmp-agent' command to verify the SNMP settings. If the settings are incorrect, modify them accordingly."}

Step 2: {'Step': '2. Verify the system firmware and software versions.', 'Action': "Run the 'display version' command to check the system firmware and software versions. Ensure that they are up-to-date."}

Step 3: {'Step': '3. Check for hardware issues.', 'Action': "Run the 'display system dcd' command to verify the system's health. If the system is not healthy, perform a hardware reset."}

Step 4: {'Step': '4. Check for software issues.', 'Action': "Run the 'display device internal-info' command to collect logs and system information. If the issue persists, contact Huawei support for further assistance."}

Post-Check Verification

```
display current-configuration | include snmp-agent
display version
```

```
display system dcd
```