

Huawei Provider Edge Router Alarm Handling SOP - ALARM_7613

Node: Huawei-PE-Delhi-NCR-11 | **Vendor:** Huawei | **Severity:** Warning | **Alarm Code:** ALARM_7613

Description

This SOP outlines the steps to diagnose and resolve the ALARM_7613 (Warning) on the Huawei Provider Edge Router (Role: PE) - Node ID: Huawei-PE-Delhi-NCR-11.

Potential Root Causes

Cause	Probability
Incorrect IP address configuration on the PE router interface	High
MTU mismatch between PE and CE devices	Medium
PE router interface is down due to hardware failure	Low

Diagnostic Commands

```
display interface description Huawei-PE-Delhi-NCR-11
display ip interface brief Huawei-PE-Delhi-NCR-11
display mpls interface Huawei-PE-Delhi-NCR-11
display bgp summary Huawei-PE-Delhi-NCR-11
```

Resolution Steps

- Step 1: {'Step': 'Check the interface description for any issues', 'Action': "Run the command 'display interface description Huawei-PE-Delhi-NCR-11' to verify the interface description", 'CLI_Command': 'display interface description Huawei-PE-Delhi-NCR-11'}
- Step 2: {'Step': 'Verify the IP address configuration', 'Action': "Run the command 'display ip interface brief Huawei-PE-Delhi-NCR-11' to verify the IP address configuration", 'CLI_Command': 'display ip interface brief Huawei-PE-Delhi-NCR-11'}
- Step 3: {'Step': 'Check for MTU mismatch', 'Action': "Run the command 'display mpls interface Huawei-PE-Delhi-NCR-11' to verify the MTU settings", 'CLI_Command': 'display mpls interface Huawei-PE-Delhi-NCR-11'}
- Step 4: {'Step': 'Check for interface down due to hardware failure', 'Action': "Run the command 'display interface Huawei-PE-Delhi-NCR-11' to verify the interface status", 'CLI_Command': 'display interface Huawei-PE-Delhi-NCR-11'}
- Step 5: {'Step': 'Reset the interface if necessary', 'Action': "Run the command 'reset interface Huawei-PE-Delhi-NCR-11' to reset the interface", 'CLI_Command': 'reset interface Huawei-PE-Delhi-NCR-11'}

Huawei-PE-Delhi-NCR-11'}

Post-Check Verification

```
display interface Huawei-PE-Delhi-NCR-11
display ip interface brief Huawei-PE-Delhi-NCR-11
display mpls interface Huawei-PE-Delhi-NCR-11
```