

Juniper Core Router Alarm SOP - ALARM_5765

Node: Juniper-Core-Mumbai-MH-1 | **Vendor:** Juniper | **Severity:** Major | **Alarm Code:** ALARM_5765

Description

This SOP outlines the procedures to diagnose and resolve the ALARM_5765 on the Juniper Core Router Node ID: Juniper-Core-Mumbai-MH-1. The alarm indicates a **Major** issue.

Potential Root Causes

Cause	Probability
Misconfigured Routing Protocol	High
Interface Failure	Medium
Software Bug	Low

Diagnostic Commands

```
show chassis hardware
show chassis environment temperature
show chassis environment fan-status
show routing-information base
show routing-instance detail
```

Resolution Steps

Step 1: {'Step': '1. Check Routing Protocol Configuration', 'Action': "Run 'show routing-information base' to verify routing protocol configuration."}

Step 2: {'Step': '2. Verify Interface Status', 'Action': "Run 'show interfaces detail' to verify interface status."}

Step 3: {'Step': '3. Check for Software Bug', 'Action': "Run 'show system software' to verify software version and check for any known bugs."}

Step 4: {'Step': '4. Restart Routing Process', 'Action': "Run 'request system reboot' to restart the routing process."}

Step 5: {'Step': '5. Verify Alarm Clearance', 'Action': "Run 'show chassis alarms' to verify that the alarm is cleared."}

Post-Check Verification

```
show chassis alarms
```

```
show routing-instance detail
```

```
show interfaces detail
```

```
show system software
```