

Juniper-PE-Delhi-NCR-28: ALARM_2081 Warning Alarm Resolution SOP

Node: Juniper-PE-Delhi-NCR-28 | **Vendor:** Juniper | **Severity:** Warning | **Alarm Code:** ALARM_2081

Description

This Standard Operating Procedure (SOP) outlines the steps to resolve the ALARM_2081 warning alarm on the Juniper-PE-Delhi-NCR-28 Provider Edge Router.

Potential Root Causes

Cause	Probability
High CPU Utilization due to CPU-intensive processes	High
Misconfigured BGP Peerings	Medium
Interface Flapping or Errors	Low

Diagnostic Commands

```
show system processes cpu
show bgp summary
show interfaces | include Flapping
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': 'Run command: show system processes cpu'}
- Step 2: {'Step': '2. Verify BGP Peerings', 'Action': 'Run command: show bgp summary'}
- Step 3: {'Step': '3. Check for Interface Flapping', 'Action': 'Run command: show interfaces | include Flapping'}
- Step 4: {'Step': '4. Resolve CPU-intensive issues', 'Action': 'Check and kill processes consuming high CPU resources'}
- Step 5: {'Step': '5. Reconfigure BGP Peerings (if necessary)', 'Action': 'Run command: set bgp group type internal'}
- Step 6: {'Step': '6. Resolve Interface Flapping (if necessary)', 'Action': 'Run command: set interfaces disable'}

Post-Check Verification

```
show system processes cpu
show bgp summary
```

```
show interfaces | include Flapping
```