

Juniper-PE-Delhi-NCR-28 ALARM_3975 Critical Alarm SOP

Node: Juniper-PE-Delhi-NCR-28 | **Vendor:** Juniper | **Severity:** Critical | **Alarm Code:** ALARM_3975

Description

This SOP outlines the steps to diagnose and resolve the ALARM_3975 Critical alarm on the Juniper-PE-Delhi-NCR-28 Provider Edge Router.

Potential Root Causes

Cause	Probability
High CPU utilization due to excessive routing updates	High
Misconfigured BGP neighbor	Medium
Hardware failure in the Juniper-PE-Delhi-NCR-28 device	Low

Diagnostic Commands

```
show system resources cpu | match %util
show bgp summary
show bgp neighbors
show log messages | match ALARM_3975
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU utilization', 'Action': "Run the command 'show system resources cpu | match %util' to check the CPU utilization. If it's above 80%, proceed to the next step."}
- Step 2: {'Step': '2. Verify BGP neighbor configuration', 'Action': "Run the command 'show bgp neighbors' to verify the BGP neighbor configuration. If the configuration is incorrect, update it and restart the BGP process."}
- Step 3: {'Step': '3. Check for hardware failure', 'Action': "Run the command 'show log messages | match ALARM_3975' to check for any hardware failure related logs. If a hardware failure is detected, contact the hardware support team to replace the faulty device."}
- Step 4: {'Step': '4. Restart the BGP process', 'Action': "Run the command 'request system software restart bgp' to restart the BGP process."}

Post-Check Verification

```
show bgp summary
show bgp neighbors
```

```
show log messages | match ALARM_3975
```