

Juniper PE Router SOP for Alarm ALARM_6933

Node: Juniper-PE-Delhi-NCR-28 | **Vendor:** Juniper | **Severity:** Major | **Alarm Code:** ALARM_6933

Description

Alarm ALARM_6933 is triggered on Juniper PE Router Juniper-PE-Delhi-NCR-28 when a Major issue occurs. This SOP outlines the necessary diagnostic, resolution, and verification steps to address the issue.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Memory Leak	Medium
Routing Protocol Issues	Low

Diagnostic Commands

```
show system resource
show route summary
show routing-instance detail
show log messages | match ALARM_6933
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Execute 'show system resource' command to monitor CPU utilization. If CPU utilization is high, proceed to step 2."}
- Step 2: {'Step': '2. Check for Memory Leak', 'Action': "Execute 'show system resource' command to monitor memory utilization. If memory leak is detected, proceed to step 3."}
- Step 3: {'Step': '3. Verify Routing Protocol Configuration', 'Action': "Verify routing protocol configuration using 'show routing-instance detail' command. If routing protocol issues are detected, correct the configuration."}
- Step 4: {'Step': '4. Clear Log Files', 'Action': "Execute 'clear log files' command to clear log files and restart the router."}

Post-Check Verification

```
show system resource
show route summary
show routing-instance detail
```

```
show log messages | match ALARM_6933
```