

Nokia Core Router - Alarm Resolution SOP

Node: Nokia-Core-Bangalore-KA-2 | **Vendor:** Nokia | **Severity:** Major | **Alarm Code:** ALARM_3481

Description

Alarm ALARM_3481 - Major - Nokia-Core-Bangalore-KA-2 Core Router

Potential Root Causes

Cause	Probability
Interface Flapping	High
Route Flapping	Medium
Neighbor Session Down	Low

Diagnostic Commands

```
show ip bgp summary
show ip bgp neighbors
show mpls ldp neighbors
show interface status
```

Resolution Steps

- Step 1: {'Step': 'Verify Interface Status', 'Action': "run 'show interface status' command", 'Description': 'Verify if interface is down or flapping'}
- Step 2: {'Step': 'Check BGP Session', 'Action': "run 'show ip bgp summary' and 'show ip bgp neighbors' commands", 'Description': 'Verify if BGP session is established with neighbors'}
- Step 3: {'Step': 'Check LDP Session', 'Action': "run 'show mpls ldp neighbors' command", 'Description': 'Verify if LDP session is established with neighbors'}
- Step 4: {'Step': 'Reset Interface', 'Action': "run 'interface shutdown' and 'interface no shutdown' commands", 'Description': 'Reset interface to bring it up'}
- Step 5: {'Step': 'Clear BGP Session', 'Action': "run 'clear ip bgp *' command", 'Description': 'Clear BGP session with neighbors'}
- Step 6: {'Step': 'Clear LDP Session', 'Action': "run 'clear mpls ldp neighbors' command", 'Description': 'Clear LDP session with neighbors'}

Post-Check Verification

```
show ip bgp summary
```

```
show ip bgp neighbors
show mpls ldp neighbors
show interface status
```