

# Nokia Core Router Alarm SOP (ALARM\_3839)

**Node:** Nokia-Core-Bangalore-KA-2 | **Vendor:** Nokia | **Severity:** Warning | **Alarm Code:** ALARM\_3839

## Description

This Standard Operating Procedure outlines the steps to be taken in the event of a warning alarm on the Nokia Core Router, Node ID: Nokia-Core-Bangalore-KA-2, alarm code: ALARM\_3839.

## Potential Root Causes

| Cause                                   | Probability |
|-----------------------------------------|-------------|
| Misconfigured routing protocol settings | Medium      |
| Hardware failure in the core router     | High        |
| Software glitch or bug                  | Low         |

## Diagnostic Commands

```
show routing protocol status
show interface statistics
show system resources
```

## Resolution Steps

- Step 1: {'Step': 'Step 1: Check routing protocol settings', 'Action': 'Verify and correct the routing protocol settings using the command: `configure routing protocol`'}
- Step 2: {'Step': 'Step 2: Check hardware status', 'Action': 'Run the command: `show hardware status` to check for any hardware issues'}
- Step 3: {'Step': 'Step 3: Reset the core router', 'Action': 'Use the command: `reset system` to reset the core router'}

## Post-Check Verification

```
show routing protocol status
show interface statistics
show system resources
```