

Nokia Core Router - ALARM_3842: Warning Severity Alarm Procedure

Node: Nokia-Core-Delhi-NCR-1 | **Vendor:** Nokia | **Severity:** Warning | **Alarm Code:** ALARM_3842

Description

This SOP outlines the steps to diagnose and resolve the ALARM_3842 warning severity alarm on the Nokia Core Router at Node ID: Nokia-Core-Delhi-NCR-1.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Memory Leak	Medium
Software Bug	Low

Diagnostic Commands

```
show cpu utilization
show memory stats
show alarm history ALARM_3842
debug enable
debug ip routing
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Run the command 'show cpu utilization' to identify high CPU utilization."}
- Step 2: {'Step': '2. Check Memory Stats', 'Action': "Run the command 'show memory stats' to identify memory leaks."}
- Step 3: {'Step': '3. Clear Alarm History', 'Action': "Run the command 'clear alarm history ALARM_3842' to clear the alarm history."}
- Step 4: {'Step': '4. Disable Debugging', 'Action': "Run the command 'debug disable' to disable debugging."}
- Step 5: {'Step': '5. Upgrade Software (if necessary)', 'Action': 'Upgrade the software to the latest version to resolve software bugs.'}

Post-Check Verification

```
show cpu utilization
show memory stats
show alarm history ALARM_3842
show version
```