

Nokia Core Router - Alarm ALARM_3646 SOP

Node: Nokia-Core-Delhi-NCR-2 | **Vendor:** Nokia | **Severity:** Critical | **Alarm Code:** ALARM_3646

Description

This SOP details the step-by-step procedures to diagnose and resolve the critical alarm ALARM_3646 on Nokia Core Router at Node ID: Nokia-Core-Delhi-NCR-2.

Potential Root Causes

Cause	Probability
Route Leaking due to BGP Session flap	High
Misconfigured BGP Neighbor	Medium
Hardware Failure in Route Processor	Low

Diagnostic Commands

```
show bgp summary
show bgp neighbors
show ip bgp | include 3646
show route | include 3646
show cpu utilization
```

Resolution Steps

- Step 1: {'Step': 'Verify BGP Session Status', 'Action': "Run 'show bgp summary' command"}
- Step 2: {'Step': 'Verify BGP Neighbor Configuration', 'Action': "Run 'show bgp neighbors' command"}
- Step 3: {'Step': 'Reset BGP Session', 'Action': "Run 'clear bgp *'"}
- Step 4: {'Step': 'Verify Route Leaking', 'Action': "Run 'show route | include 3646'"}
- Step 5: {'Step': 'Check for Hardware Issues', 'Action': "Run 'show cpu utilization'"}

Post-Check Verification

```
show bgp summary
show bgp neighbors
show ip bgp | include 3646
show route | include 3646
show cpu utilization
```