

Nokia-Core-Delhi-NCR-2 ALARM_6670 Critical Alarm SOP

Node: Nokia-Core-Delhi-NCR-2 | **Vendor:** Nokia | **Severity:** Critical | **Alarm Code:** ALARM_6670

Description

This SOP outlines the procedures to diagnose and resolve the ALARM_6670 Critical alarm on Nokia-Core-Delhi-NCR-2, a Nokia Core Router.

Potential Root Causes

Cause	Probability
High CPU Utilization on Route Processor	High
Memory Leak on Route Processor	Medium
Hardware Fault on Route Processor	Low

Diagnostic Commands

```
show system resource cpu
show system resource memory
show system resource interface
show tech-support
```

Resolution Steps

- Step 1: {'Step': 'Restart the Route Processor', 'Action': 'admin:~# reload', 'Note': 'This may resolve the issue, but further investigation is required.'}
- Step 2: {'Step': 'Clear Memory Leaks', 'Action': '[admin:~# show system resource memory | grep -i leak] & [admin:~# clear system resource memory]', 'Note': 'This may resolve the issue, but further investigation is required.'}
- Step 3: {'Step': 'Check and Replace Faulty Hardware (if necessary)', 'Action': '[admin:~# show system resource interface | grep -i faulty] & [admin:~# replace system resource interface faulty]', 'Note': 'This may resolve the issue, but further investigation is required.'}

Post-Check Verification

```
show system resource cpu
show system resource memory
show system resource interface
```

show tech-support