

# Standard Operating Procedure: Resolving ALARM\_3358 on Nokia-Core-Kolkata-WB-2

**Node:** Nokia-Core-Kolkata-WB-2 | **Vendor:** Nokia | **Severity:** Major | **Alarm Code:** ALARM\_3358

## Description

ALARM\_3358 is a Major alarm indicating a critical issue on the Nokia-Core-Kolkata-WB-2 Core Router. This SOP outlines the steps to diagnose and resolve the issue.

## Potential Root Causes

| Cause                                   | Probability |
|-----------------------------------------|-------------|
| High CPU Utilization on Route Processor | High        |
| Memory Leak on the Route Processor      | Medium      |
| Software Bug in the Routing Protocol    | Low         |

## Diagnostic Commands

```
show process cpu | include route-processor
show memory | include route-processor
show route-protocol statistics
show debug route-protocol
```

## Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Run the command 'show process cpu | include route-processor' to monitor CPU utilization on the Route Processor.", 'CLI\_Command': 'show process cpu | include route-processor'}
- Step 2: {'Step': '2. Check Memory Utilization', 'Action': "Run the command 'show memory | include route-processor' to monitor memory utilization on the Route Processor.", 'CLI\_Command': 'show memory | include route-processor'}
- Step 3: {'Step': '3. Check Routing Protocol Statistics', 'Action': "Run the command 'show route-protocol statistics' to monitor routing protocol statistics.", 'CLI\_Command': 'show route-protocol statistics'}
- Step 4: {'Step': '4. Enable Debugging on the Routing Protocol', 'Action': "Run the command 'show debug route-protocol' to enable debugging on the routing protocol.", 'CLI\_Command': 'show debug route-protocol'}
- Step 5: {'Step': '5. Reset the Route Processor', 'Action': "Run the command 'reset route-processor' to reset the Route Processor.", 'CLI\_Command': 'reset route-processor'}

## Post-Check Verification

```
show process cpu | include route-processor
show memory | include route-processor
show route-protocol statistics
```