

Nokia Core Router Alarm SOP: ALARM_6017

Node: Nokia-Core-Kolkata-WB-2 | **Vendor:** Nokia | **Severity:** Critical | **Alarm Code:** ALARM_6017

Description

Alarm Code ALARM_6017 on Nokia Core Router Node ID Nokia-Core-Kolkata-WB-2 indicates a critical issue. This SOP outlines the steps to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
Hardware Failure	High
Software Bug	Medium
Configuration Error	Low

Diagnostic Commands

```
show alarm history
show system information
show route
show ip bgp summary
```

Resolution Steps

- Step 1: {'Step': '1. Power cycle the node', 'Command': 'admin:admin restart'}
- Step 2: {'Step': '2. Check the hardware logs for any errors', 'Command': 'show system logs'}
- Step 3: {'Step': '3. Verify the software version and check for any updates', 'Command': 'show version'}
- Step 4: {'Step': '4. Check the configuration for any errors or inconsistencies', 'Command': 'show running-config'}
- Step 5: {'Step': '5. Reset the BGP session', 'Command': 'clear ip bgp *'}

Post-Check Verification

```
show route
show ip bgp summary
show alarm history
```