

Nokia Core Router Alarm SOP - ALARM_7418

Node: Nokia-Core-Kolkata-WB-2 | **Vendor:** Nokia | **Severity:** Minor | **Alarm Code:** ALARM_7418

Description

This SOP outlines the procedures to diagnose and resolve the ALARM_7418 on Nokia Core Router Node ID: Nokia-Core-Kolkata-WB-2. The alarm is reported as 'Minor' in severity.

Potential Root Causes

Cause	Probability
Interface mismatch or incorrect configuration	High
Hardware failure or faulty interface card	Medium
Software bug or incorrect firmware version	Low

Diagnostic Commands

```
show interfaces | include ALARM_7418
show system resources | include CPU/Memory usage
show routing-tables | include prefix/path
show alarm-list | include ALARM_7418
show log | include ALARM_7418
```

Resolution Steps

- Step 1: {'Step': 'Verify interface configuration and status', 'Actions': [{'Action': "Run 'show interfaces' command to verify interface status", 'CLI_Command': 'show interfaces'}, {'Action': 'Verify interface configuration against the alarm log', 'CLI_Command': 'show log | include ALARM_7418'}]}
- Step 2: {'Step': 'Check for hardware failures or faulty interface cards', 'Actions': [{'Action': "Run 'show system resources' command to check CPU/Memory usage", 'CLI_Command': 'show system resources | include CPU/Memory usage'}, {'Action': 'Verify interface card status and replace if faulty', 'CLI_Command': 'show hw-module'}]}
- Step 3: {'Step': 'Update firmware or software', 'Actions': [{'Action': 'Verify current firmware/software version', 'CLI_Command': 'show version'}, {'Action': 'Update firmware/software to latest version', 'CLI_Command': 'install firmware/software'}]}

Post-Check Verification

```
show interfaces | include ALARM_7418
show system resources | include CPU/Memory usage
```

```
show routing-tables | include prefix/path  
show alarm-list | include ALARM_7418  
show log | include ALARM_7418
```