

Nokia Provider Edge Router (PE) SOP for Alarm Code ALARM_5627

Node: Nokia-PE-Chennai-TN-100 | **Vendor:** Nokia | **Severity:** Minor | **Alarm Code:** ALARM_5627

Description

This SOP outlines the steps to diagnose and resolve the ALARM_5627 issue on the Nokia Provider Edge Router (PE) at Chennai, Tamil Nadu, India.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Routing Table Overflow	Medium
Software or Hardware Fault	Low

Diagnostic Commands

```
show system uptime
show system resource cpu
show ip route
show ip bgp summary
```

Resolution Steps

Step 1: {'Step': 'Check CPU Utilization', 'Action': "Run 'show system resource cpu' command to check CPU utilization. If utilization is high, restart the router."}

Step 2: {'Step': 'Check Routing Table', 'Action': "Run 'show ip route' command to check the routing table. If the table is overflowing, clear the BGP session and restart the router."}

Step 3: {'Step': 'Check for Software or Hardware Fault', 'Action': "Run 'show system uptime' command to check for any software or hardware issues. If issues are found, contact Nokia support for further assistance."}

Step 4: {'Step': 'Clear BGP Session', 'Action': "Run 'clear bgp *' command to clear the BGP session."}

Step 5: {'Step': 'Restart Router', 'Action': "Run 'reload' command to restart the router."}

Post-Check Verification

```
show system uptime
show system resource cpu
```

```
show ip route  
show ip bgp summary
```