HIGHPLAN 2009

Computational Methodology Documentation

Revised 12/18/2009

Table of Contents

Two Lane Methodology	
Inputs	
Calculations for Percent Time Spent Following	
Calculations for Average Travel Speed	
Service Volumes Check	11
Passing Lane Improvement	11
Multilane Methodology	
Inputs	12
LOS Computational Steps	
Service Volumes Check	13





Two-Lane Methodology

Inputs

Project Properties

Roadway Information:

AreaType := 2 1 = Urbanized, 2 = Transitioning/Urban, 3 = Rural developed, 4 = Rural undeveloped

Highway Data

Roadway Variables:

Terrain := 2 Level = 1, Rolling = 2 Median := 0 0 = No, 1 = Yes

PostedSpeed := 50 mi/hr PresencePassingLane := 0 0 = No, 1 = Yes

SegLength := 4 mi Spacing := 0 mi

%NPZ := 60

Traffic Variables:

 $AADT := 14410 P_T := 4\% Percent trucks$

Revised: 12/18/2009

K := 0.096 BaseCapacity := 1700

D := 0.60 LocalAdjustmentFactor := 1.0

PHF := 0.91

LOS Computational Steps

1. Calculate DDHV (Design Directional Hour Volume)

$$DDHV := AADT \cdot K \cdot D$$

$$DDHV = 830$$

2. Determine adjustment for the presence of a median and/or left turn lanes

Left Turn Impact Adjustment (LTadj) = -0.2 for left turn lanes NOT present, LTadj = 0 otherwise.

Median Adjustment (MedAdj) = 0.05 for median present, MedAdj = 0 otherwise.

Left Turn Lane:

$$LTadj(LeftTurnImpact) := \begin{cases} out \leftarrow -0.2 & if LeftTurnImpact = 1 \\ out \leftarrow 0 & if LeftTurnImpact = 0 \\ out \end{cases}$$

$$LTadi(LeftTurnImpact) = 0$$

$$LTadj = 0$$

Median:

MedAdj(Median) :=
$$\begin{cases} \text{out} \leftarrow 0 & \text{if Median} = 0 \\ \text{out} \leftarrow 0.05 & \text{if Median} = 1 \end{cases}$$

$$MedAdi(Median) = 0$$

$$MedAdj = 0$$

Final Adjustment Value for Left Turn Lane and Median:

$$AdjMedLTL := 1 + LTadj + MedAdj$$

$$AdjMedLTL = 1$$

3. Determine Facility Adjustment Factor (FacAdj)

$$FacAdj := 1$$

4. Calculate Adjusted Volume (AdjVol)

$$AdjVol := \frac{DDHV}{PHF \cdot LAF \cdot AdjMedLTL \cdot FacAdj}$$

$$AdjVol = 912$$

$$V := AdjVol$$

$$V = 912.1$$

Calculations for Percent Time Spent Following (PTSF)

5. Determine E_T (Truck passenger car equivalency factor)

$$\begin{split} \text{PCEs}(\text{Terrain}, V) \coloneqq & \text{ if } \text{ Terrain} = 1 \\ & E_T \leftarrow 1.1 \text{ if } 0 \leq V \leq 300 \\ & E_T \leftarrow 1.0 \text{ if } V > 600 \\ & E_R \leftarrow 1.0 \\ & \text{ out } \leftarrow \begin{pmatrix} E_T \\ E_R \end{pmatrix} \\ & \text{ out } & \text{ HCM 2000} \\ & E_T \leftarrow 1.8 \text{ if } 0 \leq V \leq 300 \\ & E_T \leftarrow 1.5 \text{ if } 300 < V \leq 600 \\ & E_T \leftarrow 1.0 \text{ if } V > 600 \\ & E_T \leftarrow 1.0 \text{ out } \leftarrow \begin{pmatrix} E_T \\ E_R \end{pmatrix} \\ & \text{ out } & \text{ out } \leftarrow \begin{pmatrix} E_T \\ E_R \end{pmatrix} \\ & \text{ out } & \text{ out } \end{pmatrix} \end{split}$$

$$\begin{aligned} \text{PCEs}(\text{Terrain}, \text{V}) = \begin{pmatrix} 1.0 \\ 1.0 \end{pmatrix} & & \text{E}_{T} \coloneqq \text{PCEs}(\text{Terrain}, \text{V})_{1} & & \text{E}_{T} = 1.0 \\ & & \text{E}_{R} \coloneqq \text{PCEs}(\text{Terrain}, \text{V})_{2} & & \text{E}_{R} = 1.0 \end{aligned}$$

6. Calculate heavy vehicle factor (f_{HV})

$$f_{HV} := \frac{1}{1 + P_T \cdot (E_T - 1)}$$
 Equation 20-4 HCM 2000

7. Determine grade adjustment factor (f_G)

$$\begin{split} f_G(\text{Terrain}, V) &:= & \begin{array}{c|c} \text{if Terrain} = 1 \\ \hline f_G \leftarrow 1.0 \\ \text{out} \leftarrow f_G \\ \text{out} \\ \\ \text{if Terrain} = 2 \\ \hline f_G \leftarrow 0.77 \text{ if } 0 \leq V \leq 300 \\ \hline f_G \leftarrow 0.94 \text{ if } 300 < V \leq 600 \\ \hline f_G \leftarrow 1.0 \text{ if } V > 600 \\ \\ \text{out} \leftarrow f_G \\ \\ \text{out} \\ \\ \text{out} \\ \\ \end{array} \end{split}$$

$$f_G(Terrain, V) = 1$$

$$f_G(Terrain, V) = 1$$
 $f_G := f_G(Terrain, V)$ $f_G = 1.00$

$$f_G = 1.00$$

8. Calculate forward direction volume (v_d)

$$v_d := \frac{V}{PHF \cdot f_G \cdot f_{HV}}$$

Equation 20-12 **HCM 2000**

Since the PHF was already accounted for in Step 5, the following equation is used:

$$v_d := \frac{AdjVol}{f_G \cdot f_{HV}}$$
 $v_d = 912.1$ pc/hr

Check this value against flow range used for Exhibits 20-10 and 20-8, and repeat steps 6 through 9 as necessary.

9. Calculate opposing direction volume (v_o).

$$v_o \coloneqq \frac{V_o}{\text{PHF} \cdot f_G \cdot f_{HV}} \\ \text{From Equation 20-13} \\ \text{HCM 2000}$$

The "equivalent" is performed by the following equation:

$$v_0 := \frac{v_d \cdot (1 - D)}{D}$$
 $v_0 = 608.1$

 f_G and f_{HV} are not currently accounted for in the determination of v_o as they are in the HCM 2000 methodology. Additionally, the PHF is assumed to be the same in the off-peak direction.

From Exhibit 20-21

HCM 2000 (per NCHRP 20-7

revisions)

10. Determine values of coefficients 'a' and 'b' for HCM Equation 20-17

Look up values from HCM Exhibit 20-21 (linear interpolation if necessary).

Input:

v_o is rounded to the nearest 10 veh/h.

$$v_{o \ rd} := round(v_{o}, -1)$$
 $v_{o \ rd} = 610$ pc/hr

From Exhibit, for
$$v_0$$
 = 600; $a_1 := -0.0033$ $b_1 := 0.870$

From Exhibit, for
$$v_0 = 800$$
; $a_2 := -0.0045$ $b_2 := 0.833$

Interpolation:

$$a := a_1 + (a_2 - a_1) \cdot \left(\frac{v_{o_rd} - 600}{800 - 600} \right)$$
 $a = -0.0034$

$$b := b_1 + (b_2 - b_1) \cdot \left(\frac{v_{o_rd} - 600}{800 - 600} \right)$$

$$b = 0.8681$$

11. Calculate base percent time spent following (BPTSF)

$$BPTSF_d := 100 \cdot \left(1 - e^{a \cdot v_d^b}\right)$$

$$BPTSF_d = 71.3$$
Equation 20-17
HCM 2000

12. Determine adjustment for % no-passing zones in analysis direction (f_{np}) for HCM Equation 20-16

Look up value from HCM Exhibit 20-20 (linear interpolation if necessary, by both volume and %NPZ.

Input: PostedSpeed =
$$50$$
 %NPZ = 60 $v_0 = 608.1$

$$FFS := PostedSpeed + 5$$
 $FFS = 55$ $D = 0.6$

$$\underline{\text{Interpolation:}} \qquad \qquad f_{np1} \coloneqq 25.4 \quad \text{ for Vp = 1400} \quad \text{ and } \qquad \qquad f_{np2} \coloneqq 16.0 \quad \text{ for Vp = 2000}$$

$$v_p := v_d + v_o \qquad v_p = 1520.176$$

$$f_{np} \coloneqq f_{np1} - \left(v_p - 1400\right) \cdot \left(\frac{f_{np1} - f_{np2}}{2000 - 1400}\right) \qquad \qquad f_{np} = 23.517 \qquad \qquad \begin{array}{l} \text{From Exhibit 20-20} \\ \text{HCM 2000 (per NCHRP 20-7 revisions)} \end{array}$$

13. Calculate percent time spent following (PTSF)

$$PTSF_{d} := BPTSF_{d} + f_{np} \cdot \left(\frac{v_{d}}{v_{p}}\right)$$

$$PTSF_{d} = 85.4$$

$$PTSF_d = 85.4$$

Equation 20-16 HCM 2000 (per NCHRP 20-7 revisions)

Calculations for Average Travel Speed (ATS)

14. Determine E_T (Truck passenger car equivalency factor)

From Exhibit 20-9 **HCM 2000**

$$PCEs(Terrain, V) = \begin{pmatrix} 1.5 \\ 1.1 \end{pmatrix} \qquad \begin{aligned} E_T &:= PCEs(Terrain, V)_1 & E_T &= 1.5 \\ E_R &:= PCEs(Terrain, V)_2 & E_R &= 1.1 \end{aligned}$$

15. Calculate heavy vehicle factor (f_{HV})

$$f_{HV} := \frac{1}{1 + P_{T}(E_{T} - 1)}$$
 $f_{HV} = 0.98$

$$f_{HV} = 0.98$$

Revised: 12/18/2009

Equation 20-4 **HCM 2000**

16. Determine grade adjustment factor (f_G)

retermine grade adjustment factor (
$$\mathbf{f_G}$$
)
$$f_G(\operatorname{Terrain}, V) := \begin{vmatrix} \text{if Terrain} = 1 \\ f_G \leftarrow 1.0 \\ \text{out} \leftarrow f_G \\ \text{out} \end{vmatrix}$$

$$f_G \leftarrow 0.71 \quad \text{if } 0 \leq V \leq 300$$

$$f_G \leftarrow 0.93 \quad \text{if } 300 < V \leq 600$$

$$f_G \leftarrow 0.99 \quad \text{if } V > 600$$

$$\text{out} \leftarrow f_G$$

$$\text{out}$$

$$\text{out}$$

$$f_G(Terrain, V) = 0.99$$

$$f_G(Terrain, V) = 0.99$$
 $f_G := f_G(Terrain, V)$ $f_G = 0.99$

$$G = 0.99$$

17. Calculate forward direction volume (v_d)

$$v_d := \frac{V}{PHF \cdot f_G \cdot f_{HV}}$$

Equation 20-12 **HCM 2000**

Since the PHF was already accounted for in Step 5, the following equation is used:

$$v_d := \frac{AdjVol}{f_{G'}f_{HV}}$$
 $v_d = 939.7$ pc/h

Check this value against flow range used for Exhibits 20-10 and 20-8, and repeat steps 6 through 9 as necessary.

18. Calculate opposing direction volume (v_o)

$$v_o \coloneqq \frac{V_o}{\text{PHF} \cdot f_G \cdot f_{HV}} \\ \\ \text{Equation 20-13} \\ \text{HCM 2000} \\ \\$$

The "equivalent" is performed by the following equation:

$$v_0 := \frac{v_d \cdot (1 - D)}{D}$$
 $v_0 = 626.5$ pc/h

 $\rm f_G$ and $\rm f_{HV}$ are not currently accounted for in the determination of $\rm v_o$ as they are in the HCM 2000 methodology. Additionally, the PHF is assumed to be the same in the off-peak direction.

19. Determine adjustment for % no-passing zones in analysis direction (f_{np}) for HCM Equation 20-15

Look up value from HCM Exhibit 20-19 (linear interpolation if necessary, by both volume and percent no-passing zone).

Input:

$$PostedSpeed = 50$$

$$%NPZ = 60$$
 $v_0 = 626.5$

$$v_0 = 626.5$$

$$FFS := PostedSpeed + 5$$

$$FFS = 55$$

Interpolation:

This example only calls for interpolation by volume,

$$f_{np} := 1.6 - (v_0 - 600) \cdot (\frac{1.6 - 1.1}{800 - 600})$$
 $f_{np} = 1.53$

$$f_{np} = 1.53$$

20. Calculate average travel speed (ATS)

Input:

$$FFS_d := FFS$$
 $FFS_d = 55$

$$FFS_d = 55$$

from inputs

Revised: 12/18/2009

$$v_d = 939.7$$

 $v_d = 939.7$ from step 9

$$v = 626.5$$

 $v_0 = 626.5$ from step 10

$$f_{np} = 1.53$$

from step 11

Calculation:

$$ATS_d := FFS_d - 0.00776 \cdot (v_d + v_o) - f_{np}$$

 $ATS_d = 41.3$

mi/h

Equation 20-5 **HCM 2000**

21. Calculate Percentage of Free-Flow Speed (%FFS)

%FFS :=
$$\frac{ATS_d}{FFS_d} \cdot 100$$

%FFS = 75.1

sec/veh

22. Calculate Free-Flow Delay

$$FFDelay := \left(\frac{SegLength}{ATS_d} - \frac{SegLength}{FFS_d}\right) \cdot 3600$$

$$FFDelay = 86.7$$

23. Calculate LOS Threshold Delay

LOSspeedthresh(AreaType) = 50

$$LOSDelay := \left(\frac{SegLength}{ATS_d} - \frac{SegLength}{LOSspeedthresh(AreaType)}\right) \cdot 3600$$

$$LOSDelay = 60.6$$

$$Sec/veh$$

24. Calculate v/c ratio

vcratioTwoWay :=
$$\frac{v_d + v_o}{BaseCapacity \cdot \left(\frac{3200}{1700}\right)}$$
 vcratioTwoWay = 0.49

$$vcratioOneWay := \frac{v_d}{BaseCapacity} \\ vcratioOneWay = 0.55$$

vcratio := max(vcratioTwoWay, vcratioOneWay) vcratio = 0.55

25. Determine Class

Revised: 12/18/2009

Class := ClassCalc(AreaType) Class = 3

26. Determine Level of Service

LosCalc(Class, PTSF, ATS, FFS) := | if Class = 1

If Class = 1, the lower LOS governs

 $\begin{aligned} & \text{out}_1 \leftarrow \text{"A"} & \text{if PTSF} \leq 35 \\ & \text{out}_1 \leftarrow \text{"B"} & \text{if } 35 < \text{PTSF} \leq 50 \\ & \text{out}_1 \leftarrow \text{"C"} & \text{if } 50 < \text{PTSF} \leq 65 \\ & \text{out}_1 \leftarrow \text{"D"} & \text{if } 65 < \text{PTSF} \leq 80 \end{aligned}$ $out_1 \leftarrow "E" \text{ if PTSF} > 80$ From Exhibit 20-2 out₂ ← "A" if ATS > 55 out₂ ← "B" if 50 < ATS ≤ 55 out₂ ← "C" if 45 < ATS ≤ 50 out₂ ← "D" if 40 < ATS ≤ 45 out₂ ← "E" if ATS ≤ 40 **HCM 2000** if Class = 2out \leftarrow "A" if PTSF ≤ 40 out \leftarrow "B" if $40 < PTSF \le 55$ From Exhibit 20-4 **HCM 2000** out \leftarrow "C" if $55 < PTSF \le 70$ out \leftarrow "D" if $70 < PTSF \le 85$ out \leftarrow "E" if PTSF > 80

Service Volumes Check

From Exhibit 15-2 HCM 2000, for a Class II Arterial, the percent free flow speed (%FFS) threshold for LOS C is 0.75.

Using the procedure documented above, the following results are obtained for the displayed 830 veh/h peak direction service volume.

$$\begin{aligned} & \text{InputAADT} \coloneqq \text{Round}\bigg(\frac{830}{\text{K}\cdot\text{D}}, 10\bigg) = 14410 \\ & \text{ATS}_{d} = 41.312 \end{aligned} \qquad \text{miles/hour}$$

$$& \text{FFS}_{d} = 55$$

$$& \text{miles/hour}$$

$$\frac{ATS_d}{FFS_d} = 0.751$$

Thus, the maximum service volume (AADT) for LOS C for the conditions in the example calculations file is \sim 14.410.

Passing Lane Improvement

If there is a passing lane in the analysis direction, the service volumes will be increased by the proportion of the length of the passing lane (assumed to be 1 mile) to the passing lane spacing, as illustrated below.

NoPassingSV := 830 veh/h

Spacing := 2 miles

Improvement := $\frac{1}{\text{Spacing}} = 0.5$

PassingSV := NoPassingSV·(1 + Improvement)

 $Passing SV := Passing SV - mod (Passing SV, 10) \\ \qquad {}^{\star} \ \text{HIGHPLAN rounds down to multiples of 10} \\$

 $\frac{\text{PassingSV} = 1240}{\text{Veh/h}}$

Note that the improvement to the service volumes cannot exceed capacity. In other words, the service volume for any level of service is capped at the LOS E service volume for the no-passing lane condition.

Multilane Methodology

Inputs

Project Properties

Roadway Information:

AreaType := 2 1 = Urbanized, 2 = Transitioning/Urban, 3 = Rural Developed, 4 = Rural Undeveloped

Highway Data

Roadway Variables:

Number of Lanes := 4 Left Turn Impact := 1 0 = No, 1 = Yes

Terrain := 2 Level = 1, Rolling = 2 Median := 0 0 = No, 1 = Yes

PostedSpeed := 45 mi/hr

SegLength := 5 mi

Traffic Variables:

 $AADT := 33490 P_T := 2\% Percent trucks$

Revised: 12/18/2009

K := 0.095 BaseCapacity := 2000

D := 0.55 Local Adjustment Factor := 1.0

PHF := 0.925

LOS Computational Steps

1. Calculate DDHV (Design Directional Hour Volume)

$$DDHV := AADT \cdot K \cdot D$$

$$DDHV = 1750$$

2. Determine E_T (Truck passenger car equivalency factor)

PCE(Terrain) :=
$$\begin{vmatrix} out \leftarrow 1.5 & if Terrain = 1 \\ out \leftarrow 2.5 & if Terrain = 2 \\ out \end{vmatrix}$$

From Exhibit 21-8 **HCM 2000**

$$PCE(Terrain) = 2.5$$

$$E_T := PCE(Terrain)$$
 $E_T = 2.5$

$$E_{T} = 2.5$$

3. Calculate heavy vehicle factor (f_{HV})

$$f_{HV} := \frac{1}{1 + P_{T} \cdot (E_{T} - 1)}$$
 $f_{HV} = 0.971$

$$f_{HV} = 0.971$$

Equation 21-4 **HCM 2000**

4. Calculate Base Analysis Volume (v_n)

LAF := LocalAdjustmentFactor

$$v_p := \frac{DDHV}{PHF \cdot \frac{Number of Lanes}{2} \cdot f_{HV} \cdot LAF}$$

$$v_p = 974.2 \quad \text{veh/h}$$

$$v_p = 974.2$$
 veh/h

Equation 21-3 HCM 2000

5. Determine adjustment for the presence of a median and/or left turn lanes

Left Turn Lane Adjustment (LTadj) = -0.2 for left turn lanes NOT present, LTadj = 0 otherwise. Median Adjustment (MedAdj) = -0.05 for no median present, MedAdj = 0 otherwise. Note: The presence of a median, but no left turn lanes is not a valid option per FDOT guidance.

LTI := LeftTurnImpact

$$LTadj(LTI) := \begin{cases} out \leftarrow -0.2 & \text{if } LTI = 1 \\ out \leftarrow 0 & \text{if } LTI = 0 \\ out \end{cases}$$
 MedAdj(Median

$$\begin{tabular}{lll} MedAdj(Median) := & out \leftarrow -0.05 & if Median = 0 \\ out \leftarrow 0 & if Median = 1 \\ out \\ \end{tabular}$$

$$LTadj(LeftTurnImpact) = -0.2$$

$$MedAdj(Median) = -0.05$$

$$LTadj = -0.2$$

$$MedAdj = -0.05$$

Revised: 12/18/2009

Final Adjustment Value for Left Turn Lane and Median:

$$AdjMedLTL := (1 + LTadj + MedAdj)$$

$$AdjMedLTL = 0.75$$

6. Determine Facility Adjustment Factor (FacAdj)

$$FacAdj := 1$$

7. Calculate Adjusted Analysis Volume (AdjVol)

$$AdjVol := \frac{v_p}{AdjMedLTL \cdot FacAdj}$$

$$AdjVol = 1299$$

$$V := AdjVol$$
 $V = 1299$

$$V = 1299$$

veh/h

8. Determine Average Passenger Car Speed

$$FFS := PostedSpeed + 5$$

$$FFS = 50$$

Exhibit 21-3 **HCM 2000**

$$\begin{aligned} \text{Speed(FFS,AdjVol)} &:= & | \text{out} \leftarrow \text{FFS} \text{ if AdjVol} \leq 1400 \\ \text{if AdjVol} > 1400 \\ \\ \text{out} \leftarrow \text{FFS} - \left(\frac{3}{10} \cdot \text{FFS} - 13\right) \cdot \left(\frac{\text{AdjVol} - 1400}{28 \cdot \text{FFS} - 880}\right)^{1.31} \text{ if FFS} > 55 \\ \text{out} \leftarrow \text{FFS} - \left(\frac{34}{205} \cdot \text{FFS} - \frac{219}{41}\right) \cdot \left(\frac{\text{AdjVol} - 1400}{\frac{171}{5} \cdot \text{FFS} - 1181}\right)^{1.31} \text{ if } 50 < \text{FFS} \leq 55 \\ \text{out} \leftarrow \text{FFS} - \left(\frac{10}{43} \cdot \text{FFS} - \frac{350}{43}\right) \cdot \left(\frac{\text{AdjVol} - 1400}{33 \cdot \text{FFS} - 1050}\right)^{1.31} \text{ if } 45 < \text{FFS} \leq 50 \\ \text{out} \leftarrow \text{FFS} - \left(\frac{1}{5} \cdot \text{FFS} - \frac{56}{9}\right) \cdot \left(\frac{\text{AdjVol} - 1400}{36 \cdot \text{FFS} - 1120}\right)^{1.31} \text{ if } \text{FFS} = 45 \end{aligned}$$

$$Speed(FFS, AdjVol) = 50.0$$

$$S := Speed(FFS, AdjVol)$$
 $S = 50.000$

Revised: 12/18/2009

$$S = 50.000$$

mi/h

9. Calculate Percentage of Free-Flow Speed (%FFS)

%FFS :=
$$\frac{S}{FFS} \cdot 100$$

%FFS = 100

10. Calculate Free-Flow Delay

$$FFDelay := \left(\frac{SegLength}{S} - \frac{SegLength}{FFS}\right) \cdot 3600$$

FFDelay = 0.0

sec/veh

11. Calculate LOS Threshold Delay

Revised: 12/18/2009

LOSspeedthresh(AreaType) = 60

$$LOSDelay := \left(\frac{SegLength}{S} - \frac{SegLength}{LOSspeedthresh(AreaType)}\right) \cdot 3600$$

LOSDelay = 60.0 sec/veh

12. Calculate v/c ratio

$$vcratio := \frac{V}{BaseCapacity}$$

vcratio = 0.65

13. Calculate density

$$Density := \frac{AdjVol}{S} \hspace{1cm} \begin{array}{c} \text{Equation 21-5} \\ \text{HCM 2000} \end{array}$$

Density = 26.0

pc/mi/ln

Determine Level of Service

```
LOSCalc(FFS, Density) := if FFS \ge 60
                                     out \leftarrow "A" if Density \leq 11
                                      out \leftarrow "B" if 11 < Density \le 18
                                      out \leftarrow "C" if 18 < Density \le 26
                                      out \leftarrow "D" if 26 < Density \leq 35
                                     out \leftarrow "E" if 35 < Density \leq 40
                                     out \leftarrow "F" if Density > 40
                                                                                               From Exhibit 21-2
                                  if 55 \le FFS < 60
                                                                                               HCM 2000
                                      out \leftarrow "A" if Density \leq 11
                                      out \leftarrow "B" if 11 < Density \le 18
                                      out \leftarrow "C" if 18 < Density \le 26
                                      out \leftarrow "D" if 26 < Density \leq 35
                                      out \leftarrow "E" if 35 < Density \leq 41
                                     out \leftarrow "F" if Density > 41
                                  if 50 \le FFS < 55
                                      out \leftarrow "A" if Density \leq 11
                                      out \leftarrow "B" if 11 < Density \le 18
                                      out \leftarrow "C" if 18 < Density \le 26
                                      out \leftarrow "D" if 26 < Density \leq 35
                                     out \leftarrow "E" if 35 < Density \leq 43
                                     out \leftarrow "F" if Density > 43
                                  if 45 \le FFS < 50
                                      out \leftarrow "A" if Density \leq 11
                                      out \leftarrow "B" if 11 < Density \le 18
                                      out \leftarrow "C" if 18 < Density \le 26
                                     out \leftarrow "D" if 26 < Density \leq 35
                                      out \leftarrow "E" if 35 < Density \leq 45
                                       out \leftarrow "F" if Density > 45
```

Revised: 12/18/2009

 $LOS \coloneqq LOSCalc(FFS, Density)$

LOS = "C"

Service Volumes Check

From Exhibit 15-2 HCM 2000, for a Class II Arterial, the density threshold for LOS C is 26 pc/mi/ln

Using the procedure documented above, the following results are obtained for the displayed 1750 veh/h peak direction service volume.

InputAADT := Round
$$\left(\frac{1750}{\text{K}\cdot\text{D}}, 10\right)$$
 = 33490

AdjVol = 1299 veh/hour

S = 50 miles/hour

Density = 25.98 pc/mi/ln

Thus, the maximum service volume (AADT) for LOS C for the conditions in the example calculations file is \sim 33,490.