

# **Vector Legacy Converter**

**Technical Reference** 

Technical Documentation Version 1.4.2

| Authors | Thorsten Fröhlinghaus |
|---------|-----------------------|
| Status  | Released              |



### **Document Information**

## **History**

| Author                | Date       | Version | Remarks                 |
|-----------------------|------------|---------|-------------------------|
| Thorsten Fröhlinghaus | 2011-04-07 | 1.0     | Created                 |
| Thorsten Fröhlinghaus | 2011-04-07 | 1.0     | Released                |
| Thorsten Fröhlinghaus | 2011-12-20 | 1.1     | Legacy Converter V1.3.0 |
| Thorsten Fröhlinghaus | 2012-01-20 | 1.1     | Released                |
| Thorsten Fröhlinghaus | 2012-03-22 | 1.2     | Released                |
| Thorsten Fröhlinghaus | 2012-11-21 | 1.3     | Released                |
| Thorsten Fröhlinghaus | 2014-04-01 | 1.4.1   | Released                |
| Thorsten Fröhlinghaus | 2014-07-28 | 1.4.2   | Released                |

#### **Reference Documents**

| No. | Source  | Title  | Version |
|-----|---------|--|---------|
| [1] | Autosar | Specification of the System Template, R3.1 Rev 4 | V3.2.0  |
| [2] | Autosar | Specification of the System Template, R3.2 Rev 1 | V3.4.0  |
| [3] | Autosar | System Template, R4.0 Rev 3                      | V4.2.0  |



#### Caution

We have configured the programs in accordance with your specifications in the questionnaire. Whereas the programs do support other configurations than the one specified in your questionnaire, Vector's release of the programs delivered to your company is expressly restricted to the configuration you have specified in the questionnaire.



# Contents

| 1 | Introduction |                        | 5  |
|---|--------------|------------------------|----|
| 2 | Fund         | ctional Description    | 6  |
|   | 2.1          | DBC Transformation     | 8  |
|   | 2.2          | LDF Transformation     | 12 |
|   | 2.3          | Fibex Transformation   | 15 |
|   | 2.4          | Extension File         | 21 |
| 3 | Glos         | sary and Abbreviations | 25 |
|   | 3.1          | Glossary               | 25 |
|   | 3.2          | Abbreviations          | 25 |
| 4 | Cont         | act                    | 26 |



# **Tables**

| Table 2-1 | Vector Legacy Converter help text                 | 6  |
|-----------|---|----|
| Table 2-2 | Transformation of CAN network objects             |    |
| Table 2-3 | Transformation of user-defined attributes         |    |
| Table 2-4 | Transformation of LIN network objects             | 14 |
| Table 2-5 | Transformation of Fibex 2.0.1 elements            |    |
| Table 2-6 | Transformation of Fibex 3.0.0/3.1.0 elements.     | 20 |
| Table 2-7 | Vector System Description Extension file elements | 24 |



#### 1 Introduction

The Vector Legacy Converter (VLC) supports the migration of legacy embedded software to the AUTOSAR software architecture. The VLC is a console application which transforms one or more DBC-, LDF- and Fibex files into an AUTOSAR System Description and its ECU Extracts. The VLC is typically called by the DaVinci Project Assistant (DPA), but it can also be used as a stand-alone tool. The resulting ECU Extracts will serve as input for the Initial EcuC Generator.



## 2 Functional Description

The VLC analyses legacy communication databases, and it maps their communication elements to AUTOSAR System Description elements. There are no standards or established rules which define such a mapping between legacy communication databases and System Descriptions. For this reason, the VLC defines its own AUTOSAR mapping rules which aim at preserving the semantics of the original communication databases. These generic rules may be supplemented with OEM-specific rules.

The AUTOSAR System Description allows various modeling variants w.r.t. to, e.g., naming conventions and package structures. The VLC imposes fixed modeling rules which define a common namespace for DBC-, LDF- and Fibex transformations. The VLC modeling rules are not coordinated with the AUTOSAR transformations of other tools from other vendors. The transformation results of the VLC and other tools may appear rather different.

The VLC supports no user interaction, and thus the transformation between legacy formats and AUTOSAR System Descriptions is always the same. However, the VLC still identifies the manufacturer of a communication database, and it applies OEM-specific rules. These OEM-specific rules must be implemented in advance.

The calling conventions and options of the VLC are specified with the following help text:

```
Usage: LegacyDb2SystemDescrConverter [options] <file|dir> [<file|dir> ...]
[extfile]

Create an AUTOSAR System Description out of one or more DBC, LDF or Fibex communication databases.

Options:

-h, --help Show this help
-a, --adoptname Adopt DBC filename as cluster name
-e, --extract Create ECU extracts
-r, --release <31|32|40> AUTOSAR release
-o, --output <file|dir> Output file or directory

Parameters:
 <file|dir> Input file (*.dbc, *.ldf, *.xml) or directory extfile Extension file (*.vsde)
```

Table 2-1 Vector Legacy Converter help text.

The options may also be specified in a file called LegacyDb2SystemDescrConverter.config which resides in the same directory as the exe file LegacyDb2SystemDescrConverter.exe. In this way, options can be defined which are processed, e.g., when calling the VLC from the DPA.

With the option '-r' or '--release' the AUTOSAR schema version can be selected. Currently, AUTOSAR 3.1.4, AUTOSAR 3.2.1 and AUTOSAR 4.0.3 are supported. The VLC implements those schema versions which are required by the Vector tool chain, especially by the Initial EcuC Generator. The VLC does not aim at supporting arbitrary AUTOSAR schema versions.



Please note that the DBC-, LDF- and Fibex transformations are rather sophisticated, and thus we can only provide a general survey with this document. To identify the AUTOSAR mapping more in detail, the user may, e.g., perform minor changes to a communication database, and then compare the transformation results before and after these changes. The VLC defines a fixed order for all AUTOSAR elements, so two System Descriptions can be easily diffed.



#### 2.1 DBC Transformation

The DBC file format is based on a network-specific object model and on user-defined attributes. The former can be transformed in a generic way to AUTOSAR, while the latter often require an OEM-specific transformation. The table below shows how CAN network objects are mapped to AUTOSAR 3.1.4 or AUTOSAR 3.2.1 elements.

```
CAN network object
                              AUTOSAR element
Signal
                              SystemSignal
                                ShortName = Signal.Name
                                Length
                                        = Signal.Bitcount
                                BooleanType|IntegerType|RealType
   ShortName = "DT_" + Signal.Name
                                  LowerLimit = (Signal.Min-Signal.Offset)/Signal.Factor
                                  UpperLimit = (Signal.Max-Signal.Offset)/Signal.Factor
                                  CompuMethod
                                    ShortName = "CM" + Signal.Name
                                    Unit
                                      ShortName = "U " + Signal.Unit
                                    CompuInternalToPhys.CompuScale
                                      LowerLimit = Signal.TextualEncoding.LowerBound
                                      UpperLimit = Signal.TextualEncoding.UpperBound
                                      CompuConst = "Cx<Limit>_" + Signal.TextalEncoding.Text
                                    CompuInternalToPhys.CompuScale.CompuRationalCoeffs
                                      CompuNumerator = Signal.Offset, Signal.Factor
SignalGroup
                              SystemSignalGroup
                                ShortName = "SG " + SignalGroup.Name
CANBUS
                              CanCluster
                                ShortName
                                            = CANBus.Attributes.DBName
                                ProtocolName = "CAN"
                                PhysicalChannel
                                  ShortName = "CHNL"
CANBus
                              Frame
 .CANFrame
                                ShortName
                                           = CANFrame.Name + " " + CanCluster.ShortName
                                FrameLength = CANFrame.DLC
                              SignalIPdu|MultiplexedIPdu|DcmIPdu|NmPdu|NPdu
                               ShortName = CANFrame.Name + "__" + CanCluster.ShortName
                                Length = 8*CANFrame.DLC
                              Frame.PduToFrameMapping
                                ShortName
                                                = CANFrame.Name
                                PackingByteOrder = Intel
                                StartPosition = 0
                              PhysicalChannel.CanFrameTriggering
                                ShortName = "FT" + CANFrame.Name
                                Identifier = CANFrame.ID
                              PhysicalChannel.IPduTriggering
                                ShortName = "PT_" + CANFrame.Name
CANBus
                                ShortName = Signal.Name + "_" + CANFrame.Name
+ " " + CanCluster.ShortName
 .CANFrame
 .MappedSignal
 .Signal
                              SignalIPdu.ISignalToIPduMapping
                                ShortName
                                               = Signal.Name
                                PackingByteOrder = MappedSignal.Intel|Motorola
                                StartPosition = MappedSignal.Startbit
                              PhysicalChannel.SignalTriggering
                                ShortName = "ST " + Signal.Name + " " + CANFrame.Name
CANBus
                              MultiplexedIPdu.SelectorField
                                ByteOrder = MappedMultiplexorSignal.Intel|Motorola
 .CANFrame
 .MappedMultiplexorSignal
                                              = MultiplexorSignal.Bitcount
 .MultiplexorSignal
                                StartPosition = MappedMultiplexorSignal.Startbit
CANBus
                              MultiplexedIPdu.DynamicPart.DynamicPartAlternative
 .CANFrame
                                SelectorFieldCode = MappedMultiplexedSignal.MultiplexorValue
 .MappedMultiplexorSignal
                                SignalIPdu
 .MappedMultiplexedSignal
                                  ShortName = CANFrame.Name + " Mx<Code> " + CanCluster.ShortName
 .MultiplexedSignal
                                          = 8*CANFrame.DLC
                                  Lenat.h
                                PhysicalChannel.IPduTriggering
```



|   | ShortName = "PT_" + CANFrame.Name + "_Mx <code>"</code>  |
|---|--|
| CANNode                                   | EcuInstance ShortName = CANNode.Name ComProcessingPeriod = 0.001 EcuInstance.CanCommunicationController ShortName = "CT_" + CanCluster.ShortName EcuInstance.CommunicationConnector ShortName = "CN_" + CanCluster.ShortName EcuInstance.AssociatedIPduGroup(Rx) ShortName = CANNode.Name + "_" + CanCluster.ShortName + "_Rx" EcuInstance.AssociatedIPduGroup(Tx) ShortName = CANNode.Name + "_" + CanCluster.ShortName + "_Tx" |
| CANNode<br>.RxCANFrame                    | CommunicationConnector.FramePort ShortName = "FP_" + RxCANFrame.Name + "_Rx" Direction = In CommunicationConnector.IPduPort ShortName = "PP_" + RxCANFrame.Name + "_Rx" Direction = In   |
| CANNode .RxCANFrame .MappedSignal .Signal | CommunicationConnector.SignalPort ShortName = "SP_" + Signal.Name + "_" + RxCANFrame.Name + "_Rx" Direction = In   |
| CANNode<br>.TxCANFrame                    | CommunicationConnector.FramePort ShortName = "FP_" + TxCANFrame.Name + "_Tx" Direction = Out CommunicationConnector.IPduPort ShortName = "PP_" + TxCANFrame.Name + "_Tx" Direction = Out   |
| CANNode .TxCANFrame .MappedSignal .Signal | CommunicationConnector.SignalPort ShortName = "SP_" + Signal.Name + "_" + TxCANFrame.Name + "_Tx" Direction = Out  |

Table 2-2 Transformation of CAN network objects.

©2014, Vector Informatik GmbH Version: 1.4.2 9 / 26



The subsequent table shows how user-defined attributes are processed by the AUTOSAR transformation.

Attribute Autosar element



Table 2-3 Transformation of user-defined attributes.

In addition to the transformation steps described in the tables above, the following rules hold for the DBC transformation.

- > For SignalGroups the SignalIPdu.ISignalToIPduMapping.TransferProperty is always Pending.
- > The attribute CANBus.ILTxTimeout is not processed.



#### 2.2 LDF Transformation

The LDF file format does not provide any user-defined attributes or other OEM extensions. The subsequent table shows how LIN network objects are transformed in a generic way to AUTOSAR 3.1.4 or AUTOSAR 3.2.1 elements.

```
LIN network object
                               AUTOSAR element
Signal
                               SystemSignal
                                 ShortName = Signal.Name
                                 Length = Signal.Bitcount
                                BooleanType | IntegerType
ShortName = "DT_" + Signal.Name
                                   LowerLimit = (Signal.Min-Signal.Offset)/Signal.Factor
                                   UpperLimit = (Signal.Max-Signal.Offset)/Signal.Factor
                                   CompuMethod
                                     ShortName = "CM" + Signal.Name
                                     Unit
                                       ShortName = "U " + Signal.Unit
                                     CompuInternalToPhys.CompuScale
                                       LowerLimit = Signal.TextualEncoding.LowerBound
                                       UpperLimit = Signal.TextualEncoding.UpperBound
                                       CompuConst = "Cx<Limit> " + Signal.TextalEncoding.Text
                                     CompuInternalToPhys.CompuScale.CompuRationalCoeffs
                                       CompuNumerator = Signal.Offset, Signal.Factor
                                ConstantSpecification
                                   ShortName = "C " + Signal.Name
                                   BooleanLiteral | IntegerLiteral
                                     ShortName = "C " + Signal.Name
                                             = Signal.LDFSignalSpecialValues
                               LinCluster
LINBus
                                 ShortName = LINBus.LINChannelPostfix
ProtocolName = "LIN"
                                 ProtocolVersion = LINBus.ProtocolVersion
                                                 = LINBus.BaudRate
                                 PhysicalChannel
                                   ShortName = "CHNL"
T.TNB11S
 .LINFrame (Unconditional)
                                            = LINFrame.Name + "__" + LinCluster.ShortName
                                 ShortName
                                 FrameLength = LINFrame.Size
                               SignalIPdu|DcmIPdu|NPdu
                                 ShortName = LINFrame.Name + "__" + LinCluster.ShortName
                                Length = 8*LINFrame.Size
                               Frame.PduToFrameMapping
                                ShortName
                                                 = LINFrame.Name
                                 PackingByteOrder = LINBus.ByteOrder
                                 StartPosition = 0 \text{ (Intel)} | 7 \text{ (Motorola)}
                               PhysicalChannel.LinFrameTriggering
                                ShortName = "FT" + LINFrame.Name
                                ChecksumType = LINFrame.CSModel
                                 Identifier = LINFrame.ID
                               PhysicalChannel.IPduTriggering
                                 ShortName = "PT_" + LINFrame.Name
                                ShortName = Signal.Name + "__" + LINFrame.Name + "_" + LinCluster.ShortName
 .LINFrame (Unconditional)
 .MappedSignal
 .Signal
                               SignalIPdu.ISignalToIPduMapping
                                 ShortName
                                                 = Signal.Name
                                 PackingByteOrder = MappedSignal.Intel|Motorola
                                StartPosition
                                                  = MappedSignal.Startbit
                               PhysicalChannel.SignalTriggering
                                 ShortName = "ST " + Signal.Name + " " + LINFrame.Name
LINBus
                              SubstitutionFrame
                                               = LINFrame.Name + "__" + LinCluster.ShortName = LINFrame.Size
 .LINFrame(Sporadic
                                ShortName
          |EventTriggered)
                                 FrameLength
                                 SubstitutionType = Sporadic|EventTriggered
                               PhysicalChannel.LinFrameTriggering
                                 ShortName = "FT " + LINFrame.Name
                                 ChecksumType = LINFrame.CSModel
```



```
Identifier
                                               = LINFrame.ID
LINNode (Master|Slave)
                                EcuInstance
                                  ShortName = LINNode.Name
                                EcuInstance.LinMaster
                                  ShortName = "CT" + LinCluster.ShortName
                                                 = LINNode.Timebase
                                  TimeBase
                                  TimeBaseJitter = LINNode.Jitter
                                EcuInstance.LinSlave
                                  ShortName = "CT_" + LinCluster.ShortName
ConfiguredNad = LINSlaveNode.ConfiguredNad
                                  LinErrorResponse = LINSlaveNode.ResponseErrorSignal
                                  ProtocolVersion = LINSlaveNode.ProtocolVersion
                                EcuInstance.CommunicationConnector
                                ShortName = "CN_" + LinCluster.ShortName
EcuInstance.AssociatedIPduGroup(Rx)
ShortName = LINNode.Name + "_" + LinCluster.ShortName + "_Rx"
                                EcuInstance.AssociatedIPduGroup(Tx)
                                  ShortName = LINNode.Name + "
                                                                  " + LinCluster.ShortName + " Tx"
T<sub>1</sub>TNNode
                                CommunicationConnector.FramePort
 .RxLINFrame
                                  ShortName = "FP " + RxLINFrame.Name + " Rx"
                                  Direction = In
                                CommunicationConnector.IPduPort
                                  ShortName = "PP_" + RxLINFrame.Name + "_Rx"
                                  Direction = In
                                CommunicationConnector.SignalPort
ShortName = "SP_" + Signal.Name + "_" + RxLINFrame.Name + "_Rx"
T.TNNode
 .RxLINFrame
 .MappedSignal
                                  Direction = In
 .Signal
I.TNNode
                                CommunicationConnector.FramePort
                                  ShortName = "FP_" + TxLINFrame.Name + "_Tx"
 .TxLINFrame
                                  Direction = Out
                                CommunicationConnector.IPduPort
                                  ShortName = "PP " + TxLINFrame.Name + " Tx"
                                  Direction = Out
T.TNNode
                                CommunicationConnector.SignalPort
                                  ShortName = "SP_" + Signal.Name + "__" + TxLINFrame.Name + " Tx"
 .TxLINFrame
                                  Direction = Out
 .MappedSignal
 .Signal
T.TNB11S
                                LinCluster.LinScheduleTable
 .LINScheduleTable
                                  ShortName = LINScheduleTable.Name
                                  Priority = 255
                                  RunMode = RunContinuous
LINBus
                                LinFrameTriggering.RelativelyScheduledTiming
.LINScheduleTable
                                             = UnconditionalFrameSlot.SlotDelay
 .UnconditionalFrameSlot
                                  PositionInTable = UnconditionalFrameSlot.ID
                                LinFrameTriggering.RelativelyScheduledTiming
.LINScheduleTable
                                                  = DiagnosticFrameSlot.SlotDelay
                                  PositionInTable = DiagnosticFrameSlot.ID
 .DiagnosticFrameSlot
                                LinFrameTriggering.AssignFrameIdTiming
.LINScheduleTable
                                                 = AssignFrameIdSlot.SlotDelay
                                  PositionInTable = AssignFrameIdSlot.ID
 .AssignFrameIdSlot
                                  AssignedFrameTriggering
                                    ShortName = "FT " + AssignFrameIdSlot.FrameToAssign.Name
LINBus
                                LinFrameTriggering.UnassignFrameIdTiming
 .LINScheduleTable
                                                   = UnassignFrameIdSlot.SlotDelay
 .UnassignFrameIdSlot
                                  PositionInTable = UnassignFrameIdSlot.ID
                                  UnassignedFrameTriggering
   ShortName = "FT_" + UnassignFrameIdSlot.FrameToUnassign.Name
LINBus
                                LinFrameTriggering.AssignNADTiming
.LINScheduleTable
                                                   = AssignNADSlot.SlotDelay
 .AssignNADSlot
                                  PositionInTable = AssignNADSlot.ID
                                  NewNAD
                                                  = AssignNADSlot.NewNAD
LINBus
                                LinFrameTriggering.DataTiming
 .LINScheduleTable
                                                        = ConditionalChangeNADSlot.SlotDelay
 . {\tt ConditionalChangeNADSlot}
                                  PositionInTable
                                                     = ConditionalChangeNADSlot.ID
                                  FreeFormatByteValues = ConditionalChangeNADSlot.DataBytes
```



| LINBus                   | LinFrameTriggering.DataTiming                           |
|--------------------------|---|
| .LINScheduleTable        | Delay = FreeFormatSlot.SlotDelay                        |
| .FreeFormatSlot          | PositionInTable = FreeFormatSlot.ID                     |
|                          | FreeFormatByteValues = FreeFormatSlot.DataBytes         |
| LINBus                   | LinFrameTriggering.RelativelyScheduledTiming            |
| .LINScheduleTable        | Delay = EventTriggeredFrameSlot.SlotDelay               |
| .EventTriggeredFrameSlot | PositionInTable = EventTriggeredFrameSlot.ID            |
| LINBus                   | LinFrameTriggering.RelativelyScheduledTiming            |
| .LINScheduleTable        | Delay = SporadicFrameSlot.SlotDelay                     |
| .SporadicFrameSlot       | PositionInTable = SporadicFrameSlot.ID                  |
| LINBus                   | LinFrameTriggering.DataTiming                           |
| .LINScheduleTable        | Delay = DataDumpSlot.SlotDelay                          |
| .DataDumpSlot            | PositionInTable = DataDumpSlot.ID                       |
|                          | FreeFormatByteValues = DataDumpSlot.DataBytes           |
| LINBus                   | LinFrameTriggering.DataTiming                           |
| .LINScheduleTable        | Delay = AssignFrameIdRangeSlot.SlotDelay                |
| .AssignFrameIdRangeSlot  | PositionInTable = AssignFrameIdRangeSlot.ID             |
|                          | FreeFormatByteValues = AssignFrameIdRangeSlot.DataBytes |
| LINBus                   | LinFrameTriggering.DataTiming                           |
| .LINScheduleTable        | Delay = SaveConfigurationSlot.SlotDelay                 |
| .SaveConfigurationSlot   | PositionInTable = SaveConfigurationSlot.ID              |
|                          | FreeFormatByteValues = SaveConfigurationSlot.DataBytes  |

Table 2-4 Transformation of LIN network objects.



#### 2.3 Fibex Transformation

The VLC supports the transformation of Fibex 2.0.1 files and of Fibex 3.0.0 or 3.1.0 files. The main difference between these Fibex versions is the modeling of PDUs. In Fibex 2.0.1 PDUs are modeled with signal groups, while in Fibex 3.0.0 and 3.1.0 PDUs are an explicit part of the XML schema. The table below shows how Fibex 2.0.1 elements are mapped to AUTOSAR 3.1.4 or AUTOSAR 3.2.1 elements.

| Fibex element                 | AUTOSAR element  |
|-------------------------------|--|
| PhysicalDimension             | PhysicalDimesion ShortName = PhysicalDimension.ShortName LengthExp = PhysicalDimension.LengthExp MassExp = PhysicalDimension.MassExp TimeExp = PhysicalDimension.TimeExp CurrentExp = PhysicalDimension.CurrentExp TemperatureExp = PhysicalDimension.TemperatureExp MolarAmoutExp = PhysicalDimension.MolarAmoutExp LuminousIntensityExp = PhysicalDimension.LuminousIntensityExp |
| Unit                          | Unit ShortName = Unit.ShortName DisplayName = Unit.DisplayName FactorSiToUnit = Unit.FactorSiToUnit OffsetSiToUnit = Unit.OffsetSiToUnit   |
| Coding                        | BooleanType OpaqueType IntegerType RealType CharType StringType ShortName = Coding.ShortName LowerLimit = (Coding.CompuMethod.PhysConstr.LowerLimit  |
| Coding<br>.CompuMethod        | CompuMethod ShortName = "CM_" + CompuMethod.ShortName CompuInternalToPhys.CompuScale LowerLimit = CompuMethod.CompuScale.LowerLimit UpperLimit = CompuMethod.CompuScale.UpperLimit CompuConst = "Cx <limit>_" + CompuMethod.CompuScale.CompuConst CompuRationalCoeffs = CompuMethod.CompuScale.CompuRationalCoeffs</limit>   |
| Signal                        | SystemSignal ShortName = Signal.ShortName Length = Signal.Coding.BitLength ConstantSpecification ShortName = "C_" + Signal.ShortName BooleanLiteral OpaqueLiteral IntegerLiteral RealLiteral   CharLiteral StringLiteral ShortName = "C_" + Signal.ShortName Value = Signal.DefaultValue   |
| Frame                         | Frame ShortName = Frame.ShortName FrameLength = Frame.ByteLength   |
| SignalGroup                   | SignalIPdu DcmIPdu NmPdu NPdu ShortName = SignalGroup.ShortName Length = SignalGroup.BitLength Frame.PduToFrameMapping ShortName = SignalGroup.ShortName PackingByteOrder = Intel StartPosition = Frame.SignalInstance.BitPosition - SignalGroup.OrderedSignal.BitPosition   |
| Frame .SignalInstance .Signal | <pre>ISignal    ShortName = Signal.ShortName + "" + Frame.ShortName SignalIPdu.ISignalToIPduMapping</pre>  |



|                  | ShortName = Sig                            |  |
|------------------|--|--|
|                  |  | nalInstance.Intel Motorola   |
|                  |  | nalInstance.BitPosition  |
|                  | - F  | rame.PduToFrameMapping.StartPosition   |
| rame             | MultiplexedIPdu                            |  |
| .Multiplexer     | ShortName = Frame.Shor                     |  |
| .Switch          | Length = 8*Frame.By                        | teLength   |
|                  | Frame.PduToFrameMapping                    | Observative and Maria  |
|                  | ShortName = Fra PackingByteOrder = Int     |  |
|                  | StartPosition = 0                          | eī   |
|                  | MultiplexedIPdu.Selector                   | Field  |
|                  | ByteOrder = Switch                         | .Intel Motorola  |
|                  | ByteOrder = Switch Length = Switch         | .BitLength   |
|                  | StartPosition = Switch                     | .BitPosition   |
| rame             | MultiplexedIPdu.DvnamicP                   | art.DynamicPartAlternative   |
| .Multiplexer     | SelectorFieldCode = Su                     |  |
| .Data            | SignalIPdu                                 |  |
| .SubFrame        | ShortName = SubFrame                       | .ShortName + "_Mx" + SubFrame.SwitchCode   |
|                  | Length = 8*Frame.                          | ByteLength   |
| :luster(FlexRay) | FlexrayCluster                             |  |
| . 2.             | ShortName                                  | = Cluster.ShortName  |
|                  | MaxFrameLength                             | <pre>= Cluster.MaxFrameLength = Cluster.Protocol = Cluster.ProtocolVersion</pre> |
|                  | ProtocolName                               | = Cluster.Protocol   |
|                  |  |  |
|                  | Speed                                      | = Cluster.Speed  |
|                  | ActionPointOffset<br>Bit                   | <pre>= Cluster.ActionPointOffset = Cluster.Bit/1000000</pre>                     |
|                  | CasRxLowMin                                | = Cluster.CasRxLowMin  |
|                  | CasRxLowMax                                | = Cluster.CasRxLowMax  |
|                  |  | = Cluster.ColdStartAttempts  |
|                  | Cycle                                      | = Cluster.Cycle/1000000  |
|                  | DynamicSlotIdlePhase                       | = Cluster.DynamicSlotIdlePhase   |
|                  | ListenNoise                                | = Cluster.ListenNoise  |
|                  | MacroPerCycle                              | = Cluster.MacroPerCycle  |
|                  | MacrotickDuration                          | = Cluster.Macrotick/1000000  |
|                  |  | = Cluster.MaxInitializationError/100000  |
|                  | MaxWithoutClockCorrect                     | = Cluster.MaxWithoutClockCorrectionFatal   |
|                  | MaxWithoutClockCorrect                     |  |
|                  | nami enoucoi ochooli ee e                  | = Cluster.MaxWithoutClockCorrectionPassiv  |
|                  | MinislotActionPointOff                     | set = Cluster.MinislotActionPointOffset  |
|                  | MinislotDuration                           |  |
|                  | NetworkIdleTime                            | = Cluster.NIT  |
|                  | NetworkManagementVecto                     |  |
|                  |  | = Cluster.NetworkManagementVectorLength  |
|                  | NumberOfCycles                             | = Cluster.NumberOfCycles   |
|                  | NumberOfMinislots                          | = Cluster.NumberOfMinislots  |
|                  | NumberOfStaticSlots<br>OffsetCorrectionMax | <pre>= Cluster.NumberOfStaticSlots = Cluster.OffsetCorrectionMax/1000000</pre>   |
|                  | OffsetCorrectionStart                      | = Cluster.OffsetCorrectionMax/1000000<br>= Cluster.OffsetCorrectionStart         |
|                  | PayloadLengthStatic                        | = Cluster.PayloadLengthStatic  |
|                  | SampleClockPeriod                          | = Cluster.SampleClockPeriod/1000000  |
|                  | StaticSlotDuration                         | = Cluster.StaticSlot   |
|                  | SymbolWindow                               | = Cluster.SymbolWindow   |
|                  | SyncFrameIdCountMax                        | = Cluster.SyncNodeMax  |
|                  | TransmissionStartSeque                     | nceDuration = Cluster.TSSTransmitter   |
|                  | WakeupRxIdle                               | = Cluster.WakeUpSymbolRxIdle   |
|                  | WakeupRxLow                                | = Cluster.WakeUpSymbolRxLow  |
|                  | WakeupRxWindow                             | = Cluster.WakeUpSymbolRxWindow   |
|                  | WakeupTxActive                             | = Cluster.WakeUpSymbolTxLow  |
|                  | WakeupTxIdle                               | = Cluster.WakeUpSymbolTxIdle   |
| hannel           | FlexrayCluster.FlexrayPh                   |  |
|                  | ShortName = Channel.                       |  |
|                  | ChannelName = Channel.                     | rrexrayCuannerwame   |
| Channel          | FlexrayPhysicalChannel.F                   |  |
| .FrameTriggering | ShortName = "FT_" + Fr                     | ameTriggering.AbsolutelyScheduledTiming  |
| hannel           | FlexrayFrameTriggering.A                   | bsolutelyScheduledTiming   |
| .FrameTriggering |  | lutelyScheduledTiming.SlotID   |
| •Framerriggering |  |  |



```
CycleRepetition = AbsolutelyScheduledTiming.CycleRepetition
Channel
                              FlexrayPhysicalChannel.IPduTriggering
.FrameTriggering
                                ShortName = "PT " + SignalGroup.ShortName
 .SignalGroup
Channel
                              FlexrayPhysicalChannel.SignalTriggering
                                ShortName = "ST " + Signal.ShortName + " "+ SignalGroup.ShortName
 .FrameTriggering
 .Frame
 .SignalGroup
 .Signal
Channel
                              SignalIPdu.IPduTimingSpecification.CyclicTiming
                                RepeatingTime = CyclicTiming.RepeatingTimeRange
 .FrameTriggering
 .CyclicTiming
                              SignalIPdu.IPduTimingSpecification.EventControlledTiming
Channel
 .FrameTriggering
                                RepetitionPeriod = EventControlledTiming.DebounceTimeRange
 .EventControlledTiming
Channel
                              SignalIPdu.IPduTimingSpecification.RequestControlledTiming
.FrameTriggering
                                ResponseTime = RequestControlledTiming.ResponseTimeRange
 .RequestControlledTiming
                              EcuInstance
Ecu
                                ShortName = Ecu.ShortName
                              EcuInstance.FlexrayCommunicationController
Ecu
 .Controller
                                ShortName
                                                            = Controller.ShortName
                                AcceptedStartupRange
                                                           = Controller.AcceptedStartupRange
                               AllowHaltDueToClock
                                                           = Controller.AllowHaltDueToClock
                                AllowPassiveToActive
                                                           = Controller.AllowPassiveToActive
                                ClusterDriftDamping
                                                           = Controller.ClusterDriftDamping
                                DecodingCorrection
                                                           = Controller.DecodingCorrection
                                DelayCompensationA
                                                            = Controller.DelayCompensationA
                                DelayCompensationB
                                                            = Controller.DelayCompensationB
                                ExternOffsetCorrection
                                                            = Controller.ExternOffsetCorrection
                               ExternRateCorrection
                                                            = Controller.ExternRateCorrection
                               KeySlotId
                                                            = Controller.KeySlotUsage.StartupSync
                                                            | Controller.KeySlotUsage.Sync
                                KeySlotUsedForStartUp = Controller.KeySlotUsage.StartupSync!=null
                               KeySlotUsedForSync = Controller.KeySlotUsage.StartupSync!=null
                                                       | Controller.KeySlotUsage.Sync
                                LatestTx
                                                           = Controller.LatestTx
                                ListenTimeout
                                                            = Controller.ListenTimeout
                               MacroInitialOffsetA
                                                           = Controller.MacroInitialOffsetA
                               MacroInitialOffsetB
                                                           = Controller.MacroInitialOffsetB
                                MaximumDynamicPayloadLength = Controller.MaxDynamicPayloadLength
                               MicroInitialOffsetA = Controller.MicroInitialOffsetA
                                                           = Controller.MicroInitialOffsetB
                               MicroInitialOffsetB
                               MicroPerCycle
                                                           = Controller.MicroPerCycle
                               MicrotickDuration
                                                           = Controller.Microtick/1000000
                                OffsetCorrectionOut
                                                            = Controller.OffsetCorrectionOut
                               RateCorrectionOut
                                                            = Controller.RateCorrectionOut
                                SamplesPerMicrotick
                                                            = Controller.SamplesPerMicrotick
                               WakeUpPattern
                                                            = Controller.WakeUpPattern
                             EcuInstance.FlexRayCommunicationConnector
ShortName = "CN_" + Cluster.ShortName
+ "_" + Connector.Channel.ShortName
Ecu
 .Connector
                                            = Ecu.DiagnosticAddress[Physical]
                                WakeUpChannel = Connector.WakeUpChannel
                              EcuInstance.AssociatedIPduGroup(Rx)
                                ShortName = Ecu.ShortName
                                           + " " + Connector.Channel.ShortName + " Rx"
                              EcuInstance.AssociatedIPduGroup(Tx)
                                ShortName = Ecu.ShortName
                                           + " " + Connector.Channel.ShortName + " Tx"
                              FlexRayCommunicationConnector.FramePort
                                ShortName = "FP"
 .Connector
                                           + FrameTriggering.AbsolutelyScheduledTiming + "_Rx"
 .InputPort
 .FrameTriggering
                                Direction = In
                              FlexRavCommunicationConnector.IPduPort
                                ShortName = "PP" + SignalGroup.ShortName + "Rx"
 .Connector
 .InputPort
                                Direction = In
 .SignalInstance
                              FlexRayCommunicationConnector.SignalPort
                                ShortName = "SP_" + Signal.ShortName
 .Signal
                                                        ' + SignalGroup.ShortName + " Rx"
 .SignalGroup
```



```
Direction = In
                                        {\tt FlexRayCommunicationConnector.FramePort}
Ecu
                                          ShortName = "FP_" + FrameTriggering.AbsolutelyScheduledTiming + "_Tx"
.Connector
 .OutputPort
 .FrameTriggering
                                          Direction = Out
                                        FlexRayCommunicationConnector.IPduPort
   ShortName = "PP_" + SignalGroup.ShortName + "_Tx"
   Direction = Out
 .Connector
 .OutputPort
                                        FlexRayCommunicationConnector.SignalPort
ShortName = "SP_" + Signal.ShortName
+ "_" + SignalGroup.ShortName + "_Tx"
 .SignalInstance
 .Signal
 .SignalGroup
                                          Direction = Out
```

Table 2-5 Transformation of Fibex 2.0.1 elements.



# The subsequent table shows how Fibex 3.0.0 or 3.1.0 elements are mapped to AUTOSAR 3.1.4 or AUTOSAR 3.2.1 elements.

| Fibex element  | AUTOSAR Element  |
|--|--|
| PhysicalDimension  | see Table 2-5  |
| Unit   | see Table 2-5  |
| Coding   | see Table 2-5  |
| Signal   | see Table 2-5  |
| Frame  | see Table 2-5  |
|  | Frame.PduToFrameMapping  |
| Frame .PduInstance   | ShortName = PduInstance.Pdu.ShortName PackingByteOrder = PduInstance.Intel Motorola StartPosition = PduInstance.BitPosition UpdateIndicationBitPosition = PduInstance.PduUpdateBitPosition                         |
| Pdu  | SignalIPdu MultiplexedIPdu DcmIPdu NmPdu NPdu ShortName = Pdu.ShortName Length = 8*Pdu.ByteLength  |
| Pdu .SignalInstance .Signal  | ISignal ShortName = Signal.ShortName + "" + Pdu.ShortName SignalIPdu.ISignalToIPduMapping ShortName = Signal.ShortName PackingByteOrder = SignalInstance.Intel Motorola StartPosition = SignalInstance.BitPosition |
| Pdu<br>.Multiplexer<br>.Switch                                       | MultiplexedIPdu.SelectorField  ByteOrder = Switch.Intel Motorola  Length = Switch.BitLength  StartPosition = Switch.BitPosition  |
| Pdu .Multiplexer .DynamicPart .SwitchedPduInstance                   | MultiplexedIPdu.DynamicPart.DynamicPartAlternative SelectorFieldCode = SwitchedPduInstance.SwitchCode SignalIPdu ShortName = SwitchedPduInstance.Pdu.ShortName Length = 8*SwitchedPduInstance.Pdu.ByteLength       |
| Cluster(FlexRay)   | see Table 2-5  |
| Channel  | see Table 2-5  |
| Channel  | see Table 2-5  |
| .FrameTriggering Channel .FrameTriggering .AbsolutelyScheduledTiming | see Table 2-5  |
| Channel .PduTriggering   | FlexrayPhysicalChannel.IPduTriggering ShortName = "PT_" + PduTriggering.Pdu.ShortName  |
| Channel .PduTriggering .Pdu .SignalInstance .Signal                  | FlexrayPhysicalChannel.SignalTriggering ShortName = "ST_" + Signal.ShortName + "_" + PduTriggering.Pdu.ShortName   |
| Channel .PduTriggering .CyclicTiming                                 | SignalIPdu.IPduTimingSpecification.CyclicTiming FinalRepetitions = CyclicTiming.FinalRepetitions RepeatingTime = CyclicTiming.RepeatingTimeRange StartingTime = CyclicTiming.StartingTimeRange                     |
| Channel .PduTriggering .EventControlledTiming                        | SignalIPdu.IPduTimingSpecification.EventControlledTiming NumberOfRepeats = EventControlledTiming.FinalRepetitions RepetitionPeriod = EventControlledTiming.DebounceTimeRange                                       |
| Channel .PduTriggering .RequestControlledTiming                      | SignalIPdu.IPduTimingSpecification.RequestControlledTiming ResponseTime = RequestControlledTiming.ResponseTimeRange  |
| Ecu  | see Table 2-5  |
| Ecu<br>.Controller   | see Table 2-5  |
| .Controller<br>Ecu   | see Table 2-5  |
| .Connector   |  |



| Ecu<br>.Connector            | see Table 2-5   |  |  |
|------------------------------|---|--|--|
| .InputPort                   |   |  |  |
| .FrameTriggering             |   |  |  |
| Ecu                          | FlexRayCommunicationConnector.IPduPort  |  |  |
| .Connector                   | ShortName = "PP_" + PduTriggering.Pdu.ShortName + "_Rx"                               |  |  |
| .InputPort                   | Direction = In  |  |  |
| .IncludedPdu                 |   |  |  |
| .PduTriggering               |   |  |  |
| Ecu                          | FlexRayCommunicationConnector.SignalPort  |  |  |
| .Connector                   | ShortName = "SP_" + SignalInstance.Signal.ShortName + ""                              |  |  |
| .InputPort                   | + IncludedPdu.PduTriggering.Pdu.ShortName + "_Rx" Direction = In                      |  |  |
| .IncludedPdu .IncludedSignal | Direction = in  |  |  |
| .SignalInstance              |   |  |  |
| Ecu                          | see Table 2-5   |  |  |
| .Connector                   | See Table 2 9   |  |  |
| .OutputPort                  |   |  |  |
| .FrameTriggering             |   |  |  |
| Ecu                          | FlexRayCommunicationConnector.IPduPort  |  |  |
| .Connector                   | ShortName = "PP " + PduTriggering.Pdu.ShortName + " Tx"                               |  |  |
| .OutputPort                  | Direction = Out   |  |  |
| .IncludedPdu                 |   |  |  |
| .PduTriggering               |   |  |  |
| Ecu                          | FlexRayCommunicationConnector.SignalPort  |  |  |
| .Connector                   | ShortName = "SP_" + SignalInstance.Signal.ShortName + ""                              |  |  |
| .OutputPort                  | + IncludedPdu.PduTriggering.Pdu.ShortName + "_Tx"                                     |  |  |
| .IncludedPdu                 | Direction = Out   |  |  |
| .IncludedSignal              |   |  |  |
| .SignalInstance              |   |  |  |
| TpConfig                     | FlexrayPhysicalChannel.TpAddress  |  |  |
| .TpAddress                   | ShortName = "TA_" + TpAddress TpAddress = TpAddress                                   |  |  |
|                              | ipaddiess - ipaddiess   |  |  |
| TpConfig                     | FlexrayPhysicalChannel.FlexrayTpChannel   |  |  |
| .TpChannel                   | AckType = TpChannel.AckType   |  |  |
|                              | ExtendedAddressing = TpChannel.AddressingType == FrtpTb                               |  |  |
|                              | MaxBs = TpChannel.MaxBlockSize  |  |  |
|                              | MaxRetries = TpChannel.MaxRetries   |  |  |
|                              | MaximumMessageLength = TpChannel.MaximumMessageLength                                 |  |  |
|                              | MulticastSegmentation = TpChannel.GroupSegmentation                                   |  |  |
|                              | TimeoutBs = TpChannel.TimeoutBs   |  |  |
|                              | TimeoutCr = TpChannel.TimeoutCr TransmitCancellation = TpChannel.TransmitCancellation |  |  |
|                              | riansmitteanterration - iponamer. riansmitteanterration                               |  |  |
| TpConfig                     | FlexrayTpChannel.FlexRayTpConnection  |  |  |
| .TpChannel                   | FlexrayTpChannel.FlexRayTpConnection.DirectTpSdu                                      |  |  |
| .TpConnection                | ShortName = TpConnection.ShortName + "_Rq"  |  |  |
|                              | FlexrayTpChannel.FlexRayTpConnection.ReversedTpSdu                                    |  |  |
|                              | ShortName = TpConnection.ShortName + "_Rs"  |  |  |
| TpConfig                     | FlexrayPhysicalChannel.FlexrayTpNode  |  |  |
| .TpNode                      | ShortName = TpNode.ShortName  |  |  |
| -                            | FlexrayPhysicalChannel.FlexrayTpChannel   |  |  |
|                              | MaxAr = TpNode.MaxAr  |  |  |
|                              | MaxAs = TpNode.MaxAs  |  |  |
|                              | MaxBufferRequest = TpNode.BufferRequest   |  |  |
|                              | MaxFrIf = TpNode.MaxFrif  |  |  |
|                              | MinimumSeparationTime = TpNode.Stmin  |  |  |
|                              | TimeBuffer = TpNode.TimeBuffer  |  |  |
|                              | TimeFrIf = TpNode.TimeFrif  |  |  |
|                              | TimeoutAr = TpNode.TimeoutAr  |  |  |
|                              | TimeoutAs = TpNode.TimeoutAs  |  |  |

Table 2-6 Transformation of Fibex 3.0.0/3.1.0 elements.



#### 2.4 Extension File

The Vector System Description Extension (VSDE) file is used to supplement the content of DBC-, LDF- or Fibex files. An extension file defines certain communication elements which might be missing in the original legacy communication databases, or which cannot be specified with these communication databases. The table below explains the extension elements which are supported so far.

| VSDE element  | Description   |
|---|---|
| <pre><filtering>   <flexray-cluster-ref channel="A">FlexRay01   </flexray-cluster-ref> </filtering></pre>   | The dual channel FlexRayCluster FlexRay01 is filtered for its A channel. This feature is supported for Fibex databases.   |
|   |   |
| <pre><can-cluster-name>   <can-cluster-ref>Can01</can-cluster-ref>   <short-name>Can01NewName</short-name> </can-cluster-name></pre>  | The CanCluster Can01 obtains a new name Can01NewName. Similarly, LinClusters and FlexrayClusters can be renamed.  This feature is supported for DBC, LDF and Fibex databases.   |
| <pre><ecu-instance-name>   <ecu-instance-ref>Ecu01</ecu-instance-ref>   <short-name>Ecu01NewName</short-name></ecu-instance-name></pre>   | The ECU Ecu01 obtains a new name Ecu01NewName.  |
|   | This feature is supported for DBC, LDF and Fibex databases.   |
| <pre><system-signal-name>   <signal-i-pdu-ref>Pdu01</signal-i-pdu-ref>   <system-signal-ref>Sig01</system-signal-ref>   <short-name>Sig01NewName</short-name> </system-signal-name></pre>   | The signal Sig01 within pdu Pdu01 obtains a new name Sig01NewName. Signal renaming is used, e.g., to distinguish signals of the same name in different pdus.  |
|   | This feature is supported for DBC, LDF and Fibex databases.   |
| <pre><system-signal-group>   <short-name>SG_SigGrp01</short-name>   <system-signal-refs>     <system-signal-ref>Sig01</system-signal-ref>     <system-signal-ref>Sig02</system-signal-ref>   </system-signal-refs>   </system-signal-group></pre> | The signals Sig01 and Sig02 are aggregated to a new signal group SG_SigGrp01. The signals must be defined in the same database. Each pdu must contain all or none of these signals. This feature is supported for DBC, LDF and Fibex databases.           |
| <safety-pdu> <signal-i-pdu-ref>Pdu01</signal-i-pdu-ref> <create-pdu-gap-signals>true</create-pdu-gap-signals> </safety-pdu>   | All signals of pdu Pdu01 are aggregated to a new signal group SG_Pdu01. Optionally, the pdu gaps are filled with artificial gap signals, when then also become part of the new signal group.  This feature is supported for DBC, LDF and Fibex databases. |
| <bidirectional-pdu></bidirectional-pdu>   | The pdu Pdu01 can be send and received by the same ECU. This feature is supported for DBC and Fibex databases.  |
| <pdu-group> <short-name>PduGrp01</short-name> <signal-i-pdu-refs> <signal-i-pdu-ref>Pdu01</signal-i-pdu-ref> <signal-i-pdu-ref>Pdu02</signal-i-pdu-ref> </signal-i-pdu-refs> </pdu-group>   | For each cluster and ECU which sends or receives the pdus Pdu01 or Pdu02 a new Tx or Rx pdu group is created. The pdus are not assigned to the standard pdu groups created by the VLC.  This feature is supported for DBC, LDF and Fibex databases.       |
| <pre><pdu-group-definition>   <flexray-cluster-ref>FlexRay01</flexray-cluster-ref></pdu-group-definition></pre> <ecu-instance-ref>Ecu01 <channel-specific>true</channel-specific> </ecu-instance-ref>   | The dual channel FlexRayCluster FlexRay01 obtains for its ECU Ecu01 two standard Tx pdu groups and two standard Rx pdu groups – one for each channel and direction, respectively. This feature is supported for Fibex databases.                          |



```
<SIGNAL-UPDATE-DEFINITION>
                                                              The signal SigUpd01 UB within pdu Pdu01
  <SIGNAL-I-PDU-REF>Pdu01</sigNAL-I-PDU-REF>
                                                              serves as update signal for the signal Sig01
  <UPDATE-INDICATION-SIGNAL-REF>
                                                              and the signal group SG_SigGrp01. The
    SigUpd01 UB</UPDATE-INDICATION-SIGNAL-REF>
                                                              update signal can be used for one or more
  <UPDATED-SIGNALS>
                                                              signals and signal groups within a pdu at the
    <SYSTEM-SIGNAL-REF>Sig01</system-SIGNAL-REF>
  </UPDATED-SIGNALS>
                                                              same time.
  <UPDATED-SIGNAL-GROUPS>
                                                              This feature is supported for DBC, LDF and
    <SYSTEM-SIGNAL-GROUP-REF>
                                                              Fibex databases.
      SG SigGrp01</SYSTEM-SIGNAL-GROUP-REF>
  </updated-signal-groups>
</SIGNAL-UPDATE-DEFINITION>
<T-PDU-TTMTNG>
                                                              The timing elements NumberOfRepetitions,
  <STGNAL-T-PDU-REF>Pdu01</STGNAL-T-PDU-REF>
                                                              RepetitionPeriod and MinimumDelay of pdu
  <NUMBER-OF-REPETITIONS>10/NUMBER-OF-REPETITIONS>
                                                              Pdu01 override the corresponding database
  <REPETITION-PERIOD>0.001</repetITION-PERIOD>
                                                              settings. Further, the SignalSendType timing
  <MINIMUM-DELAY>0.01/MINIMUM-DELAY>
                                                              element of signal Sig01 overrides the signal
  <SIGNAL-TIMINGS>
                                                              specific timing settings. Finally, the element
    <STGNAL-TIMING>
      <SYSTEM-SIGNAL-REF>Sig01</system-SIGNAL-REF>
                                                              AccessRights defines whether the timing data
      <SIGNAL-SEND-TYPE>ON-CHANGE</SIGNAL-SEND-TYPE>
                                                              later can be changed in the Vector tool chain.
    </SIGNAL-TIMING>
                                                              This feature is supported for DBC databases.
  </SIGNAL-TIMINGS>
                                                              The AccessRights element is also supported
  <ACCESS-RIGHTS>READ-ONLY</ACCESS-RIGHTS>
                                                              for LDF and Fibex databases.
</I-PDU-TIMING>
<CAN-TP-CONNECTION>
                                                              The directly opposed pdus Pdu01 and Pdu02
  <SHORT-NAME>Can01 Pdu01 Pdu02/SHORT-NAME>
                                                              of CanCluster Can01 are combined to a new
  <CAN-CLUSTER-REF>Can01</CAN-CLUSTER-REF>
                                                              CanTpConnection Can01_Pdu01_Pdu02. The
  <DATA-PDU-REF>Pdu01/DATA-PDU-REF>
                                                              VSDE internal CanTpConnection name can be
  <FLOW-CONTROL-PDU-REF>Pdu02/FLOW-CONTROL-PDU-REF>
                                                              referred by TpHighLevelRoutings. Similarly,
</CAN-TP-CONNECTION>
                                                              pdus can be combined to a LinTpConnection.
                                                              This feature is supported for DBC and LDF
                                                              databases.
<PDUR-MESSAGE-ROUTING>
                                                              The pdu Pdu01 of CanCluster Can01 is routed
  <ECU-INSTANCE-REF>Ecu01/ECU-INSTANCE-REF>
                                                              via the gateway ECU Ecu01 to the pdu Pdu02
  <SOURCE-CAN-CLUSTER-REF>Can01/SOURCE-CAN-CLUSTER-REF>
                                                              of CanCluster Can02. The pdu Pdu01 will be
  <TARGET-CAN-CLUSTER-REF>Can02</TARGET-CAN-CLUSTER-REF>
                                                              routed by the PDUR module, and also its DLC
  <I-PDU-MAPPINGS>
                                                              value will be routed. The signal Sig01 of pdu
    <I-PDU-MAPPING>
      <ROUTE-DLC>true</ROUTE-DLC>
                                                              Pdu01 is received by the gateway ECU Ecu01,
      <SOURCE-I-PDU-REF>Pdu01</source-I-PDU-REF>
                                                              all other signals of pdu Pdu01 are not received
      <SOURCE-SIGNALS>
                                                              by Ecu01.
        <SYSTEM-SIGNAL-REF>Sig01</system-SIGNAL-REF>
                                                              This feature is supported for DBC, LDF and
      </SOURCE-SIGNALS>
                                                              Fibex databases.
      <TARGET-I-PDU-REF>Pdu02</TARGET-I-PDU-REF>
    </I-PDU-MAPPING>
  </I-PDU-MAPPINGS>
</PDUR-MESSAGE-ROUTING>
<COM-MESSAGE-ROUTING>
  <ECU-INSTANCE-REF>Ecu01/ECU-INSTANCE-REF>
 SPERRE-CAN-CLUSTER-REF>Can01</source-CAN-CLUSTER-REF>
RANGETECONEMCUSTER<REMCCOn 506/TargeTecanscousebr-bbf>9
  <I-PDUÐMÆ₽ÐĪN6$≯ROU5I
PEPPIN6PDU-MAPPING>U
     ><PROCESSING>
```

©2014, Vector Informatik GmbH Version: 1.4.2 22 / 26



```
</COM-MESSAGE-ROUTING>
<COM-SIGNAL-ROUTING>
                                                             The signal Sig01 within pdu Pdu01 of
  <ECU-INSTANCE-REF>Ecu01/ECU-INSTANCE-REF>
                                                             CanCluster Can01 is routed via the gateway
  <SOURCE-CAN-CLUSTER-REF>Can01//SOURCE-CAN-CLUSTER-REF>
                                                             ECU Ecu01 to the signal Sig02 within pdu
  <TARGET-CAN-CLUSTER-REF>Can02</TARGET-CAN-CLUSTER-REF>
                                                             Pdu02 of CanCluster Can02. The signal Sig01
  <STGNAL-MAPPINGS>
                                                             will be routed deferred by the COM module.
    <SIGNAL-MAPPING>
      <PROCESSING>DEFERED/PROCESSING>
                                                             This feature is supported for DBC, LDF and
      <SOURCE-I-PDU-REF>Pdu01</source-I-PDU-REF>
                                                             Fibex databases.
      <SOURCE-SIGNAL-REF>Sig01//SOURCE-SIGNAL-REF>
      <TARGET-I-PDU-REF>Pdu02</TARGET-I-PDU-REF>
      <TARGET-SIGNAL-REF>Sig02</TARGET-SIGNAL-REF>
    </SIGNAL-MAPPING>
  </SIGNAL-MAPPINGS>
</COM-SIGNAL-ROUTING>
<TP-HIGH-LEVEL-ROUTING>
                                                             The CanTpConnection Can01 Pdu01 Pdu02
  <ECU-INSTANCE-REF>Ecu01</ECU-INSTANCE-REF>
                                                             is routed via the gateway ECU Ecu01 to the
  <SOURCE-CAN-TP-CONNECTION-REF>Can01 Pdu01 Pdu02
                                                             CanTpConnection Can02_Pdu03_Pdu04.
    </source-can-tp-connection-ref>
                                                             CanTpConnections and LinTpConnections
  <TARGET-CAN-TP-CONNECTION-REF>Can02 Pdu03 Pdu04
                                                             are defined by the VSDE file, while
    </TARGET-CAN-TP-CONNECTION-REF>
                                                             FlexrayTpConnections are provided by Fibex
</TP-HIGH-LEVEL-ROUTING>
                                                             databases.
                                                             This feature is supported for DBC, LDF and
                                                             Fibex databases.
<TP-LOW-LEVEL-ROUTING>
                                                             The n-pdu Pdu01 of CanCluster Can01 is
  <ECU-INSTANCE-REF>Ecu01</ECU-INSTANCE-REF>
                                                             routed via the gateway ECU Ecu01 to the
  <SOURCE-CAN-CLUSTER-REF>Can01/SOURCE-CAN-CLUSTER-REF>
                                                             n-pdu Pdu02 of CanCluster Can02.
  <TARGET-CAN-CLUSTER-REF>Can02/TARGET-CAN-CLUSTER-REF>
                                                             This feature is supported for DBC databases.
  <N-PDU-MAPPINGS>
    <N-PDU-MAPPING>
      <SOURCE-N-PDU-REF>Pdu01/SOURCE-N-PDU-REF>
      <TARGET-N-PDU-REF>Pdu02</TARGET-N-PDU-REF>
    </N-PDIJ-MAPPING>
  </N-PDU-MAPPINGS>
</TP-LOW-LEVEL-ROUTING>
<PNC-CONFIGURATION>
                                                             The pdus Pdu01 and Pdu02 of CanCluster
  <PNC-VECTOR-LENGTH>3</PNC-VECTOR-LENGTH>
                                                             Can01 are combined to a PNC group for ECU
  <PNC-VECTOR-OFFSET>5/PNC-VECTOR-OFFSET>
                                                             Ecu01 and the partial network with the ID 1.
  <PNC-CLUSTERS>
                                                             A partial network is defined by all PNC groups
    <PNC-CLUSTER>
                                                             which refer the same partial network ID.
      <CAN-CLUSTER-REF>Can01</CAN-CLUSTER-REF>
      <PNC-ECUS>
                                                             This feature is supported for DBC and Fibex
        <PNC-ECU>
                                                             databases.
          <ECU-INSTANCE-REF>Ecu01</ECU-INSTANCE-REF>
          <PNC-GATEWAY-TYPE>ACTIVE</pnc-GATEWAY-TYPE>
          <PNC-WAKEUP-CAN-ID>452984832
            </PNC-WAKEUP-CAN-ID>
          <PNC-WAKEUP-CAN-ID-EXTENDED>true
            </PNC-WAKEUP-CAN-ID-EXTENDED>
          <PNC-WAKEUP-CAN-ID-MASK>127
            </PNC-WAKEUP-CAN-ID-MASK>
          <PNC-WAKEUP-DATA-MASK>4611686018427387904
            </PNC-WAKEUP-DATA-MASK>
          <PNC-WAKEUP-DLC>8</PNC-WAKEUP-DLC>
          <PNC-GROUPS>
            <PNC-GROUP>
              <pnc-identifier>1</pnc-identifier>
               <COMMUNICATION-DIRECTION>IN
                 <COMMUNICATION-DIRECTION>
               <SIGNAL-I-PDU-REFS>
                 <SIGNAL-I-PDU-REF>Pdu01
                   </SIGNAL-I-PDU-REF>
               </SIGNAL-I-PDU-REFS>
               <MULTIPLEXED-I-PDU-REFS>
                 <MULTIPLEXED-I-PDU-REF>Pdu02
                   </MULTIPLEXED-I-PDU-REF>
              </MULTIPLEXED-I-PDU-REFS>
            </PNC-GROUP>
          </PNC-GROUPS>
        </PNC-ECU>
      </PNC-ECUS>
```

©2014, Vector Informatik GmbH Version: 1.4.2 23 / 26



Table 2-7 Vector System Description Extension file elements.

The extension file is provided as a file parameter to the VLC. Its XML schema is described with the ExtractExtension.xsd file.



# 3 Glossary and Abbreviations

# 3.1 Glossary

| Term | Description |
|------|-------------|
|      |             |

### 3.2 Abbreviations

| Abbreviation | Description                         |
|--------------|-------------------------------------|
| DPA          | DaVinci Project Assistant           |
| VLC          | Vector Legacy Converter             |
| VSDE         | Vector System Description Extension |



### 4 Contact

Visit our website for more information on

- > News
- > Products
- > Demo software
- > Support
- > Training data
- > Addresses

www.vector.com