

SUGARCUBE™

SugarCube SC2-Mini-Phono

What's new as of version 2.3-570+



SugarCube SC2-Mini/Phono

New Features/Changes

Below is a short list of changes in recent releases:

1. If background clicking is detected, please **press 'Bypass' twice** to clear the click removal buffers.
2. No more needed to **power-cycle** after an update. Your SugarCube will restart itself after an update and is ready to go.
3. Various bug fixes including internal USB pathway reworked and more stable.
4. Current **software version** number now shows on main menu.
5. New '**System**' tab added to '**Settings**' to control some system functions including how long the front panel display remains on, among other controls.
6. "**VU Meter**" added to the '**Settings**' page on '**Input Level**' tab.
7. New **Startup Screen** shows the SugarCube startup progress to know when it is ready to use after power on.
8. New requirement to **power cycle** the SugarCube when a new update is installed. You will see a message to announce a new download is ready and to please power off, count to 3, then back on to complete the update process.
9. Please see the **What's New in Recording** for additional updates.

SugarCube SC2-Mini-Phono

New Features/Changes

Below is a short list of changes in the previous release:

1. **Changes to the recording system**, please see '**What's new with Recording.**'
2. **Clipping indicator** has been carefully recalibrated. If you see a yellow **Clipping Warning** pop-up, the audio has not yet clipped but is right on the edge. If you see a red **Clipping Error** (while audio is playing) the audio has clipped. In either case, you should go to the the **Settings** menu and select **Line-In Level** one step lower. Note, the clipping message stays visible for about 10 minutes or until you click on it to clear it.
3. **Fixed: missing external DAC selection in Settings**
4. **Simplified pairing:** you can now enter "1111". No more need to press the pairing button!