

WELCOME TO SUGARCUBE™

Software Version 2.0



Thank You for purchasing the SugarCube SC-1


Your experience of high-end audio is about to
get a lot sweeter

These pages provide an overview of the set-up
and control of the SC-1


For any usage questions,
please contact:
support@sweetvinyl.com



1. Unpacking Your SugarCube



SugarCube SC-1 unit



AC Power Adapter



Wifi USB Adapter



Test Record for Setup


33 1/3 RPM

Please download the **SugarCube App** from your mobile device's app store to control your **SugarCube** remotely.

This adapter connects the SugarCube to your WiFi network or you can use a wired Internet connection if available.

This test LP will be used for automatic level setting inside the SugarCube and will be usable with the SugarCube App.

2. The SC-1 Front Panel Controls



CLICK REMOVE

When pressed and the LED is lit, SugarCube is processing audio to remove clicks and pops. The **BYPASS** LED will go out.

BYPASS

When pressed and the LED is lit, an internal relay has shunted the **LINE IN** directly to **LINE OUT** completely bypassing all internal circuitry.

CLICK MON


When pressed and the LED is lit, the SugarCube suppresses the music so that you can better hear the clicks and pops. This helps set the **STRENGTH** level for particularly noisy LPs.

STRENGTH

Controls the strength of the click and pop detection and removal process. Almost all LPs will sound great at a setting of 5 or 6.

Note: we recommend that you do NOT adjust **STRENGTH** all the way to 10, you will rarely need this much. Sometimes less is more.

3. The SC-1 Back Panel




Connecting SugarCube to Your Sound System

1. Hardware Interconnects

PLEASE BE SURE ALL
EQUIPMENT IS TURNED
OFF BEFORE ATTEMPTING
INSTALLATION



4. Connecting Your SugarCube SC-1



Connecting the supplied AC adaptor.

1. Plug your SugarCube power adapter into a power source.
2. Please only use the supplied 5 volt adaptor or one that we approve.

5. Connecting Your SugarCube SC-1




Connecting in series between a phono pre-amp and line-stage (pre-amp).

1. Plug your SugarCube power adapter into a power source.
2. Connect the output of your phono pre-amp to the **LINE IN** of the SC-1.
3. Connect the **LINE OUT** of the SC-1 to an appropriate line-level input of your line-stage/pre-amp.

NOTE: DO NOT CONNECT THE **LINE OUT** OF THE SC-1 TO THE PHONO INPUT ON YOUR EQUIPMENT.

6. Connecting Your SugarCube SC-1




Connecting in series between a pre-amp, with phono input, and power amp

1. Plug your SugarCube power adapter into a power source.
2. Connect the output of your pre-amp to the **LINE IN** of the SC-2.
3. Connect the **LINE OUT** of the SC-2 to the input of your power amp.

7. Connecting Your SugarCube SC-1

Integrated Amp: using the 'tape loop'



Connecting to an integrated amplifier via Aux In/Out (or Rec In/Out).

1. Plug your SugarCube power adapter into a power source.
2. Connect **AUX OUT** (or REC OUT) of your integrated amp (or processor) to the **LINE IN** of the SC-1.
3. Connect **LINE OUT** of the SC-1 to **AUX IN** (or **REC IN**) of your integrated amp or processor.

NOTE: DO NOT CONNECT THE **LINE OUT** OF THE SC-1 TO THE **PHONO INPUT** ON YOUR EQUIPMENT.

8. Connecting Your SugarCube SC-1

Integrated Amp **WITHOUT** an AUX OUT/IN or REC OUT/IN or PRE-OUT / PWR IN



Many contemporary integrated amplifiers no longer have what was known as a 'tape loop' (back in the day of the cassette or reel-to-reel tape). Also, most modern home theatre processors that do have what are called 'effects loops' will not send audio from a phono input through the loop. In these cases, there is not a way to connect to SugarCube directly to these devices.

The solution is to add a phono stage (pre-amp) between your turntable and the SugarCube. Then connect the Line Out of the SugarCube to any available input on the integrated amp (except for the phono input, of course.)

9. Connecting Your SugarCube SC-1

Connecting turntables with built-in phono pre-amps




For turntables with a built-in phono pre-amp, be sure to set the **PHONO/LINE** switch to **LINE** before plugging into the SugarCube.

Directly connecting the line-level output from your turntable.

1. Plug your SugarCube power adapter into a power source.
2. Connect the turntable with a built-in phono pre-amp to **LINE IN**.
3. Be sure the turntable is set to **LINE** not **PHONO**.
4. Connect the **LINE OUT** of the SugarCube to any line-level input of your line stage, pre-amp, or integrated amp.

NOTE: SORRY TO BE A BROKEN RECORD ;) BUT DO NOT CONNECT THE **LINE OUT** OF THE SC-1 TO THE **PHONO INPUT** ON YOUR EQUIPMENT.

10. Connecting Your SugarCube SC-1 to a LAN or WiFi



If you would like to use the SugarCube app to control your SugarCube SC-1, please connect either the WiFi adapter supplied with your SugarCube OR plug into a wired connection. There is no need to connect both except when setting up WiFi (please read appendix A).

- When using the WiFi adapter, once the SugarCube is powered on and operational, use the SugarCube app to set-up the Wifi connection by following the instructions on the app (iOS and Android operate similarly.)
- When connecting via wired Ethernet, you need only launch the SugarCube app and it will locate and connect to your SugarCube when the device running the app is on the same network with the SugarCube.

NOTE: THE SUGARCUBE SC-1 IS FULLY FUNCTIONAL BY MEANS OF THE FRONT PANEL CONTROLS WITHOUT THE NEED TO CONNECT TO A NETWORK.

11. Starting Up Your SugarCube



(1) SugarCube just powered on



(2) SugarCube is ready to go
(please expect about three minutes to ready.)



(3) Hold the 'Bypass' button for a few seconds to see LAN address
(and WiFi SSID if using wireless.)

Please note:

When you power up your SugarCube, it will take about three minutes to complete its startup procedures. During this time, the display will light up but remain blank. We apologize for the wait but we have some seriously sophisticated software loading and it simply takes additional time. When you hear the results of our efforts, you will agree that it was worth the wait.

12. Pairing your SugarCube SC-1

NOTE: as of version 2.1 or greater, no need to press PAIR, you can use just enter code: 5123



PAIR

While setting up the connection between the SC1-Mini and the SugarCube app, or Web browser you will be prompted to press and release the front panel knob to **PAIR**, then enter the four-digit code on the SC1-Mini display.

This button is also used when setting up WiFi for the SC1-Mini for use with the SugarCube app. When configuring WiFi, you will be instructed to press and HOLD the knob in for 5 SECONDS. The display of the SC1-Mini will announce that it is in WiFi setup mode, then continue setup on your mobile device, tablet, or desktop.

Setting Up SugarCube Mobile App

2. Connecting to the SugarCube

Apple iOS and Android
Guide






Using an Apple Mobile Device (Apple iOS)

13. Items needed to set up your Apple device to control SugarCube:

1. iPhone, iPad, Touch.
2. Network with WiFi your Apple device can communicate with and that can be connected to your SugarCube with WiFi or wired Ethernet.
3. From the Apple App Store, you will be able to download the 'SugarCube' app to your Apple mobile device. (Look for: SugarCube by SweetVinyl.)
4. The WiFi dongle supplied with your SugarCube.

Note: If you plan to use **wired Ethernet**, there is no need to plug in the WiFi adapter to the SugarCube; please skip to **Section 1.3** and follow the instructions there.


14. Connecting the app with SugarCube on Wi-Fi



(1) Launch the SugarCube app




(2) App is loading




(3) App is searching for SugarCubes already setup on the LAN if any. For the first time user, nothing will be found, of course.


15. Connecting the app with SugarCube on Wi-Fi



(4) No SugarCube is found so the app offers the option to run WiFi setup.




(5) The user is instructed to press and hold the front panel knob for 5 seconds to put the SugarCube into 'WiFi Setup Mode' which will be displayed on the front panel.




(6) The instructions direct the user to press the 'Home' key to get back to the 'Home' screen and then launch 'Setup'.


16. Connecting the app with SugarCube on WiFi



(7) When in 'Settings', select 'Wi-Fi'




(8) Select 'SugarCube_nnnn', (whatever number appears after 'SugarCube_' is your device's serial number)
Use password: **SugarCube**




(9) With the 'SugarCube_nnnn' selected, your SugarCube is now temporarily acting as an access point.


17. Connecting the app with SugarCube on Wi-Fi



(10) Relaunch the SugarCube app




(11) Select the WiFi network that you wish to use



(12) Enter the WiFi password for your network


18. Connecting the app with SugarCube on Wi-Fi



(13) The app will now complete the connection to your WiFi network and also do a little housekeeping.




(14) The app will then display the SugarCube(s) found on your network. Select the appropriate device.




(15) If asked to 'Pair', press the 'front panel knob' of the SugarCube.

19. Connecting the app with SugarCube on Wi-Fi



(16) Enter the pairing code displayed on the SugarCube front panel and then press 'Pair' on the app screen.



(17) You will then see the 'Control' screen and you are done, congratulations!

NOTE: as of version 2.1 software, you can just enter **5123** without needing to get a pair code.



Using an **Android** Mobile Device

20. Items needed to set up your Android device to control SugarCube:


1. Android phone or tablet.
2. Network with WiFi your Android device can communicate with and that can be connected to your SugarCube with WiFi or wired Ethernet.
3. Download the Android App from the Google Play Store.
(Look for: SugarCube by SweetVinyl.)
4. The WiFi dongle supplied with your SugarCube or a wired Ethernet cable from a port on your router.

Note: If you plan to use wired Ethernet, there is no need to plug in the WiFi adapter to the SugarCube; please skip to page 1.10 and follow the instructions.


21. Connecting the app with SugarCube on Wi-Fi




(1) App is loading



(2) App is searching for SugarCubes on the LAN




(3) No SugarCube is found so the app offers the option to run WiFi setup.




(4) User taps 'WiFi Setup' to start the process.


22. Connecting the app with SugarCube on WiFi




(5) Next, press and hold the pairing button (on the rear panel) for 5 seconds as instructed.



(6) After this, your SugarCube will be configured as an access point and display its SSID (e.g. SugarCube_110). In this screen the app has now connected to it automatically. The password is: **SugarCube**




(7) Next, the SugarCube will find your available WiFi connections. This could take a minute but if nothing shows, please press the refresh (upper right).





(8) When you see your network, select the desired connection.


23. Connecting the app with SugarCube on Wi-Fi



(9) Next, enter the password for your WiFi network.



(10) The app has connected successfully with the SugarCube and will now jump to the main screen.




(11) The connection process is complete and you are ready to go.



Using **Wired Ethernet** with SugarCube

24. Connecting Your SC-1 via Wired Ethernet



If you would like to use the SugarCube app to control your SC-1 over wired Ethernet, plug in the cable to the back panel as seen above and follow the steps on the next few pages.


NOTE: THE SUGARCUBE SC-1 IS FULLY FUNCTIONAL BY MEANS OF THE FRONT PANEL CONTROLS WITHOUT CONNECTING TO ANY NETWORK.

Apple iOS & Android


25. Connecting the app with SugarCube on wired Ethernet



(1) App is loading




(2) App is searching for SugarCubes on the LAN




(3) App has found a SugarCube and will now initiate a connection.


26. Connecting the app with SugarCube on wired Ethernet



(4) App needs you to press the knob on the front panel.



(5) App needs you to enter the pair code displayed on the front panel display then touch 'PAIR'.



(6) App is linked to SugarCube and ready for use.


NOTE: as of version 2.1 software, you can just enter **5123** without needing to get a pair code.




Manually Connecting to SugarCube

Using the SugarCube's IP Address


27. Manually Connecting the App with SugarCube Using IP Address




(1) If, for any reason, you wish to manually connect to your SugarCube touch the menu button in the lower right of the screen.



(2) Select 'Configure Manual IP'.




(3) You will then see a window to enter the IP address of the SugarCube. This address can be seen by pressing and holding 'Bypass' for a few seconds.




(4) Enter the IP address as displayed on the front panel display.


28. Manually Connecting the App with SugarCube Using IP Address



(5) App need you to press the knob on the front panel.



(6) App needs you to enter the pair code displayed on the front panel display then touch 'PAIR'.



(7) App is linked to SugarCube and ready for use.

NOTE: as of version 2.1 software, you can just enter **5123** without needing to get a pair code.


Controlling SugarCube via the App

3. Basic SugarCube Functions


Apple iOS & Android




29. Main Control Page



(1) App matches the front panel controls. In this example the SugarCube is in 'Bypass' mode.




(2) You can select 'Click Remover' to engage the click removal process, same as pushing 'In' on the front panel.




(3) You can select 'Click Mon' to listen to the level of clicks and pops while the LP plays. In this mode the music is suppressed to better hear the noise.


30. Setting Click Removal Strength



(4) With app or front panel set to 'Click Monitor'...



(5) You can adjust the slider to listen to the result of setting 'Strength'.



(6) You will generally find that a setting of '5' or '6' is all you need for all but the most damaged LPs.


Controlling SugarCube via the App

4. Input Level Sensitivity


Apple iOS & Android




31. Audio Setup



(1) Select the upper left 'Mode' menu




(2) Select 'Settings', then



(3) For almost all systems, this setting is perfect, the factory default setting.

32. Audio Setup

IMPORTANT NOTE: The output of the SugarCube will always equal the input. Changes in settings here will result in NO change in volume of your system.



Select this mode ONLY if you know you have a very-low-output cartridge (and you have to turn up the volume higher than normal on your system.) If the 'Clipping' alert is seen, go back to 'Normal Output'.

Almost all systems should operate here (factory default).

If the 'Clipping' alert is seen on the app AND already in 'Normal Output' mode (above), select this.

If the 'Clipping' alert is seen on the app AND already in 'High Output' mode (above), select this.

Controlling SugarCube via a Web Browser

5. Google Chrome

MacOS, Windows
Linux, iOS, or Android



33. Controlling the SugarCube from a Web Browser

Finding the IP address of your SugarCube SC-1



2

Press and hold 'BYPASS' for 3 to 5 seconds

Your SugarCube will then enter a display mode where it will show you its IP address, among other information.



3

You will use an address that looks like this example. It usually will start with 192 or with 10.



1

Plug in an Ethernet Cable

If you wish to use WiFi, before connecting the unit to your sound system, take the SugarCube to your router and plug in a wired Ethernet cable then consult diagram A4.

34. Controlling the SugarCube from a Web Browser

Entering the IP address with additional information into the browser



Important Note: the SugarCube web interface is not compatible with the older Internet Explorer web browser from Microsoft.



We recommend Chrome.

(1) Type the SugarCube's IP address into the **address bar** then add a colon ':' and '5123'.
PLEASE NOTE: the '5123' is a fixed port number and NOT the serial number of your SugarCube.

(2) Press 'Enter' and the SugarCube webpage will appear in the browser.

35. Controlling the SugarCube from a Web Browser

Pairing with the SugarCube



(1) You will see a screen appearing in your browser to accept a pairing code.


(2) Press and release the 'PAIR' button on the back panel.

(3) Enter the four digit pairing code displayed on the SC-1 display and click on 'Pair'.

*NOTE: as of version 2.1 software, you can just enter **5123** without needing to get a pair code.*


36. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 1 of 4



SugarCube SC-1
#1062
My SugarCube

[ClickRemove control](#)
[Audio tuning \(test record and levels\)](#)
[Wifi Setup](#)
[Control display](#)
[Support](#)



State: normal
Ssid: <Not Configured>
Info: disconnected

SSID
Password

Site survey

	SSID	Signal	Channel	Security	Access Points
Use	1qa2ws3ed	87%	6 40	WPA2	2
Use	219Guest	20%	11	WPA1 WPA2	1
Use	219SecureIoT	34%	6	WPA1 WPA2	1
Use	219SecureWireless	30%	6	WPA1 WPA2	1
Use	BlueCart Wifi	30%	6	WPA2	1
Use	BlueCart Wifi - Guest	50%	6	WPA2	1
Use	SmugMug	84%	40	WPA2	1
Use	SmugMugs	84%	40	WPA2	1
Use	sweetvinyl	100%	9 48	WPA2	4
Use	Tap Guest	34%	11	WPA1 WPA2	1



Model: SC-1
veetVinyl LLC
Mt View, Calif

Ethernet port, USB port (with WiFi stick), DC In, On / Off switch, Pair button, 12v / 2 amp center +, Made In U.S.A.


(1) If wired Ethernet is not available in your sound room, then take the SugarCube to your router just for these WiFi setup steps.

(2) You need both Ethernet and the WiFi stick plugged into the SC-1.

(3) Find your WiFi name on the list of SSIDs.

37. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 1 of 4



(1) If wired Ethernet is not available in your sound room, then take the SugarCube to your router just for these WiFi setup steps.

(2) You need both Ethernet and the WiFi stick plugged into the SC-2 Mini.

(3) Press Site Survey to find your SSID.

38. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 2 of 4

State: normal

Ssid: <Not Configured>

Info: disconnected

SSID

Password

Site survey

	SSID	Signal	Channel	Security	Access Points
Use	1qa2ws3ed	87%	6 40	WPA2	2
Use	219Guest	20%	11	WPA1 WPA2	1
Use	219SecureIOT	34%	6	WPA1 WPA2	1
Use	219SecureWireless	30%	6	WPA1 WPA2	1
Use	BlueCart Wifi	30%	6	WPA2	1
Use	Cart Wifi - Guest	50%	6	WPA2	1
Use	SmugMug	84%	40	WPA2	1
Use	SmugMugs	84%	40	WPA2	1
Use	sweetvinyl	100%	9 48	WPA2	4
Use	Tap Guest	34%	11	WPA1 WPA2	1

(4) Please select your network by clicking on the 'Use' button next to your SSID.

Info: disconnected

SSID

Password


Site survey

	SSID	Signal	Channel	Security	Access
Use	1qa2ws3ed	80%	6 40	WPA2	
Use	219Guest	44%	11	WPA1 WPA2	
Use	219SecureIOT	30%	6	WPA1 WPA2	
Use	219SecureWireless	34%	6	WPA1 WPA2	
Use	BlueCart Wifi	34%	6	WPA2	
Use	SmugMug	87%	6 40	WPA2	


(5) Next, enter the password for your WiFi then click on 'Connect.'

39. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 3 of 4



(6) The system will indicate that it is connecting to your WiFi.




(7) Once connected, you will now see, scrolling by, both your new WiFi address (w) and your currently wired Ethernet IP address (e). Remember, you are currently communicating with the SugarCube via the wired IP address.

40. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 4 of 4



(9) So, when you disconnect the wire, your browser will no longer communicate (of course). You will have to change the IP address in your browser, in this example, to the WiFi address ending in '.118'. (Once the wire is disconnected, the front panel display will show only the WiFi IP address.)




(10) Usually, you need only change the last group of numbers and press 'Enter', and you should reconnect (sometimes you may have to re-enter the entire address).


(11) Please note, if your SugarCube cannot connect to your WiFi, contact support@sweetvinyl.com with the details of your system (WiFi make and model and the serial number of your SugarCube.)

41. Controlling the SugarCube from a Web Browser

Controlling the SugarCube



(1) Click on 'Repair'




(2) Functions available mirror the front panel controls. A change here is reflected on the front panel and a change on the front panel changes the above.

42. Controlling the SugarCube from a Web Browser

Input Level Sensitivity


PLEASE NOTE: unless you see a '**CLIPPING**' warning appear while using your SugarCube, you do **NOT** need to change the audio setup.

If you do see a clipping warning then follow the steps on the next three pages:



43. Audio Setup

IMPORTANT NOTE: The output of the SugarCube will always equal the input. Changes in settings here will result in NO change in volume on your system.



Select this mode **ONLY** if you know you have a very-low-output cartridge (and you have to turn up the volume higher than normal on your system.) If the 'Clipping' alert is seen, go back to 'Normal Output'.


Almost all systems should operate here (factory default).

If the 'Clipping' alert is seen on the app **AND** already in 'Normal Output' mode (above), select this.

If the 'Clipping' alert is seen on the app **AND** already in 'High Output' mode (above), select this.

44. Input Level Sensitivity

IMPORTANT NOTE: The output of the SugarCube will always equal the input. Changes in settings here will result in NO change in volume on your system.



NOTE: if this appears when, for example, you just dropped the needle on an LP, just touch it and it will go away.

However: if you see this warning while an LP is playing, then move down a level.

SugarCube Software Update Notes

Appendix A



A1. Updates, Future Releases, Mobile Apps

The SugarCube automatically updates when connected to the Internet

The SugarCube periodically checks the servers at SweetVinyl for software updates. These updates will resolve operating issues that are identified and provide greater functionality. In order for updates to occur the SugarCube must have a connection to the Internet and be left on without audio passing through it for more than one hour. We recommend leaving the SugarCube on periodically without use if you are in the habit of turning it off and making sure you have an Internet connection via WiFi or Ethernet.

My SugarCube is stuck trying to boot

Occasionally a SugarCube will fail to boot and will be stuck with a fuzzy screen or message with blinking lights for more than a few minutes. If this happens, the SugarCube has encountered an error during its boot process and needs your help to get unstuck. Please power it off – wait 10 seconds – and power it on. If this happens more than a few times in a row please contact support@sweetvinyl.com.

Why is the SugarCube App not in the iOS App or Google Play Store?

SweetVinyl's iOS and Android apps are continued to be developed and will be released soon. If you have a SugarCube and would like to try out the App please email support@sweetvinyl.com and include the following information:

iOS: Please tell us the email associated with the iOS App Store

Android: Please tell us the email associated with your Android device

After we receive this information we will submit a request to add you to the approved user list at Apple and/or Google and provide you additional information. We submit these requests in bulk so please allow a few days to process.


Technical Specs

Appendix B




SugarCube SC-1 Mechanical:

Front View



Side View



Technical Specifications

- Line In maximum level = +20 dBu (approx. 7.7Vrms or 22Vp-p)
- Line Out level = Line In level
- THD+N = 0.0025% (A-weighted)
- Frequency Response = 25Hz to 60kHz +/-0.1dB
- Frequency Response = 15Hz to 75kHz -3dB
- DC in = 12 volts, center-pin positive
- Average Power Dissipation = 9 watts

Support

Thank you for purchasing this SugarCube product.

Please contact customer support at: info@sweetvinyl.com

Trademarks

SweetVinyl™ and SugarCube™ are trademarks of SweetVinyl Inc. Any non-SweetVinyl trademarks are used for reference purposes only.

Compliance

For the current EU Declaration of conformity, visit:
<http://support.sweetvinyl.com/regulatory>

For regulatory compliance information in North America, visit:
<http://support.sweetvinyl.com/regulatory>

SweetVinyl Inc

57 E. Evelyn Ave
Mountain View, CA 94041



March 2020