



Help: Comprehensive Repair

Click Sensitivity: slider sets how aggressively the algorithm removes clicks and pops. A little goes a long way, so, usually no more than four or five is all you need. (Same control as front panel knob.)

Monitor Clicks: Listen to just the click and pops. If you increase sensitivity too far you might start hearing sound other than clicks and pops (parts of the underlying music.) If so, dial back the sensitivity.

Start: The Noise Reduction (**NR**) feature requires a sample of the record or tape audio without music. For records, the best place is the lead-in groove. So, press start and then drop the needle. In five seconds or so, the noise algorithm is ready to reduce noise. When ready, the button turns to '**Running**'.

If you have a set of records that are from the same label and period, the surface noise is likely to be the same. You do not need to stop and start NR for each disc.

Noise Reduction: slider sets the amount of noise removed. Up to about -10dB you will hear little or no change in sound quality but a very large reduction in background noise. Beyond -10dB the algorithm starts to take away some music. If you have a really noisy recording, the trade-off may be worth it.

EQ: there are eleven equalization settings for pre-RIAA LPs and 78's. When NR is off, the EQ curve can be changed. EQ can run independently of NR by simply moving Noise Reduction slider all the way to the left to 0dB which disables it. Note: once NR is started, EQ can not be turned on or off until NR is stopped. Also note, when EQ menu is set to RIAA, the EQ is disabled and will not run (nothing to do!)