

WELCOME TO SUGARCUBE™



Thank You for purchasing the
SugarCube SC-2

Your experience of high-end audio
is about to get a lot sweeter

These pages provide an overview of
the set-up and control of the SC-2


Users with questions
please contact:
support@sweetvinyl.com



1. Unpacking Your SugarCube



SugarCube SC-2 unit



AC Power Adapter
12v/2A



Wifi USB Adapter



Please download the **SugarCube App** from your mobile device's app store to control your **SugarCube** remotely.

The SugarCube App will use this adapter or you can use a wired Internet connection if available.

2. The SC-2 Front Panel Controls



HEADPHONE JACK, VOLUME, MUTE

Headphone amp operates independently and does not affect the level of the line in / out audio.

BYPASS

When pressed and the LED is lit, an internal relay has shunted the **LINE IN** directly to **LINE OUT** completely bypassing all internal circuitry.

STRENGTH

Controls the strength of the click and pop detection and removal process. Almost all LPs will sound great at a setting of 5 or 6.

Note: we recommend that you do NOT adjust **STRENGTH** all the way to 10, you will rarely need this much. Less is more.

CLICK REMOVE 'IN'

Push on, push off: when the LED is lit, SugarCube is processing audio to remove clicks and pops (the **BYPASS** LED will go out.)

CLICK MONITOR

When pressed and the LED is lit, the SugarCube suppresses the music so that you can better hear the clicks and pops. This helps set the **STRENGTH** level for particularly noisy LPs.

STATUS

Green when storage pugged in and ready. Blinks red while recording.


USB3

Plug in USB stick or drive
To record & playback
Storage.

RECORD

Press to start recording
Press to stop.

3. The SC-2 Back Panel




Connecting SugarCube to Your Sound System

PLEASE BE SURE ALL
EQUIPMENT IS TURNED
OFF BEFORE ATTEMPTING
INSTALLATION




4. Connecting Your SC-2



Connecting the supplied AC adaptor.

1. Plug your SugarCube power adapter into a power source.
2. Please only use the supplied 5 volt adaptor or one that we approve.

4. Connecting Your SC-2




Connecting in series between a phono pre-amp and line stage (pre-amp)

1. Plug your SugarCube power adapter into a power source.
2. Connect the output of your phono pre-amp to the **LINE IN** of the SC-2.
3. Connect the **LINE OUT** of the SC-2 to an appropriate line-level input of your line-stage/pre-amp.

NOTE: DO NOT CONNECT THE **LINE OUT** OF THE SC-2 TO THE PHONO INPUT ON YOUR EQUIPMENT.

5. Connecting Your SC-2




Connecting in series between a pre-amp, with phono input, and power amp

1. Plug your SugarCube power adapter into a power source.
2. Connect the output of your pre-amp to the **LINE IN** of the SC-2.
3. Connect the **LINE OUT** of the SC-2 to the input of your power amp.

6. Connecting Your SC-2

Integrated Amp: using the 'tape loop'




Connecting to an integrated amplifier via Aux In/Out (or Rec In/Out)

1. Plug your SugarCube power adapter into a power source.
2. Connect **AUX OUT** (or REC OUT) of your integrated amp (or processor) to the **LINE IN** of the SC-2
3. Connect **LINE OUT** of the SC-2 to **AUX IN** (or **REC IN**) of your integrated amp or processor.

NOTE: DO NOT CONNECT THE **LINE OUT** OF THE SC-2 TO THE **PHONO INPUT** ON YOUR EQUIPMENT.

9. Connecting Your SC-2


Integrated Amp **WITHOUT** an AUX OUT/IN or REC OUT/IN or PRE-OUT / PWR IN



Many contemporary integrated amplifiers no longer have what was known as a 'tape loop' (back in the day of the cassette or reel-to-reel tape). Also, most modern home theatre processors that do have what are called 'effects loops' will not send audio from a phono input through the loop. In these cases there is not was to connect to SugarCube directly to these devices.

The solution is to add a phono stage (pre-amp) between your turntable and the SugarCube. Then connect the **LINE OUT** of the SugarCube to any available **input** on the integrated amp (except for the phono input, of course.)

10. Connecting Your SC-2




For turntables with a built-in phono pre-amp, be sure to set the **PHONO/LINE** switch to **LINE** before plugging into the SugarCube.

- ## Directly connecting a line-level output from your turntable
1. Plug your SugarCube power adapter into a power source.
 2. Connect the turntable with a built-in phono pre-amp to **LINE IN**.
 3. Be sure the turntable is set to **LINE** not **PHONO**.
 4. Connect the **LINE OUT** of the SugarCube to any line-level input of your line stage, pre-amp, or integrated amp.

NOTE: SORRY TO BE A "BROKEN RECORD" ;) BUT DO NOT CONNECT THE
LINE OUT OF THE SC-2 TO THE PHONO INPUT ON YOUR EQUIPMENT.

11. Connecting Your SC-2 to a LAN or WiFi



If you would like to use the SugarCube app to control your SugarCube SC-2, please connect **EITHER** the WiFi adapter supplied with your SugarCube **OR** plug into a wired connection. (PLEASE NOTE: IF YOU INTEND TO CONTROL THE SUGARCUBE VIA A WEB BROWSE VIA WIFI, YOU WILL NEED BOTH CONNECTED JUST FOR SETUP ONLY, SEE NEXT SECTION.)

- When using the WiFi adapter, once the SugarCube is powered on and operational, use the SugarCube app to set-up the WiFi connection by following the instructions on the app (iOS and Android operate similarly).
- When connecting via wired Ethernet, you need only launch the SugarCube app and it will locate and connect to your SugarCube when the device running the app is on the same network with the SugarCube.

NOTE: THE SUGARCUBE SC-2 IS FULLY FUNCTIONAL BY MEANS OF THE FRONT PANEL CONTROLS WITHOUT CONNECTING TO ANY NETWORK.

13. Starting Up Your SugarCube



(1) SugarCube just powered on



(2) SugarCube is ready to go (please expect about three minutes to ready.)




(3) Hold the 'Bypass' button for a few seconds to see LAN address (and WiFi SSID if using wireless.)

Please note:

When you power up your SugarCube, it will take about three minutes to complete its startup procedures. During this time, the LCD display will show snow (our humorous tip of the hat to the old days of analog TV). There is nothing wrong with your unit. We apologize for the wait but we have some seriously sophisticated software loading and it simply takes additional time. When you hear the results of our efforts, you will agree that it was worth the wait.

12. The Pair Button



In the course of setting up the connection between the SugarCube SC-2 and the SugarCube app, the app will prompt you to press and release the **PAIR** button, then enter the four-digit code on the SC-2 display.

This button is also used when setting up WiFi for the SugarCube SC-2 for use with the SugarCube app. When configuring WiFi, you will be instructed to press and HOLD the **PAIR** button for 5 SECONDS. The display of the SC-2 will announce that it is in WiFi setup mode, then continue setup on your mobile device, tablet, or desktop.

Setting Up SugarCube Mobile App

2. Connecting to the SugarCube

Apple iOS and Android
Guide






Using an Apple Mobile Device (Apple iOS)

13. Items needed to set up Apple to control SugarCube:

1. iPhone, iPad, Touch.
2. Network with WiFi your Apple device can communicate with and that can be connected to your SugarCube with WiFi or wired Ethernet.
3. From the Apple App Store, you will be able to download the 'SugarCube' app to your Apple mobile device. (Look for: SugarCube by SweetVinyl.)
4. The WiFi dongle supplied with your SugarCube.

Note: If you plan to use **wired Ethernet**, there is no need to plug in the WiFi adapter to the SugarCube; please skip to **Section 1.3** and follow the instructions there.


14. Connecting the app with SugarCube on Wi-Fi



(1) Launch the SugarCube app




(2) App is loading




(3) App is searching for SugarCubes already setup on the LAN if any. For the first time user, nothing will be found, of course.


15. Connecting the app with SugarCube on Wi-Fi



(4) No SugarCube is found so the app offers the option to run WiFi setup.




(5) The user is instructed to press and hold the front panel knob for 5 seconds to put the SugarCube into 'WiFi Setup Mode' which will be displayed on the front panel.




(6) The instructions direct the user to press the 'Home' key to get back to the 'Home' screen and then launch 'Setup'.

16. Connecting the app with SugarCube on WiFi




(7) When in 'Settings', select 'Wi-Fi'




(8) Select 'SugarCube_nnnn', (whatever number appears after 'SugarCube_' is your device's serial number)

The password is: **SugarCube**




(9) With the 'SugarCube_nnnn' selected, your SugarCube is now temporarily acting as an access point.


17. Connecting the app with SugarCube on Wi-Fi



(10) Relaunch the SugarCube app



(11) Select the WiFi network that you wish to use



(12) Enter the WiFi password for your network


18. Connecting the app with SugarCube on Wi-Fi



(13) The app will now complete the connection to your WiFi network and also do a little housekeeping.




(14) The app will then display the SugarCube(s) found on your network. Select the appropriate device.




(15) If asked to 'Pair', press the 'front panel knob' of the SugarCube.

19. Connecting the app with SugarCube on Wi-Fi



(16) Enter the pairing code displayed on the SugarCube front panel and then press 'Pair' on the app screen.



(17) You will then see the 'Control' screen and you are done, congratulations!

NOTE: as of version 2.1 software, you can enter **5123** without needing to get a pair code.



Using an **Android** Mobile Device

20. Items needed to set up Android device to control SugarCube:


1. Android phone or tablet.
2. Network with WiFi your Android device can communicate with and that can be connected to your SugarCube with WiFi or wired Ethernet.
3. Download the Android App from the Google Play Store.
(Look for: SugarCube by SweetVinyl.)
4. The WiFi dongle supplied with your SugarCube or a wired Ethernet cable from a port on your router.

Note: If you plan to use wired Ethernet, there is no need to plug in the WiFi adapter to the SugarCube; please skip to page 1.10 and follow the instructions.


21. Connecting the app with SugarCube on Wi-Fi




(1) App is loading



(2) App is searching for SugarCubes on the LAN




(3) No SugarCube is found so the app offers the option to run WiFi setup.




(4) User taps 'WiFi Setup' to start the process.


22. Connecting the app with SugarCube on WiFi




(5) Next, press and hold the pairing button (on the rear panel) for 5 seconds as instructed.



(6) After this, your SugarCube will be configured as an access point and display its SSID (e.g. SugarCube_110) In this screen the app has now connected to it automatically. The password is: **SugarCube**




(7) Next, the SugarCube will find your available WiFi connections. This could take a minute but if nothing shows, please press the refresh (upper right).



(8) When you see your network, select the desired connection.

23. Connecting the app with SugarCube on Wi-Fi



(9) Next, enter the password for your WiFi network.

(10) The app has connected successfully with the SugarCube and will now jump to the main screen.

(11) The connection process is complete and you are ready to go.

NOTE: as of version 2.1 software, you can enter **5123** without needing to get a pair code.



Using **Wired Ethernet** with SugarCube

24. Connecting Your SC2-Mini via Wired Ethernet




If you would like to use the SugarCube app to control your SugarCube SC-2 Mini over wired Ethernet, plug in the cable to the back panel as seen above and follow the steps on the next few pages.

NOTE: THE SC-2 Mini's basic functions of click and pop removal are fully available via front panel controls. However, the recording functions, other than start and stop recording, are only available via a table or laptop run a Google Chrome browser.


25. Connecting the app with SugarCube on wired Ethernet



(1) App is loading




(2) App is searching for SugarCubes on the LAN




(3) App has found a SugarCube and will now initiate a connection.


26. Connecting the app with SugarCube on wired Ethernet



(4) App needs you to press the knob on the front panel.



(5) App needs you to enter the pair code displayed on the front panel display then touch 'PAIR'.



(6) App is linked to SugarCube and ready for use.


NOTE: as of version 2.1 software, you can enter **5123** without needing to get a pair code.




Manually Connecting to SugarCube

Using the SugarCube's IP Address


27. Manually Connecting the App Using IP Address




(1) If, for any reason, you wish to manually connect to your SugarCube touch the menu button in the lower right of the screen.



(2) Select 'Configure Manual IP'.




(3) You will then see a window to enter the IP address of the SugarCube. This address can be seen by pressing and holding 'Bypass' for a few seconds.




(4) Enter the IP address as displayed on the front panel display.


28. Manually Connecting the App Using IP Address



(5) App need you to press the knob on the front panel.



(6) App needs you to enter the pair code displayed on the front panel display then touch 'PAIR'.



(7) App is linked to SugarCube and ready for use.

NOTE: as of version 2.1 software, you can enter **5123** without needing to get a pair code.


Controlling SugarCube via the App

3. Basic SugarCube Functions


Apple iOS & Android




29. Main Control Page



(1) App matches the front panel controls. In this example the SugarCube is in 'Bypass' mode.




(2) You can select 'Click Remover' to engage the click removal process, same as pushing 'In' on the front panel.




(3) You can select 'Click Mon' to listen to the level of clicks and pops while the LP plays. In this mode the music is suppressed to better hear the noise.


30. Setting Click Removal Strength



(4) With app or front panel set to 'Click Monitor'...



(5) You can adjust the slider to listen to the result of setting 'Strength'.



(6) You will generally find that a setting of '5' or '6' is all you need for all but the most damaged LPs.

Controlling SugarCube via a Web Browser

4. Google Chrome

MacOS, Windows
Linux, iOS, or Android



31. Controlling the SugarCube from a Web Browser

Finding the IP address of your SugarCube SC-2 Mini



2

Press and hold 'BYPASS' for 3 to 5 seconds

Your SugarCube will then enter a display mode where it will show you its IP address, among other information.

You will use an address that looks like this example. It usually will start with 192 or with 10.

3



1

Plug in an Ethernet Cable

If you wish to use WiFi, before connecting the unit to your sound system, take the SugarCube to your router and plug in a wired Ethernet cable then consult diagram A4.

32. Controlling the SugarCube from a Web Browser

Entering the IP address with additional information into the browser




(1) Type the SugarCube's IP address into the **address bar** then add a colon ':' and '5123'.
PLEASE NOTE: the '5123' is a fixed port number and NOT the serial number of your SugarCube.

(2) Press 'Enter' and the SugarCube webpage will appear in the browser.

33. Controlling the SugarCube from a Web Browser

Pairing with the SugarCube




1



2

(1) You will see a screen appearing in your browser to accept a pairing code.

(2) Press and release the knob on the front panel.



3



(3) Enter the four-digit pairing code displayed on the SC-2 display and click on 'Pair'.

*NOTE: as of version 2.1 software, you can just enter **5123** without needing to get a pair code.*

34. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 1 of 4

The image is a composite illustrating the WiFi setup process for the SugarCube SC2-Mini. It features two browser screenshots, a physical device, and three numbered instructions.

Browser Screenshot 1 (localhost:5123): Shows the main interface with a sidebar menu. The 'Settings' button is highlighted with a blue arrow.

Browser Screenshot 2 (localhost:5123/newsettings): Shows the 'Settings' page. The 'Wifi Setup' button is highlighted with a blue arrow. The 'Info' section shows 'State: normal', 'SSID: None', and fields for 'SSID' and 'Password'. A 'Connect' button is below. The 'Site survey' section shows 'No wifi seen.' and a 'Refresh' button, which is also highlighted with a blue arrow. A callout box states: 'WiFi setup is where you link your SC-2 to your home WiFi if you are not using wired Ethernet to the SC-2.'


Physical Device: A black SugarCube SC2-Mini device is shown. A USB WiFi stick is plugged into the USB port, and an Ethernet cable is plugged into the LAN port. The device has 'Model: SC2-Mini' and 'Made in U.S.A.' printed on it.

Instructions:


- (1) If wired Ethernet is not available in your sound room, then take the SugarCube to your router just for these WiFi setup steps.
- (2) You need both Ethernet and the WiFi stick plugged into the SC-2 Mini.
- (3) Press Site Survey to find your SSID.

35. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 2 of 4



(4) Please select your network by clicking on the 'Use' button next to your SSID.



(5) Next, enter the password for your WiFi then click on 'Connect.'

36. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 3 of 4

Press the pair button on your SugarCube for at least 5 seconds to start the setup wifi network.

State: connect

Ssid: s\ **<your wifi>**

Info: connecting (getting IP configuration)

SSID sw **<your wifi>**

Password **<password>**

Site survey

	SSID	Signal	Channel	Security	Access Points
Use	1qa2ws3ed	87%	6 40	WPA2	2
Use	219Guest	20%	11	WPA1 WPA2	1
Use	219SecureIoT	34%	6	WPA1 WPA2	1
Use	219SecureWireless	30%	6	WPA1 WPA2	1
Use	BlueCart Wifi	30%	6	WPA2	1
Use	BlueCart Wifi - Guest	50%	6	WPA2	1
Use	SmugMug	84%	40	WPA2	1
Use	SmugMugs	84%	40	WPA2	1

WiFi IP address

Your WiFi SSID

Wired IP address




(6) The system will indicate that it is connecting to your WiFi.

(7) Once connected, you will now see, scrolling by, both your new WiFi address (w) and your currently wired Ethernet IP address (e). Remember, you are currently communicating with the SugarCube via the wired IP address.

37. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 4 of 4




(9) So, when you disconnect the wire, your browser will no longer communicate (of course). You will have to change the IP address in your browser, in this example, to the WiFi address ending in '.118'. (Once the wire is disconnected, the front panel display will show only the WiFi IP address.)

(10) Usually, you need only to change the last group of numbers and press 'Enter', and you should reconnect (sometimes you may have to re-enter the entire address).


(11) Please note, if your SugarCube cannot connect to your WiFi, contact support@sweetvinyl.com with the details of your system (WiFi make and model and the serial number of your SugarCube.)

38. Controlling the SugarCube from a Web Browser

Controlling the SugarCube



(1) Click on 'Repair'




(2) Functions available mirror the front panel controls. A change here is reflected on the front panel and a change on the front panel changes the above.

39. Controlling the SugarCube from a Web Browser

Input Level Sensitivity


PLEASE NOTE: unless you see a '**CLIPPING**' warning appear while using your SugarCube, you do **NOT** need to change the audio setup.

If you do see a clipping warning then follow the steps on the next three pages:



40. Audio Setup

IMPORTANT NOTE: The output of the SugarCube will always equal the input. Changes in settings here will result in NO change in volume on your system.



Select this mode **ONLY** if you know you have a very-low-output cartridge (and you have to turn up the volume higher than normal on your system.) If the 'Clipping' alert is seen, go back to 'Normal Output'.


Almost all systems should operate here (factory default).

If the 'Clipping' alert is seen on the app **AND** already in 'Normal Output' mode (above), select this.

If the 'Clipping' alert is seen on the app **AND** already in 'High Output' mode (above), select this.

41. Input Level Sensitivity

IMPORTANT NOTE: The output of the SugarCube will always equal the input. Changes in settings here will result in NO change in volume on your system.



NOTE: if this appears when, for example, you just dropped the needle on an LP, just touch it and it will go away.

However: if you see this warning while an LP is playing, then move down a level.

Controlling SugarCube via the a Web Browser

Appendix A

MacOS, Windows
Linux, iOS, or Android



A1. Controlling the SugarCube from a Web Browser


Finding the IP address of your SugarCube SC-2



Press and hold 'BYPASS' for 3 to 5 seconds

Your SugarCube will then enter a display mode where it will show you its IP address, among other information.

You will use an address that looks like this example. It usually will start with 192 or with 10.



Plug in an Ethernet Cable

If you wish to use WiFi, before connecting the unit to your sound system, take the SugarCube to your router and plug in a wired Ethernet cable then consult diagram **A4**.

A2. Controlling the SugarCube from a Web Browser

Entering the IP address with additional information into the browser



Important Note: the SugarCube web interface is not compatible with the older Internet Explorer web browser from Microsoft.


We recommend Safari, Firefox, or Chrome.

(1) Type the SugarCube's IP address into the **address bar** then add a colon ':' and '5123'. PLEASE NOTE: the '5123' is a fixed port number and NOT the serial number of your SugarCube.

(2) Press 'Enter' and the SugarCube webpage will appear in the browser.

A3. Controlling the SugarCube from a Web Browser

Pairing with the SugarCube



(1) You will see a screen appearing in your browser to accept a pairing code.

2

(2) Press and release the 'PAIR' button on the back panel.

(3) Enter the four digit pairing code on the display and click on 'Pair'.

A4. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 1 of 4

The image is a composite showing the steps for setting up WiFi on the SugarCube SC-2. It includes a screenshot of the main web interface, a photo of the hardware with a USB WiFi stick and Ethernet cable connected, and a screenshot of the WiFi configuration page.

SugarCube SC-2 #313 My SugarCube

ClickRemove control
Audio tuning (test record and levels)
Wifi Setup
Album recog
Recording
Control display
Support

State: normal
Ssid: <Not Configured>
Info: disconnected
SSID
Password
Connect

Site survey

	SSID	Signal	Channel	Security	Access Points
Use	1qa2ws3ed	87%	6 40	WPA2	2
Use	219Guest	20%	11	WPA1 WPA2	1
Use	219SecureIoT	34%	6	WPA1 WPA2	1
Use	219SecureWireless	30%	6	WPA1 WPA2	1
Use	BlueCart Wifi	30%	6	WPA2	1
Use	BlueCart Wifi - Guest	50%	6	WPA2	1
Use	SmugMug	84%	40	WPA2	1
Use	SmugMugs	84%	40	WPA2	1
Use	sweetvinyl	100%	9 48	WPA2	4
Use	Tap Guest	34%	11	WPA1 WPA2	1


(1) If wired Ethernet is not available in your sound room, then take the SugarCube to your router just for these WiFi setup steps.

(2) You need both Ethernet **AND** the WiFi stick plugged into the SC-2.


(3) Find your WiFi name on the list of SSIDs.

A5. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 2 of 4



(4) Please select your network by clicking on the 'Use' button next to your SSID.



(5) Next, enter the password for your WiFi then click on 'Connect.'

A6. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 3 of 4

Press the pair button on your SugarCube for at least 5 seconds to start the setup wifi network.

State: connect

Ssid: s\ <your wifi>

Info: connecting (getting IP configuration)


SSID

Password

Site survey

	SSID	Signal	Channel	Security	Access Points
Use	1qa2ws3ed	87%	6 40	WPA2	2
Use	219Guest	20%	11	WPA1 WPA2	1
Use	219SecureIoT	34%	6	WPA1 WPA2	1
Use	219SecureWireless	30%	6	WPA1 WPA2	1
Use	BlueCart Wifi	30%	6	WPA2	1
Use	BlueCart Wifi - Guest	50%	6	WPA2	1
Use	SmugMug	84%	40	WPA2	1
Use	SmugMugs	84%	40	WPA2	1

(6) The system will indicate that it is connecting to your WiFi.



(7) Once connected, you will now see both your new WiFi address (w) and your currently wired Ethernet IP address (∞). Remember, you are currently communicating with the SugarCube via the wired IP address.


A7. Controlling the SugarCube from a Web Browser

Setting up WiFi (in place of wired Ethernet), 4 of 4



(9) So, when you disconnect the wire, your browser will no longer communicate (of course). You will have to change the IP address in your browser, in this example, to the WiFi address ending in '.118'. (Once the wire is disconnected, the front panel display will show only the WiFi IP address.)


(11) Please note, if your SugarCube cannot connect to your WiFi, contact support@sweetvinyl.com with the details of your system (WiFi make and model and the serial number of your SugarCube.)




(10) Usually, you need only change the last group of numbers and press 'Enter', and you should reconnect (sometimes you may have to re-enter the entire address).

A8. Controlling the SugarCube from a Web Browser

Controlling the SugarCube





(1) Click on 'Click Remove Control.'



(2) Functions available mirror the front panel controls. A change here is reflected on the front panel and a change on the front panel changes the above.

A9. Controlling the SugarCube from a Web Browser

Audio setup with the test record (1 of 3)




(1) Before playing the test LP, please play any record you like at the volume at which you normally listen. You need spend no more than 30 seconds doing this as long as the volume is set to where you normally listen. Then, do not move the volume control during the test.


(2) Select 'Audio Tuning' from the menu. Make sure that your SugarCube is not in 'Bypass'.

A12. Controlling the SugarCube from a Web Browser

Sending SC-2 system data (logs) to 'Support'



(1) Click on 'Support' on the main menu



(2) Click on 'Submit my logs.'

Recording with the SC-2 (demo)

Appendix B

NOTE: (1) Fully functioning recording and playback software is under development and will be available soon. The features available now are partial but will allow you to do basic recording. Track splitting is not yet implemented.





B1. Recording in SC-2 Demo Mode

Inserting and Scanning USB Drive

Insert USB memory stick
or USB hard drive

Drive is being scanned

Drive is ready for recording



(1) Once inserted, please wait while the drive is being scanned. The yellow question mark indicates scanning in progress.



(2) When scanning is complete and ready for recording, a green checkmark will appear on the display.

Technical Specs

Appendix D



SugarCube SC-2 Mechanical:



Technical Specifications

- Line In maximum level = +20 dBu (approx. 7.7Vrms or 22Vp-p)
- Line Out level = Line In level
- THD+N = 0.0045% (A-weighted)
- Frequency Response = 25Hz to 60kHz +/-0.1dB
- Frequency Response = -3dB points at 15Hz and 75Hz
- DC in = 12 volts, centre-pin positive
- Average Power Dissipation = 9 watts

Support

Thank you for purchasing this SugarCube product.

Please contact customer support at: info@sweetvinyl.com

Trademarks

SweetVinyl™ and SugarCube™ are trademarks of SweetVinyl LLC. Any non-SweetVinyl trademarks are used for reference purposes only.

Compliance

For the current EU Declaration of conformity, visit:
<http://support.sweetvinyl.com/regulatory>

For regulatory compliance information in North America, visit:
<http://support.sweetvinyl.com/regulatory>

SweetVinyl, LLC

57 E. Evelyn Ave
Mountain View, CA 94041



November, 2017