

SUGARCUBE™

SugarCube SC2-svNR

What's New as of version 2.3-570+



SugarCube SC-2svNR

New Features/Changes

Below is a short list of changes in recent releases:

1. If background clicking is detected, please **press 'Bypass' twice** to clear the click removal buffers.
2. No more needed to **power-cycle** after an update. Your SugarCube will restart itself after an update and is ready to go.
3. Various bug fixes including internal USB pathway reworked and more stable.
4. Noise Reduction: obscure bug found and fixed, should now work as expected.
5. EQ settings should now work as expected whether with Noise Reduction or stand alone.
6. Software version number now displays on the main menu.
7. Note: changes/updates to recording can be found separately in 'What's New in Recording' help guide.

SugarCube SC-2svNR

New Features/Changes

Below is a short list of changes in this release:

1. New '**System**' tab added to the '**Settings**' page to control some system functions including how long the front panel display remains on, among other controls.
2. "**VU Meter**" added to the '**Settings**' page on '**Input Level**' tab.
3. New **Startup Screen** shows the SugarCube startup progress to know when it is ready to use after power on.
4. New requirement to **power cycle** the SugarCube when a new update is installed. You will see a message to announce a new download is ready and to please power off, count to 3, then back on to complete the update process.
5. When using **Noise Reduction**, the process now waits for the needle drop before sampling noise. So, no hurry, just **Start** the **Noise Reduction** process and it will wait for you to get to the turntable.

SugarCube SC2-svNR

New Features/Changes from the previous update:

1. **Changes to the recording system**, please see '**What's new with Recording.**'
2. **"Noise Reduce"** function has been added that reduces Gaussian noise but up to 18dB.
3. **"EQ"** function has been added to allow the selection of 12 different equalization settings based on the manufacturer of the record (prior to RIAA adoption.)
4. **"Help"** button will pop up a handy user guide to applying the new features.(preview on next page.)

SugarCube SC2-svNR

Help page:

Click Sensitivity: Sider sets how aggressively the algorithm removes clicks and pops. A little goes a long way, so, usually no more than four or five is all you need. (Same control as front panel knob.)

Monitor Clicks: Listen to just the click and pops. If you increase sensitivity too far you might start hearing sound other than clicks and pops (parts of the underlying music.) If so, dial back the sensitivity.

Start: The Noise Reduction (NR) feature requires a sample of the record or tape audio without music. For records, the best place is the lead-in groove. So, press start and then drop the needle. In five seconds or so, the noise algorithm is ready to reduce noise. When ready, the button turns to 'Running'.

If you have a set of records that are from the same label and period, the surface noise is likely to be the same. You do not need to stop and start NR for each disc.

Noise Reduction: Slider sets the amount of noise removed. Up to about -10dB you will hear little or no change in sound quality but a very large reduction in background noise. Beyond -10dB the algorithm starts to take away some music. If you have a really noisy recording, the trade-off may be worth it.

EQ: there are eleven equalization settings for pre-RIAA LPs and 78's. When NR is off, the EQ curve can be changed. EQ can run independently of NR by simply moving Noise Reduction slider all the way to the left to 0dB which disables it. Note: once NR is started, EQ can not be turned on or off until NR is stopped. Also note, when EQ menu is set to RIAA, the EQ is disabled and will not run (nothing to do!)