# **LAB 08 Requirement Description**

#### CCP Module

• Video Link: <u>Lab08: CCP Module- YouTube</u>

• HackMD Link: Lab08: CCP Module- HackMD

# • Lab requirements:

○ Basic(70%)


### Description:

Use RB0 as a motor control button, and then use it to control the motor rotation as follow:

- 1. Initial degree: 45°
- 2. When pressing the button, the motor will rotate 45° counterclockwise.
- 3. When the motor rotates to +45°, the direction of rotation will change to clockwise.
- 4. When the motor rotates back to  $-45^{\circ}$ , pressing the button again, do step  $2\sim$  step 4.

# Standard of grading:

- 1. Do not ignore CCP1CON <5:4> when setting the duty cycle.
- 2. C or assembly are both accepted.




### • Advanced(30%)

#### Description:

Use RB0 as a motor control button, and then use it to control the motor rotation as follow:

- 1. Initial degree: 90°
- 2. When pressing the button, the motor will rotate from  $-90^{\circ}$  to  $+90^{\circ}$ .
- 3. When the motor rotates to  $+90^{\circ}$ , set the degree of the motor to the initial state  $-90^{\circ}$
- 4. When pressing the button again, do step  $2 \sim$  step 4



set the degree to initial state

### Standard of Grading:


- 1. Do not set 90° and + 90° only. You should deal with each degree, which means you should increase CCPR1L: CCP1CON <5:4> one by one.
- 2. Do not ignore CCP1CON <5:4> when setting the duty cycle.
- 3. C or assembly are both accepted.

# o Bonus (20%)

#### Description:

Use RB0 as a motor control button, and then use it to control the motor rotation as follow:

- 1. Initial degree: 90°
- 2. When pressing the button, the motor will rotate from 90°to + 90° and then rotate back to 90°, rotating continuously.



# Standard of Grading:

- 1. Do not set -90° and +90° only. You should deal with each degree, which means you should increase CCPR1L: CCP1CON <5:4> one by one.
- 2. Do not ignore CCP1CON <5:4> when setting the duty cycle.
- 3. C or assembly are both accepted.

#### o Hint:

The following steps should be taken when configuring the CCP module for PWM operation:

- 1. Set the PWM period by writing to the PR2 register.
- 2. Set the PWM duty cycle by writing to the CCPRxL register and CCPxCON<5:4>bits.
- 3. Make the CCPx pin an output by clearing the appropriate TRIS bit.
- 4. Set the TMR2 prescale value, then enable Timer2 by writing to T2CON.
- 5. Configure the CCPx module for PWM operation.