sebao / 2017-09-26 07:56:00 / 浏览数 7132 安全技术 技术讨论 顶(0) 踩(0)

## 简介:

#### QEMU是一套由法布里斯·贝拉(Fabrice

Bellard)所编写的以GPL许可证分发源码的模拟处理器,在GNU/Linux平台上使用广泛。Bochs,PearPC等与其类似,但不具备其许多特性,比如高速度及跨平台的特性,道

qemu和vmware一样,一种虚拟机软件,只不过qemu能够虚拟的平台更加丰富一些。能够虚拟很多嵌入式平台的设备。

在qemu我们可以运行路由器固件,进行调试,以及漏洞挖掘。大大减少研究成本。穷人必备技能。

# 固件下载

从官网 ftp://ftp2.dlink.com/PRODUCTS/ 下载路由器固件,然后用binwalk解开固件。

## binwalk安装

解路由器固件需要用到binwalk。

本人建议下载源码,自己编译安装,这样可以安装到最新版本,还有一个原因就是 apt-get安装的binwalk会缺少很多依赖。

```
$ sudo apt-get update
$ sudo apt-get install build-essential autoconf git
# https://github.com/devttys0/binwalk/blob/master/INSTALL.md
$ git clone https://github.com/devttys0/binwalk.git
$ cd binwalk
# python2.7■■
$ sudo python setup.py install
# python2.7■■■■■■
$ sudo apt-get install python-lzma
$ sudo apt-get install python-crypto
$ sudo apt-get install libqt4-opengl python-opengl python-qt4 python-qt4-gl python-numpy python-scipy python-pip
$ sudo pip install pyqtgraph
$ sudo apt-get install python-pip
$ sudo pip install capstone
# Install standard extraction utilities■■■■
$ sudo apt-get install mtd-utils gzip bzip2 tar arj lhasa p7zip p7zip-full cabextract cramfsprogs cramfsswap squashfs-tools
# Install sasquatch to extract non-standard SquashFS images
$ sudo apt-get install zlib1g-dev lib1zma-dev lib1zo2-dev
$ git clone https://github.com/devttys0/sasquatch
$ (cd sasquatch && ./build.sh)
# Install jefferson to extract JFFS2 file systems■■■■
$ sudo pip install cstruct
$ git clone https://github.com/sviehb/jefferson
$ (cd jefferson && sudo python setup.py install)
# Install ubi_reader to extract UBIFS file systems
$ sudo apt-get install liblzo2-dev python-lzo
```

\$ git clone https://github.com/jrspruitt/ubi\_reader \$ (cd ubi\_reader && sudo python setup.py install)

# Install yaffshiv to extract YAFFS file systems \$ git clone https://github.com/devttys0/yaffshiv \$ (cd yaffshiv && sudo python setup.py install)

# Install unstuff (closed source) to extract StuffIt archive files

```
$ wget -0 - http://my.smithmicro.com/downloads/files/stuffit520.611linux-i386.tar.gz | tar -zxv
$ sudo cp bin/unstuff /usr/local/bin/
```

#### gemu安装

## qemu 网络配置

qemu网络配置又有很多坑, google&度娘各种搜索,终于解决了,解决办法如下。

```
手动每次配置(启动一次就要配置一次)
```

```
$ sudo apt-get install uml-utilities
$ sudo tunctl -t tap0 -u sebao
$ sudo ifconfig tap0 172.16.0.1/24
ifconfig tap0
```

#### 进入gemu虚拟机再执行一次命令

sudo ifconfig eth0 172.16.0.2/24

### 自动配置

sudo apt-get install uml-utilities

#### sudo vi /etc/network/interfaces

```
auto lo
iface lo inet loopback
auto eth0
iface eth0 inet dhcp
iface br0 inet dhcp
bridge_ports eth0
bridge_maxwait 0
```

# sebao@ubuntu:~\$ sudo cat /etc/default/grub

```
# If you change this file, run 'update-grub' afterwards to update
# /boot/grub/grub.cfg.
# For full documentation of the options in this file, see:
   info -f grub -n 'Simple configuration'
GRUB_DEFAULT=0
GRUB HIDDEN TIMEOUT=0
GRUB_HIDDEN_TIMEOUT_QUIET=true
GRUB TIMEOUT=10
GRUB_DISTRIBUTOR=`lsb_release -i -s 2> /dev/null || echo Debian`
GRUB_CMDLINE_LINUX_DEFAULT="quiet splash"
GRUB_CMDLINE_LINUX="net.ifnames=0 biosdevname=0"
\mbox{\#} Uncomment to enable BadRAM filtering, modify to suit your needs
# This works with Linux (no patch required) and with any kernel that obtains
\sharp the memory map information from GRUB (GNU Mach, kernel of FreeBSD ...)
#GRUB_BADRAM="0x01234567,0xfefefefe,0x89abcdef,0xefefefef"
# Uncomment to disable graphical terminal (grub-pc only)
#GRUB TERMINAL=console
# The resolution used on graphical terminal
# note that you can use only modes which your graphic card supports via VBE
# you can see them in real GRUB with the command `vbeinfo'
```

```
#GRUB GFXMODE=640×480
```

62 ls 63 cd ../

66 cd var/ 67 ls

64 chroot . usr/bin/lighttpd -f mnt/lighttpd/lighttpd.conf 65 cat mnt/lighttpd/lighttpd.conf | grep "lighttpd.pid"

```
# Uncomment if you don't want GRUB to pass "root=UUID=xxx" parameter to Linux
#GRUB_DISABLE_LINUX_UUID=true
# Uncomment to disable generation of recovery mode menu entries
#GRUB_DISABLE_RECOVERY="true"
# Uncomment to get a beep at grub start
#GRUB_INIT_TUNE="480 440 1"
sebao@ubuntu:~$ sudo cat /etc/qemu-ifup
#!/bin/sh
echo "Executing /etc/qemu-ifup"
echo "bridge networking"
sudo ifdown eth0
sudo ifup br0
echo "Bringing up $1 for bridge mode"
sudo /sbin/ifconfig $1 0.0.0.0 promisc up
echo "Adding $1 to br0"
sudo /sbin/brctl addif br0 $1
sleep 2
配置完一定要重启网卡才能生效
sudo /etc/init.d/networking restart
qemu-mips对应包下载
https://people.debian.org/~aurel32/qemu/mips/
我这里下载两个包,这里要对应固件的版本进行下载。这里一定要选择大端和小端。大端和小端是根据固件的架构来选择的。
vmlinux-2.6.32-5-4kc-malta
debian_squeeze_mips_standard.qcow2
启动qemu
qemu-system-mips -M malta -kernel vmlinux-2.6.32-5-4kc-malta -hda debian_squeeze_mips_standard.qcow2 -append "root=/dev/sda1"
console=tty0" -net nic,macaddr=52:54:be:36:42:a9 -net tap
D-link dir601 踩坑
解压web月录
tar zxvf mnt/www.tgz www/
cp usr/bin/my_cgi.cgi www/
直接运行http服务会报各种错误,需要手动创建文件夹,以及文件
创建文件: /var/run/lighttpd.pid
创建文件:/log/lighttpd/error.log
WWW目录下 rt文件夹里面的所有文件, 移动到 www目录
chroot . usr/bin/lighttpd -f mnt/lighttpd/lighttpd.conf
57 cd ../
58 ls
59 cd squashfs-root/
60 ls
61 cd www/
```


```
69 ls
70 cd run
71 vi lighttpd.pid
72 cd ../../
73 chroot .usr/bin/lighttpd -f mnt/lighttpd/lighttpd.conf
77 mkdir log
78 cd log/
79 mkdir lighttpd
80 cd lighttpd/
81 vi error.log
82 cd ../../
83 chroot . usr/bin/lighttpd -f mnt/lighttpd/lighttpd.conf
84 cd www/
85 ls
86 cd rt/
87 ls
88 cd ../
89 ls
90 ls
91 cd rt/
92 ls
93 ls -11
94 cd ../
95 mv rt/ .
96 ls
97 mv rt/* .
```

## 启动固件

68 mkdir run

chroot . usr/bin/lighttpd -f mnt/lighttpd/lighttpd.conf

在浏览器输入 qemu虚拟机的ip 就可以进入路由器的界面了。



# 点击收藏 | 0 关注 | 0

上一篇:威胁情报真的是网络安全的"少数派报... 下一篇:Tomcat漏洞分析—【CVE-2...

# 1. 1 条回复



不会c的程序员 2018-11-27 16:05:01

博主您好,我想问一下这个web目录是哪来的啊,我现在有一个dlink的bin文件,已经用binwalk解包了,现在该怎么做啊

0 回复Ta

登录 后跟帖

先知社区

现在登录

热门节点

技术文章

社区小黑板

目录

RSS 关于社区 友情链接 社区小黑板