Alarm Log Reporting

ADAC

Zone: Prime Start: 12/9/2016 8:22:49 PM End: 12/12/2016 10:27:28 AM

Severity: All Alarm: All Device: All

Category: All 21 Categories Found

| Alarm | Description | Occurrences |
|-----------------|---|-------------|
| PLCR-067 | P2 Process Air Low Pressure Warning | 1 |
| PLCR-092 | P1 Applicators Disabled (OC/GUI Switch) | 1 |
| PLCR-092 | P2 Applicators Disabled (OC/GUI Switch) | 1 |
| PLCZ-006 | 20 Hour Run Active | 1 |
| PLCZ-029 | Auto Mode Active | 1 |
| PLCZ-031 | Teach Mode Active | 1 |
| PLCZ-111 | Break Enabled OS From GUI | 10 |
| PLCZ-112 | Break Enabled From GUI | 10 |
| PNT1-002 | Press master reset | 2 |
| PNT1-214 | Bad cal.tbl.(color[1]-parm[2]) | 2482 |
| PNT1-400 | Applicator enable is OFF | 2 |
| PNT1-462 | %sInvalid instruction argument | 4934 |
| PNT1-487 | Application enable is OFF | 2 |
| PNT1-771 | Color(1) Res:Hrd ratio is 0.0:0.0 | 4934 |
| | External emergency stops | 2 |
| SRVO-037 | P1 IMSTP input (Group:1) | 1 |
| SRVO-037 | P2 IMSTP input (Group:1) | 1 |
| SRVO-233 | TP OFF in T1,T2 | 2 |
| SYST-038 | Operation mode T1 Selected | 2 |
| SYST-043 | TP disabled in T1/T2 mode | 2 |
| TPIF-110 | Screen used by other device | 1 |