Name: Splash Shield

Frequency: Refer to QSI03 05 Level II

Reference drawing: Sabin 5495

PROCEDURE:

Inspect all steps 100%, unless otherwise specified. Reference QSI03 05.

- 1. Cloth gloves must be worn to handle product.
- 2. Check to assure product is free of excess, scratches, discoloration and debris.

Page 1 of 1