MILITARY INSTITUTE OF SCIENCE AND TECHNOLOGY DEPARTMENT OF COMPUTER SCIENCE AND ENGINEERING COURSE TITLE: MICROPROCESSOR AND MICROCONTROLLER SESSIONAL COURSE CODE: CSE 306 LAB MANUAL 1

Basic Idea on MDA-8086 Trainer KIT

RES	system reset	STP	execute user's program, a single step
AD	set memory address	GO	go to user's program or execute monitor functions
DA	Update segment & Offset. and input data to memory	MON	Immediately break user's program and Non makable interrupt.
:	Offset set.	REG	Register Display.
+	Segment & Offset +1 increment. Register display increment.		
-	Segment & Offset -1 increment. Register display decrement.		

FIG: Function of keys

Modes of Operation

- 1. KIT Mode (Takes machine language to process the operation)
- 2. PC Mode (Takes assembly or C programming language to process the operation)



HERE WE START

Check the contents of memory

KEY

LCD

-	Λ.		
-	-\	$ldsymbol{-}$	

_	

_		
_		
u		
\sim		

0

-		
U		

1

0

RES

Seg	Offset	Data
0000	1000	FF
Seg	Offset	Data
000F	1000	FF
Seg	Offset	Data
00F0	1000	FF
Seg	Offset	Data

Seg	Offset	Data
F000	1000	FF
Seg	Offset	Data
F000	1000	FF
Seg	Offset	Data
00F0	0000	FF

MDA-8086 KIT!! Midas 2109-5964

To INPUT DATA

RES

AD

DA

MDA-8086 KIT!! Midas 2109-5964			
Seg	Offset	Data	
0000	1000	FF	
Seg	Offset	Data	
0000	1000	FF	

List of Machine Codes for the Instructions

Assembly code	Machine code
MOV AX,	B8
MOV BL	B3
MOV DX	BA
MOV BX	BB
MOV AL	B0
ADD AX,	05
ADD AL	04
MUL BL	F6 E3
DIV BL	F6 F3
DEC AL	FE C8
MOV CL	B1
MOV AL,CL	8A C1
AND AL	24
OR AL	OC
XOR AL	34
SHL AL,1	D0 E0
SHR AL,1	DO E8
ROL AL,1	D0 C0
ROR AL,1	D0 C8
INC AL	FE CO
ADD AX,BX	03 C8
ADD AX,CX	03 C1
ADD AX,DX	03 C2
NEG AL	F6 D8
SUB BX,CX	2B D9
SUB BX,DX	2B DA
NOT AL	F6 D0

SINGLE LINE PROGRAM

MOV AX,0000 Machine Code: B8 0000

Steps to load it in MDA-8086:

1.RES
2.AD
3.DA
4.B8
5.+
6.00
7.+
8.00
9.STP
10.+

AX=0000 BX=0000 CX=0000

Do it yourself:

1. MOV AX,00F0H	10. NEG AL
2. MOV BL,10H	11. SUB BX,CX
3. MOV DX,-1	12. SUB BX,DX
4. MOV AX,-1	13. MUL BL
5. MOV BX,1	14. DIV BL
6. MOV AL,FFH	15. DEC AL
7. ADD AX,4789	16. INC AL
8. ADD AL,88H	17. ADD AX,BX
9. ADD AX,DX	18. ADD AX,CX

MULTIPLE LINE PROGRAM

MOV AX,05 Machine Code: B8 05

ADD AX,03 05 03

Steps:

 1. RES
 9. +

 2. AD
 10.05

 3. DA
 11.+

 4. B8
 12.03

 5. +
 13.+

 6. 05
 14.00

 7. +
 15.STP

8. 00 16.STP+

TRY IT YOURSELF

Program 1: Program 3:

MOV BL,5 MOV AL,00000001

MOV CL,10 NOT AL

MOV AL,CL AND AL,00001111
MUL BL MOV AL,10101010
OR AL,00001111

XOR AL,11001100

Program 4:

Program 2: MOV AL,11111111

MOV AX,104 SHL AL,1

MOV BL,4 SHR AL,1

DIV BL MOV AL,10001000

ROL AL,1 ROR AL,1