
## SYNTHIAM







## **Assembly Instructions**

Neopixel Blaster Bit [E-22] Rev 2


## PARTS & TOOLS


#	Qty	Name
1	1	Neopixel Blaster Bit
2	1	3 position 0.1" pitch female header
3	1	40-pin Black male 0.1" pitch Male header (3 pin broken off)
4	1	Medium grit file
5	1	Tech Brush
6	1	Flush Cutters






**Step 1.** LED Orientation: Yellow dot indicates pin 3 for U2.






**Step 2.** P1 and P2 Order Pictured. Solder them in place.



**Step 3.** Solder the 6-pins on the back side of E-22.






**Step 4.** Solder a ~0.020" high circular blob on area pictured.


## \*IMPORTANT\*

This is step is for precision fit with ez-clips.






**Step 5.** Trim the 6 pins pictured.






**Step 6.** File down the 6 pins pictured.





**Step 7.** Clean the entire back of the E-22 PCB with a tech brush



The E-22 Neopixel Blaster Bit is now complete.