


SmartHub Diagnostics & Use Case Diagram (Simplified)



How to read (flow)

Technician starts a use case inside the SmartHub system boundary.
Boxes on the right are external systems used by SmartHub (phone, Windows USB/PnP, ADB/Fastboot tools, camera checker, and offline AI helper).
Arrows show interactions: Technician -> SmartHub use cases; SmartHub -> external systems when needed.
USB-only BSOD flow works without USB debugging (skipAdb/usbOnly); camera + offline AI are optional helpers.