# Anziehvorschrift für Zylinderkopf Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

## Prescripciones de apriete para culatas


#### 896.235

passend für / suitable for adaptable à / adaptable a




Mercedes-Benz Das Original

Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo





Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



907.980 M16x2x191

Anziehen/ Tightening/ Serrage/

50 Nm 250 Nm

90° Apriete 90°

### Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
•	Setzzeit	relaxation time	durée de tassement	tiempo de espera
>	Drehwinkel	torque angle	angle de serrage	ángulo de giro

# Motortyp / Engine type / Type de moteur / Tipo de motor

Mot: 14,81 ltr./15,6 tr.

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601 \*896.235\*