# Anziehvorschrift für Zylinderkopf Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

### Prescripciones de apriete para culatas

## 727.894


passend für / suitable for adaptable à / adaptable a Mercedes-Benz



Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo



Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



852.570 M14x186x2

Anziehen/ Tightening/ Serrage/

50 Nm 100 Nm 90°

Apriete 90°

### Zeichenerklärung / Explanations / Explication / Explicacion

	*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
		Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	•	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	>	Drehwinkel	torque angle	angle de serrage	ángulo de giro
ı					

# Motortyp / Engine type / Type de moteur / Tipo de motor

OM 470

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601