Anziehvorschrift für Zylinderkopf Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

Prescripciones de apriete para culatas

380.060


passend für / suitable for adaptable à / adaptable a Mercedes-Benz



Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo



Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



004.210 M15 x 2 x 192

Anziehen/ Tightening/ Serrage/ Apriete

50 Nm 200 Nm 90° 90°

Zeichenerklärung / Explanations / Explication / Explicacion

-	*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
;	*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
[L	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
		Setzzeit	relaxation time	durée de tassement	tiempo de espera
)	★	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

OM 471 Ø 133 mm

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601

380.060