### Anziehvorschrift für Zylinderkopf **Tightening Instructions for Cylinder Head**

# Instructions de serrage pour culasse

### Prescripciones de apriete para culatas


#### 366.670

passend für / suitable for adaptable à / adaptable a



Volkswagen/Audi

Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo









Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



 $\overline{7}$ 







104.930 M 11x1,5x96

Anziehen/ Tightening/ Serrage/ Apriete

40 Nm 60 Nm 90° 90°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
•	Setzzeit	relaxation time	durée de tassement	tiempo de espera
>	Drehwinkel	torque angle	angle de serrage	ángulo de giro

# Motortyp / Engine type / Type de moteur / Tipo de motor

1,8 Ltr. 4 Cyl. 20V, 85-165 kW (115-224 PS)

Mot. ADR, AEB, AGN, AGU, AJL, AJH, AJQ, APX, APT, APG, APP, AQA, ARZ, APY, AMK, APH, ARG, ARK, AFY, ANB, APU, AWC, AWT, AVJ, ARY, AUQ, AUL, AWP, ATC, AMU, AVC, AWU, AWV, ARX, BAM

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601 \*366.670\*