## Anziehvorschrift für Zylinderkopf

Tightening Instructions for Cylinder Head Instructions de serrage pour culasse

## Prescripciones de apriete para culatas

150.172

passend für / suitable for adaptable à / adaptable a Volkswagen



Das Original

Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo

dead shape
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



















057.240 M 12x166-10.9

Anziehen/ Tightening/ Serrage/ Apriete

\* 40 Nm 60 Nm ➤ 90° ➤ 90°

 ${\bf Zeichenerkl\"{a}rung\ /\ Explanations\ /\ Explication\ /\ Explicacion}$ 

*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
•	Setzzeit	relaxation time	durée de tassement	tiempo de espera
>	Drehwinkel	torque angle	angle de serrage	ángulo de giro

## Motortyp / Engine type / Type de moteur / Tipo de motor

₹ 1,65 mm, Ø 80,5 mm, 3 Löcher/holes/trous/agujeros

1,9 Ltr. TDI

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601

\*150 172\*