


ELECROW ESP32 Terminal RGB Touch Display User Manual

Home » ELECROW » ELECROW ESP32 Terminal RGB Touch Display User Manual



ESP32 Terminal RGB Touch Display User Manual



Thank you for purchasing our product.

Please read this user manual carefully before use and keep it properly for future reference.

Contents


- 1 Package List
- 2 Screen Buttons and

Interfaces

- **3 Parameters**
- **4 Expansion Resources**
- **5 Safety Instructions**
- **6 Documents / Resources**
 - **6.1 References**


Package List


The following list diagram is for reference only. Please refer to the actual product inside the package for details.



Screen Buttons and Interfaces

Screen appearance varies by model, and diagrams are for reference only. Interfaces and buttons are silk screen labeled, use actual product as reference.





Parameters

Size	2.4"	2.8"	3.5″
Resolution	240*320	240*320	320*480
Touch Type	Resistive Youch	Resistive Youch	Resistive Youch
Main Processor	ESP32-WROOM-32-N4	ESP32-WROOM-32-N4	ESP32-WROOM-32-N4
Frequency	240 MHz	240 MHz	240 MHz
Flash	4MB	4MB	4MB
SRAM	520KB	520KB	520KB
ROM	448KB	448KB	448KB
PSRAM	/	1	1
Display Driver	ILI9341V	ILI9341V	ILI9488
Screen Type	TFT	TFT	TFT
Interface	1*UART0, 1*UART1, 1*I2C, 1*GPIO, 1*Battery	1*UART0, 1*UART1, 1*I2C, 1*GPIO, 1*Battery	1*UART0, 1*UART1, 1*I2C, 1*GPIO, 1*Battery
Speaker Jack	YES	YES	YES
TF Card Slot	YES	YES	YES
Color Depth	262K	262K	262K
Active Area	36.72*48.96mm(W*H)	43.2*57.6mm(W*H)	48.96*73.44mm(W*H)

Size	4.3"	5.0"	7.0"
Resolution	480*272	800*480	800*480
Touch Type	Resistive Youch	Capacitive Youch	Capacitive Youch
Main Processor	ESP32-S3-WROOM-1- N4R 2	ESP32-S3-WROOM-1- N4R 8	ESP32-S3-WROOM-1- N4R 8
Frequency	240 MHz	240 MHz	240 MHz
Flash	4MB	4MB	4MB
SRAM	512KB	512KB	512KB
ROM	384KB	384KB	384KB
PSRAM	2MB	8MB	8MB
Display Driver	NV3047	+	EK9716BD3 + EK73002ACG B
Screen Type	TFT	TFT	TFT
Interface	1*UART0, 1*UART1, 1*GPIO , 1*Battery	2*UART0, 1*GPIO, 1*Battery	2*UART0, 1*GPIO, 1*Battery
Speaker Jack	YES	YES	YES
TF Card Slot	YES	YES	YES
Color Depth	16M	16M	16M
Active Area	95.04*53.86mm(W*H)	108*64.8mm(W*H)	153.84*85.63mm(W*H)

Expansion Resources

- Schematic Diagram
- Source Code
- ESP32 Series Datasheet
- Arduino Libraries
- 16 Learning Lessons for LVGL
- LVGL Reference

For More Details Please Scan the QR Code.



https://wx.jzx.com/?id=wq09Bd

Safety Instructions

To ensure safe use and avoid injury or property damage to yourself and others, please follow the safety instructions below.

- Avoid exposing the screen to sunlight or strong light sources to prevent affecting its viewing effect and lifespan.
- Avoid pressing or shaking the screen hard during use to prevent loosening of internal connections and components.
- For screen malfunctions, such as flickering, color distortion, or unclear display, stop use and seek professional repair.
- Before repairing or replacing any equipment components, make sure to turn off the power and disconnect from the device.

Company Name: Elecrow Technology Development Co., Ltd.

Company address: 5th Floor, Fengze Building B, Nanchang Huafeng Industrial Park, Baoan District, Shenzhen,

China

E-mail: techsupport@elecrow.com

Company website: https://www.elecrow.com

Made in China



Documents / Resources



ELECROW ESP32 Terminal RGB Touch Display [pdf] User Manual

ESP32 Terminal RGB Touch Display, ESP32, Terminal RGB Touch Display, RGB Touch Display, Touch Display

References

• <u>Selection: PCB Prototype & Open Hardware For Makers</u>

Manuals+,