12.07.2017

Bluetooth Developer Studio Level 1 Profile Report

PROFILE

Profile Name

STUFF MANAGER

Abstract:

The Stuff Manager profile enables the monitoring for some stuff. It's based on a scheme Master-Slave.

Summary:

The Stuff Manager profile defines the interactions for a device who will manage some stuff. There is two roles defined here: Master for the Client and Slave for the Server. The Master will send a command to the Slave and, depends of the mode, will send the list of the stuff or other operations.

Base UUID

e71a00006ed94a89bbbf98a29df5e71a

Server Role

Client Role

SERVICES

Stuff Manager Mandatory E71AE71A6ED94A89BBF98A29DF5E71A

Entry Value: Mandatory: E71AE71D6ED94A89BBBF98A29DF5E71A

Entry Selection: Mandatory: E71AE71C6ED94A89BBBF98A29DF5E71A

Manager Mode: Mandatory: E71AE71F6ED94A89BBBF98A29DF5E71A

Entry Number: Mandatory: E71AE7106ED94A89BBBF98A29DF5E71A

Link Loss Mandatory 1803

Alert Level: Mandatory: 2A06

1 sur 1 12/07/2017 10:28