Wall Mounting Procedures

ACR120 Contactless Reader/Writer



Special note to customers:

If you are looking for *ACR120 readers for wall mounting applications*, *please kindly notify the sales representative in advance* so that you will receive the ACR120 readers with separate PVC stickers.
(You will receive the individual PVC stickers at the same time so that after wall mounting, you can put it back to protect the casing.)

Dimensions of suggested screws (for wall-mounting)



1. Please make sure that no front sticker is attached to the ACR120 reader front casing.



2. Remove the rubber feet at the back so that you can drive in the screws.

3. Tighten the screws.