


ANCHOR SETTING DETAIL

AR1
(REFER PLAN FOR COL. ORIENTATION & SIZES)


34 LOCATION



ANCHOR SETTING DETAIL

AR4
(REFER PLAN FOR COL. ORIENTATION & SIZES)

9 LOCATION



TOP OF PIER TOP OF PIER TOP OF PIER TOP OF PIER (2) HEAVY HEX NUT EACH.

ANCHOR SETTING DETAIL


AR2
(REFER PLAN FOR COL. ORIENTATION & SIZES)

13 LOCATION

ANCHOR SETTING DETAIL

AR3
(REFER PLAN FOR COL. ORIENTATION & SIZES)

11 LOCATION



ANCHOR SETTING DETAIL

AR5
(REFER PLAN FOR COL. ORIENTATION & SIZES)

3 LOCATION

