SiPi Wiring Diagram



* Servo I requires USB-Serial Adapter with FTDI chipset

**Ethernet required for updates