
1. Introduction

This tutorial teaches you how to upgrade your device using the upgrade software.

2. Hardware and software preparation

- A PC or laptop running windows XP, windows 7, windows 10 above or windows Vista.
- One USB cable (standard)
- Upgrade software









3. Connection

Connect the USB cable to the computer and open the device manager. Find the "Prolific USB-to-Serial Comm port", as shown below.






Note: 1. Remember the port number. Select this port number when using the upgrade software.

- 2. A standard USB cable must be used.
- 3. Do not move devices and data lines during upgrade.

4. Upgrade


- 4.1 Connect the computer and device with a USB cable first
- 4.2 Run the upgrade software to enter the initial page.

Upgrade description




4.3 Click the port drop-down box and select the correct port number, as shown


below:




4.4 Click the "select hex file" button, then in the window that pops up open the correct firmware upgrade and click the Open button, as shown below:



4.5 Click the Restart button to restart the device, as shown in the following figure:



4.6 Click the restart button, and then click the "upgrade" button to link the upgrade file to upgrade, as shown below:



4.7 After a few seconds, the system displays a message indicating that the upgrade is successful. The device can be used normally.

