
Auto Reporting with Map Legend Optimization


Use Legend Setting feature of Map to change Symbol color.

Usage of this feature is as below.

1. Select pop-up menu in Map or Map Setting in Tool bar.



2. Select Parameter to create a Report from the Parameter Tree on the left.




3. Changes Color, Symbol and Size of the Legend on the right. Uncheck the option on the lower-left corner to change configuration when user desires differential application to Symbol and Size by Range.

4. Double-click Min/Max.Com column and enter value to change Range.


© Copyright by Accuver Co., Ltd.

5. Use icon to add and delete Range.
6. As a reference, Batch feature can be used to change Range at once.



7. Start Auto Report Menu after configuring Legend to design the Parameter to create Report.
8. Click New icon in Report List to enter the Title.
9. Select Map tab from the Parameter Tabs on the right, and select a Parameter to Drag & Drop as shown below.

© Copyright by Accuver Co., Ltd.



10. After selecting a parameter, click Map option button to configure necessary options.


11. Corresponding option can be configured by each parameter.


© Copyright by Accuver Co., Ltd.

Examples

Overlap Setting


1. Map Option>Param Setting






© Copyright by Accuver Co., Ltd.

Output>>




© Copyright by Accuver Co., Ltd.

Area Binning Setting




Output>>




No.	Range	Count	Percentage
1	-40 <= x	0	0.00%
2	-50 <= x < -40	0	0.00%
3	-60 <= x < -50	0	0.00%
4	-70 <= x < -60	13	3.30%
5	-80 <= x < -70	151	38.32%
6	-90 <= x < -80	215	54.57%
7	-100 <= x < -90	15	3.81%
8	x < -100	0	0.00%

© Copyright by Accuver Co., Ltd.

Filter Application



Output>>



No.	Range	Count	Percentage
1	-8 <= x	0	0.00%
2	-10 <= x	0	0.00%
3	-12 <= x	0	0.00%
4	-14 <= x	0	0.00%
5	-16 <= x	1	25.00%
6	-20 <= x	2	50.00%
7	x < -20	1	25.00%

© Copyright by Accuver Co., Ltd.