Event Call Extract from Statistics Window

Call Statistics of Statistics Tab in XCAP is activated when Data is measured through Auto call function in measurement device XCAL.


When Event occurs in the measured Logs, Event Call (Drop, Fail, Pending, etc) can be extracted to create an individual drm file in XCAP.

This is useful to manage Calls with Event occurred or send corresponding log to another person since the individual file only contains Calls.

Usage


Procedures are as follows.

1. Open Call Statistics to select Event Call.
2. Select Create Log File > Each Call menu of Mouse Pop-up menu.




3. When select Each Call menu, model is created with displaying progress bar.
4. The select call is saved as model to the path saved initial drm file. Call event and signaling message are saved as text file automatically to event folder.

© Copyright by Accuver Co., Ltd.




Use Create model feature to process multiple Calls at once.

1. Before selecting a Call, Select Save a logging file when "create model" option in Tools>Options>Path>Path to save a logging file menu and define a path.




2. Select Event call as shown below. (Use Ctrl Key when not continuous.)



© Copyright by Accuver Co., Ltd.

3. Create log file in the designated path.



4. Open Call Statistics after creating Create model to see the result below.

No	Result (End By User event is excluded for statistics calculation.)	Reason	Connection Cause(LTE)	Call Type	Service Type	Start Time
1	Fail		mo_Data	Origination	Voice Call	2014-08-19 14:30:07.035
2	Fail		mo_Data	Origination	Voice Call	2014-08-19 14:33:37.133
3	Fail		mo_Data	Origination	Voice Call	2014-08-19 14:37:07.075
4	Fail		mo_Data	Origination	Voice Call	2014-08-19 14:44:07.033
5	Fail			Origination	Voice Call	2014-08-19 14:47:37.083

© Copyright by Accuver Co., Ltd.