
Exporting Batch using Batch Export Feature

This function is used to automatically export batch file through Batch Export feature. It creates model for user-desired KPI item and simultaneously saves the result as excel or csv file.

Exporting while Model Creation with Favorite List


Procedure to export batch while model creation is as shown below.

1. Create parameter list using Table analysis or Tools>Favorite Manager Menu.




2. Open New window and moves drm file to create to Select Files section. (Batch can be grouped for each call type, optimization status, region and mobile.

© Copyright by Accuver Co., Ltd.




3. Select Option of New Window and then select Batch Export button.



© Copyright by Accuver Co., Ltd.


4. Select Favorite menu in Batch Export Setting window.



5. Click Setting menu of next to the Favorite menu.


6. Check created List in Favorite Setting window. User is able to select duplicated lists when several lists exist. (The list is added next to first item.)

© Copyright by Accuver Co., Ltd.




7. Click OK to create Model.

8. The result file is simultaneously saved to configured path when Model is created.



© Copyright by Accuver Co., Ltd.



	A	B	C	D	E	F
1	TIME_STAMP	LTE KPI Serving PCI	LTE KPI Serving RSRP[dBm]	LTE KPI Serving RSRQ[dB]	LTE KPI Serving RSRQ[dB]	LTE KPI Serving RSSI[dBm]
2	2013-06-15 15:50:28.000	218	-67.69	-7.38	-7.38	-43.38
3	2013-06-15 15:50:29.000	218	-67.69	-7.44	-7.44	-43.25
4	2013-06-15 15:50:30.000	218	-67.56	-7.31	-7.31	-43.25
5	2013-06-15 15:50:32.000	218	-67.69	-7.31	-7.31	-43.44
6	2013-06-15 15:50:33.000	218	-68.06	-7.25	-7.25	-43.81
7	2013-06-15 15:50:34.000	218	-67.13	-6.94	-6.94	-43.19
8	2013-06-15 15:50:35.000	218	-67.69	-7.19	-7.19	-43.5
9	2013-06-15 15:50:37.000	218	-68.06	-7.56	-7.56	-43.5
10	2013-06-15 15:50:38.000	218	-67.94	-7.56	-7.56	-43.44
11	2013-06-15 15:50:40.000	218	-67.81	-7.56	-7.56	-43.25
12	2013-06-15 15:50:41.000	218	-68.38	-7.56	-7.56	-43.81
13	2013-06-15 15:50:42.000	218	-68.5	-7.38	-7.38	-44.13
14	2013-06-15 15:50:43.000	218	-69.49	-7.59	-7.59	-44.72
15	2013-06-15 15:50:44.000	218	-69.74	-7.5	-7.5	-44.89
16	2013-06-15 15:50:45.000	218	-69.72	-8.65	-8.65	-43.35
17	2013-06-15 15:50:46.000	218	-69.66	-7.93	-7.93	-44
18	2013-06-15 15:50:47.000	218	-69.61	-8.67	-8.67	-42.66
19	2013-06-15 15:50:48.000	218	-69.59	-9.49	-9.49	-42.31
20	2013-06-15 15:50:49.000	218	-69.72	-10.42	-10.42	-41.76
21	2013-06-15 15:50:50.000	218	-69.6	-8.43	-8.43	-43.14
22	2013-06-15 15:50:51.000	218	-69.48	-8.64	-8.64	-42.74


Example of Batch Export

© Copyright by Accuver Co., Ltd.


Exporting in Workspace

Procedure to export batch in workspace is as shown below.

1. First of all, create workspace to use this feature.
2. Use Table, graph, map, cdf, pdf, pie/bar while clicking Workspace icon to display 'check' to create in workspace.
3. Displayed items can be confirmed in Display manager on the bottom of left side in marked red box.




4. Execute workspace list manager when user completes selecting data to display.
5. Click New and configure name to save the item. Use export feature to create individual files.
6. Please note that workspace list and Model of model manager must be identically configured. Example of saving Workspace is shown below.



7. Configure Graph, map and chart according to Window size before saving workspace as export is processed according the displayed size.

© Copyright by Accuver Co., Ltd.

8. Complete Workspace setting and select Logging file.




9. Select Option>MISC.>Batch Export>Workspace and click Setting button.

10. Select Workspace and configure path to save the file.

11. Use Import Workspace feature to load saved workspace.

© Copyright by Accuver Co., Ltd.



12. Result Screen is shown below.

