
Message Duration Time Analysis

Message Duration Time Analysis is a feature to create Duration Time of L3 Message, Autocall Event, SIP Message by section based on user definition.

User may compare Duration between Signaling Message on each Call/Business measurement Logs, and is able to confirm existence of Messaged within user-defined Time.

Procedure to use Message Duration Statistics feature is shown below.

1. Select Message Duration Time from Statistics Tab.
2. Select Message window appears when Message Duration Time is selected, as shown below.



3. Select desired Message from Select Message window. Selecte Message will be displayed on Condition List. Detailed desription of each column of Select Message window is shown below.

Classification	Description
Message Tree	Display messages
Condition List	User Section Setting List
From	Starting Point of the selected List
To	Ending Point of the selected List

© Copyright by Accuver Co., Ltd.

Classification	Description
First/Last	Option to select First or Last message to apply when duplicate messages are received
Select	Select to define Call section based on Autocall ◆ With Regard to Call: Define Call section based on Autocall ◆ Regardless of Call: Process regardless of Autocall

Cf) When logged with Autocall, With Regard to Call is the Default option and it defines sections between Call Start(or Idle Start) ~ Call End.

Notice) When logged with Chipset Time, it displays Time Difference value using Chipset Time between two Messages.

4. Click OK after selection.
5. Message Duration Time Result Window will appear when OK button is clicked, as shown below.

No	From	To	RRC Setup Time	LTE Call Setup Time	Invite ~ 180 Ringing
1	2012-07-06 14:09:35.749	2012-07-06 14:09:51.068	0.012	0.062	0.035
2	2012-07-06 14:10:07.599	2012-07-06 14:10:26.148	0.012	0.062	0.035
3	2012-07-06 14:10:42.023	2012-07-06 14:11:00.812	0.012	0.062	0.035
4	2012-07-06 14:11:16.687	2012-07-06 14:11:30.813	0.012	0.062	0.035
5	2012-07-06 14:11:46.672	2012-07-06 14:12:05.869	0.012	0.062	0.035
6	2012-07-06 14:12:21.713	2012-07-06 14:12:35.463	0.012	0.062	0.035
7	2012-07-06 14:12:51.338	2012-07-06 14:13:07.911	0.012	0.062	0.035
8	2012-07-06 14:13:23.771	2012-07-06 14:13:36.209	0.012	0.062	0.035
9	2012-07-06 14:13:52.037	2012-07-06 14:14:07.719	0.012	0.062	0.035
10	2012-07-06 14:14:23.750	2012-07-06 14:14:35.954	0.012	0.062	0.035
Count	10	10	0	1	0
Minimum				0.062	
Maximum				0.062	
Average				0.062	
Stdev				0	

Message Duration calculates duration between message of previous and current Column by default. Statistics window displays all calculated results min/max/average of the corresponding Model, and Call Number is displayed for the Calls that does not satisfy user-configured Threshold.

© Copyright by Accuver Co., Ltd.