

Media flange	Technical data
Media flange pneumatic	Interfaces
	(>>> 6.2.2.1 "Interface, media flange pneumatic" Page 43)
	Wiring diagram
	(>>> 6.2.2.2 "Wiring diagrams, media flange pneumatic" Page 44)
	 Connector bypack X651 required
	(>>> 6.2.5 "Connector bypack X651" Page 54)
Media flange IO pneumatic	Interfaces
	(>>> 6.2.3.1 "Interface, media flange IO pneumatic" Page 45)
	Wiring diagram
	(>>> 6.2.3.2 "Wiring diagrams, media flange IO pneumatic" Page 46)
	Connecting cable set X650, X651
	(>>> 6.2.6 "Data cable" Page 54)
Media flange Touch pneu- matic	Interfaces
	(>>> 6.2.4.1 "Interface, media flange Touch pneumatic" Page 50)
	Wiring diagram
	(>>> 6.2.4.2 "Wiring diagrams, media flange Touch pneumatic" Page 51)
	Connecting cable set X650, X651
	(>>> 6.2.6 "Data cable" Page 54)

6.2.1 Media flange electrical

6.2.1.1 Interface, media flange electrical

Overview




Fig. 6-3: Interface for media flange electrical

- 1 X36 power supply
- 2 X32 power supply
- 3 X33 power supply
- 4 X2 CAT5 interface
- 5 X35 power supply
- 6 X34 CAT5 interface



Connection/ function

Connection	Function
X2	CAT5 interface
	4x AWG 26 shielded (CAT5), external via X651, M8 connection, 4-pole
X36	Power supply
X32	max. 60 V / 4 A per connection, max. total 8 A, external via X651, M8 connection, 3-pole
X33	Power supply
X35	max. 60 V / 4 A per connection, max. total 5 A, external via X76, M8 connection, 3-pole
X34	Interface for analog signals and CAT5
	6x AWG 28 shielded, external via X76, M8 connection, 8-pole

6.2.1.2 Wiring diagrams, media flange electrical

Connection X651, X32, X36




Fig. 6-4: Wiring diagram, MF electrical, X651, X32, X36



Connection X651, X2






Fig. 6-5: Wiring diagram, MF electrical, X651, X2

Connection X76, X33, X35





Fig. 6-6: Wiring diagram, MF electrical, X76, X33, X35

Connection X76, X34






Fig. 6-7: Wiring diagram, MF electrical, X76, X34