

Griffin: Steady State vs. Transient

Steady State

```
TRANSPORT SYSTEM
TransportSystems]
particle
                                = neutron
 equation type
                                = eigenvalue
                                = 16
 ReflectingBoundary
                                = 'left'
VacuumBoundary
                                = 'bottom right top loop b
 [transport]
                                = CFEM-Diffusion
   scheme
   family
                                = LAGRANGE
                                = FIRST
   order
   n delay groups
   assemble scattering jacobian = true
   assemble_fission_jacobian
                                = true
   external dnp variable
                                = 'dnp'
   fission source aux
                                = true
```

Transient

```
TRANSPORT SYSTEM
[TransportSystems]
 particle
                                = neutron
                                 = transient
 equation type
                                 = 16
                                = 'left'
 ReflectingBoundary
 VacuumBoundary
                                 = 'bottom right top loop
 [transport]
   scheme
                                 = CFEM-Diffusion
   family
                                 = LAGRANGE
   order
                                 = FIRST
   n delay groups
                                 = 6
   assemble_scattering_jacobian = true
   assemble fission jacobian
                                = true
   external dnp variable
                                = 'dnp'
   fission source aux
                                = true
```

Remove initial conditions of the restarted variables.

Griffin: Steady State vs. Transient

Steady State

Transient

```
[Executioner]
                     = Transient
 type
                     = PJFNK
 solve type
 petsc options iname = '-pc type -pc hypre type -ksp gmres restart'
 petsc options value = 'hypre boomerama 50'
 start time = 0.0
 [TimeStepper]
                     = IterationAdaptiveDT
   type
                     = 1.0
   dt
   timestep limiting postprocessor = dt max pp
   optimal iterations = 20
   iteration window = 2
   growth factor
   cutback factor
                     = 0.5
 end time
                     = 2000.0
 auto advance
                     = true
 l max its
                     = 200
 nl abs tol
 fixed point min its = 1
 fixed point max its = 50
 fixed point rel tol = 1e-5
 fixed point abs tol = 1e-5
```

Restart Griffin Steady State Solution

- Remove initial conditions of the restarted variables.
- Restart steady state transport solution from binary file using user object.

```
USER OBJECTS FOR RESTART
UserObjects1
 [transport solution]
                  = TransportSolutionVectorFile
  type
  transport system = transport
  writing
                 = false
  execute on
                  = 'INITIAL'
  scale with keff = false
                  = '../../ex2 ss/ex23 fp multiphysics/'
  folder
 [auxvar solution]
                   = SolutionVectorFile
  type
                  = ' vel x vel y T salt T solid
                                                         c1
                                                                c2
                                                                                                 ad C12
  var
                     ad U235 ad U238 ad Be9 ad Li7 ad F9 ad Zr90 ad Zr91 ad Zr92 ad Zr94
                                                                                                ad Zr96'
                                                                                                 ad C12
  loading var
                  = ' vel x vel y T salt T solid
                                                         c1
                                                                c2
                                                                      c3
                     ad U235 ad U238 ad Be9 ad Li7 ad F9 ad Zr90 ad Zr91 ad Zr92 ad Zr94
                                                                                                ad Zr96'
  writing
                   = false
  execute on
                   = 'INITIAL'
  folder
                  = '../../ex2_ss/ex23_fp_multiphysics/'
```

```
[AuxVariables]
  [T salt]
    family
                      = MONOMIAL
    order
                      = CONSTANT
    block
                      = ${all blocks}
  [T solid]
    family
                      = MONOMIAL
    order
                      = CONSTANT
    block
                      = ${solid blocks}
  [c1]
    order
                      = CONSTANT
    family
                      = MONOMIAL
    block
                      = ${salt blocks}
  [c2]
    order
                      = CONSTANT
    family
                      = MONOMIAL
    block
                      = ${salt blocks}
  [c3]
    order
                      = CONSTANT
    family
                      = MONOMIAL
    block
                      = ${salt blocks}
  [c4]
    order
                      = CONSTANT
    family
                      = MONOMIAL
                      = ${salt blocks}
    block
```

Restart Pronghorn Steady State Solution

- Remove initial conditions of the restarted variables.
- Restart steady state solution from exodus output file.

```
FV VARIABLES
Variables1
 [superficial_vel_x]
                             = PINSFVSuperficialVelocityVariable
  tvpe
  block
                             = ${fluid blocks}
  initial from file var
                             = superficial vel x
  initial_from_file_timestep = LATEST
 [superficial_vel_y]
                             = PINSFVSuperficialVelocitvVariable
  type
  block
                             = ${fluid blocks}
  initial from file var
                             = superficial vel y
  initial_from_file_timestep = LATEST
 [pressure]
                             = INSFVPressureVariable
  type
  block.
                             = ${fluid_blocks}
  initial from file var
  initial from file timestep = LATEST
 [T_fluid]
   type
                             = INSFVEnergyVariable
                             = ${fluid blocks}
   initial_from_file_var
                             = T fluid
   initial from file timestep = LATEST
```

```
[AuxVariables]
 [power density]
                               = MooseVariableFVReal
   tvpe
   initial from file var
                              = power density
   initial from file timestep = LATEST
 [power_density_fuel]
                              = MooseVariableFVReal
   type
   initial from file var
                              = power density fuel
   initial from file timestep = LATEST
 [power density graph]
                               = MooseVariableFVReal
   type
   initial from file var
                              = power density graph
   initial from file timestep = LATEST
 [fission source]
                              = MooseVariableFVReal
   type
   initial from file var
                              = fission source
   initial from file timestep = LATEST
```



Battelle Energy Alliance manages INL for the U.S. Department of Energy's Office of Nuclear Energy. INL is the nation's center for nuclear energy research and development, and also performs research in each of DOE's strategic goal areas: energy, national security, science and the environment.