CAD Lecture 6

- 1. In Command option write un, then enter. Choose Engineering option instead of Decimal and Precision $> 2^{nd}$ Option.
- 2. In Command option write d, then enter. Choose modify >Primary units > then choose Engineering option instead of Decimal and Precision > 2^{nd} Option.
- 3. To make reduce the size of the drawing in your display, Choose View > Zoom > Out (Several times as you need).
- 4. First draw all the black hidden lines (but in **by layer option that means straight line**) of the outlines
- 5. Then draw all the hidden lines (but in by layer option that means straight line) of the inside of the apartment.
- 6. Then give the offset.
- 7. Then fillet option.
- 8. Now change all the **by layer option that means straight line** into hidden lines.
- 9. All the dimensions given inside (Drawing, Dining, Toilet etc.) without considering the offset distance.
- 10. Take offset distance 5" (Also for the stairs).
- 11. Give dimensions (change the dimension height to see it in the screen) and Text.

CAD Lecture 7 & 8

*SB of toilet > Outside wall

*SDB > Drawing room

