TempTrek

Environmental Monitoring System — User Manual

Everyday instructions for operators, reviewers, approvers, and administrators.

Application version	2.5.5 (Windows x64)
Who should use this	Authorized TempTrek users
Purpose	Daily monitoring, reviewing data, reporting, and safe administration

Use only your own account. Never share passwords or approve data you have not personally reviewed.

1. Getting started

Sign in

1. Open TempTrek and approve the Windows UAC prompt if it appears.
2. Enter your TempTrek user name and password.
3. If your password has expired, enter your current password and set a new password when prompted.

After signing in, the menu shows only the functions permitted for your account. If a menu item is not visible, ask the Super Admin to confirm your access role.

Understand the dashboard

Item	Meaning
Device card	Shows the monitored device and its current channel values.
Current value	The most recently successful value read from the device.
STALE status	A recent refresh failed; check the device and network. The last good reading is retained.
Live Log	Shows recent communication and measurement activity.
Start / Stop monitoring	Starts or stops polling for a device. Use only if your procedure and permissions allow it.

> **Daily check:** verify that each required device has a current timestamp and a plausible value before relying on the data.

2. Monitor devices

1. Open **Dashboard**.
2. Review each device card for current values, status, and stale indicators.
3. Open **Live Log** when you need a detailed recent activity view.
4. If a device is stale or disconnected, check power, network cable, IP address, port, slave ID, and field-device status. Report the issue according to your site procedure.

TempTrek polls configured devices in the background. It stores readings at the interval chosen by the system administrator, so a dashboard update does not necessarily mean a new CSV record was written at that exact moment.

3. Review and approve historical data

View data

1. Open **FDA 21 CFR → View Data**.
2. Select the device and the exact From and To date/time range.
3. Select **Load Data**.
4. Review the displayed records, values, timestamps, and any status information.

Loading data creates a viewed-record history with your user name, workstation, and time. This is intentional and supports traceability.

Approve data

1. First load and review the exact data range in **View Data**.
2. Open **FDA 21 CFR → Approved Data** or use the approval action available to your authorized role.
3. Confirm the selection, enter any required note, and re-enter your password when prompted.
4. Confirm the approval only after checking that the displayed data is correct and complete.

> **Approval is an electronic confirmation.** You cannot approve a range that was not loaded and reviewed. Do not approve on behalf of another person.

Report status

Reports that include any unapproved record are marked **DRAFT**. Reports containing only approved records are marked **FINAL / APPROVED**.

4. Export reports and trends

1. Use **Reports / PDF → Export / Download** for data export, or **Historic Trends** to review graphical history.
2. Select the correct device, channels, and time range.
3. Choose CSV/Excel-compatible export or PDF, as permitted.
4. Review the output filename and save location before confirming.

PDF reports support up to 10 registers and 50,000 records per export. Narrow the selection if you exceed a limit.

5. Alerts and notifications

Authorized administrators configure alert rules under **Notifications**. Operators should treat alerts as prompts to investigate the monitored environment according to site procedure.

When an alert occurs

1. Identify the device, channel, value, threshold, and time from the alert or dashboard.
2. Check the physical condition and the device reading where safe to do so.
3. Record the response or escalation required by your SOP.
4. Do not silence, alter, or remove rules unless you have authorization.

Scheduled report email

Scheduled PDF emails run only while TempTrek is open. If a report is not received, confirm that the application is running, the schedule is enabled, email settings are valid, and the network allows the SMTP connection.

6. Administration basics

Users and passwords

Use **Administration → System Users** only if you have permission. Create individual accounts, apply least-privilege permissions, and remove access promptly when a person no longer needs it. The Super Admin controls password expiry settings.

Device configuration

Use **Administration → Device Manager** to add or change device connections, register mappings, data types, scaling, and recording intervals. Any configuration change can affect recorded data; follow site change control and verify readings after the change.

Company details

Use **Administration → Company Details** to change the report header and logo. Check a generated PDF after making a change.

7. Backup, restore, and troubleshooting

Back up

Only an elevated Windows administrator with the application **Backup & Restore** permission can manage backups.

1. Open **Administration** → **Backup & Restore**.
2. Set or enter the dedicated backup password when prompted.
3. Select **Create Backup Now** and wait for a successful result.
4. Keep the backup password separate from your TempTrek login password.

Restore

Restore is an administrator-controlled recovery action. It creates a safety backup, pauses monitoring, validates the archive, and requires TempTrek to restart after success. Do not manually copy files into TempTrek folders as a substitute for restore.

Quick troubleshooting

Issue	Action
Cannot sign in	Check user name and password. If expired, complete the password-change prompt. Contact the Super Admin if your account is locked or missing.
Device shows STALE	Check device power, LAN connection, IP/port/slave ID, and field-device health. Escalate if readings are safety or quality critical.
Report is DRAFT	At least one selected record is unapproved. Review the intended range and complete approval if authorized.
Backup button fails	Run TempTrek as a Windows administrator and verify the application's Backup & Restore permission.
Email alert/report not received	Confirm TempTrek is running, recipient address is correct, and ask an administrator to test SMTP configuration.