Chapter 4-Fig4-1




Table 10-1: Interrupt Vector Table for the ATmega32 AVR

Interrupt	ROM Location (Hex)
Reset	0000
External Interrupt request 0	0002
External Interrupt request 1	0004
External Interrupt request 2	0006
Time/Counter2 Compare Match	0008
Time/Counter2 Overflow	000A
Time/Counter1 Capture Event	000C
Time/Counter1 Compare Match A	000E
Time/Counter1 Compare Match B	0010
Time/Counter1 Overflow	0012
Time/Counter0 Compare Match	0014
Time/Counter0 Overflow	0016
SPI Transfer complete	0018
USART, Receive complete	001A
USART, Data Register Empty	001C
USART, Transmit Complete	001E
ADC Conversion complete	0020
EEPROM ready	0022
Analog Comparator	0024
Two-wire Serial Interface (I2C)	0026
Store Program Memory Ready	0028

Table 10-3: Interrupt Vector Name for the ATmega32/ATmega16 in WinAVR

Interrupt	Vector Name in WinAVR
External Interrupt request 0	INT0_vect
External Interrupt request 1	INT1_vect
External Interrupt request 2	INT2_vect
Time/Counter2 Compare Match	TIMER2_COMP_vect
Time/Counter2 Overflow	TIMER2_OVF_vect
Time/Counter1 Capture Event	TIMER1_CAPT_vect
Time/Counter1 Compare Match A	TIMER1_COMPA_vect
Time/Counter1 Compare Match B	TIMER1_COMPB_vect
Time/Counter1 Overflow	TIMER1_OVF_vect
Time/Counter0 Compare Match	TIMER0_COMP_vect
Time/Counter0 Overflow	TIMER0_OVF_vect
SPI Transfer complete	SPI_STC_vect
USART, Receive complete	USART0_RX_vect
USART, Data Register Empty	USART0_UDRE_vect
USART, Transmit Complete	USART0_TX_vect
ADC Conversion complete	ADC_vect
EEPROM ready	EE_RDY_vect
Analog Comparator	ANALOG_COMP_vect
Two-wire Serial Interface	TWI_vect
Store Program Memory Ready	SPM_RDY_vect